SAMSUNG DIGITall
everyone's invited™

- **SMS/EMS Messaging**

- **Vibrant Color Display**

- **Java Enabled**

- **GPRS Technology**

B_k_R_e_A_y_N_s_D®
CUSTOMER LOYALTY
AWARD WINNER
2003

Samsung mobile phones have been rated number one in brand loyalty by consumers two years in a row according to Brand Keys, a leading independent authority on brand loyalty.

Training
Guide

SAMSUNG

SGH x426

Key Features and Benefits

SMS/EMS Messaging

Your customers can send and receive instant text messages (SMS) with an attached icon or sound (EMS).

Vibrant UFB Color Display

Allows you to view games, the Internet, and more in Ultra Fine Bright color.

Java Enabled

With this technology embedded in the phone, you can download more applications, games, and sounds.

Get to know your phone

Earpiece/ Receiver

Display Screen

Menu   Name

SAMSUNG

Antenna

Headset Jack

Navigation Key

Quick Internet Access

Volume Keys

Left Soft Key

Right Soft Key

END / POWER Key

SEND Key

Clear Key

VoiceMail

Numeric Keypad

Asterisk / Shift Key

Space / Silent Mode Key

Microphone

Accessory Interface Connector

Quick Reference

Create a Text Message

1. Press ⋮ for **Menu**, the 1∞ for **Messages** and 3DEF for **Write New**.

2. Enter your message then press ⋮ for **Options**. The following options are available:
   • **Send**: The message is sent then deleted.
   • **Save and Send**: The message is sent and then a copy is saved in your Outbox.
   • **Save**: The message is saved in your Outbox and can be sent at a later time.

3. Select an option and press the ⋮ for **OK**.

Write a Calendar Memo

1. Press ▣ up to open the Calendar.

2. Select a date on the calendar, using the ▣ keys and press ⋮ for **Select**.

   Note: To skip to the previous or next month, press the ⸰ keys on the left side of the phone.

3. Enter your memo and then press ⋮ for OK.

4. You are asked if you wish to set an alarm. If you want the alarm to ring on the chosen day, press ⋮ for **Yes** or ⋮ for **No**. The memo is saved and the display returns to the calendar.

5. If you selected **Yes**, set the time for the alarm and press ⋮ for **OK**. You can also select the melody for the alarm by pressing ⋮ for **Melody**.

6. Press 1∞ for **AM** or 2ABC for **PM**.

Create a To Do List

1. Press ⋮ for **Menu**, 5JKL for **Organizer**, and 2ABC for **To Do List**.

2. Press ⋮ for **New** and enter a task.

   Note: You can enter up to 40 characters.

3. Press ⋮ for **OK**.

4. Select **High**, **Normal** or **Low** priority using the ▣ keys and press ⋮ for **Select**.

5. Enter your deadline and press ⋮ for **OK**. If you do not want to set a deadline, press ⋮ for **Skip**.

Store Phonebook Entries

1. Enter the phone number you want to store.

2. Press ⋮ for **Save**.

3. Select ▢Mobile , ▦Work or ⌂Home and press ⋮ for **Select**.

4. Enter a name for the contact.

5. Press ⋮ for **OK** to save to the SIM card or press ⋮ for **To Phone** if you prefer to use the phone's internal memory.

Set an Alarm

1. Press ⋮ for **Menu**, the 5JKL for **Organizer** and 4GHI for **Alarm**.

2. Choose the type of alarm and press ⋮ for **Select**.
   Once Alarm: rings on only one day
   Daily Alarm: rings every day at the same time
   Morning Call: rings to wake you up in the morning

3. Enter the time for the alarm and press ⋮ for **OK**.

4. Choose **AM** or **PM** using the ▣ key and press ⋮ for **Select**.

   Note: Your phone is preset to use 12-hour format.

Placing Multi-Party Calls (Where available)

1. Call the first participant in the normal way.

2. Call the second participant in the normal way. The first call is automatically put on hold.

3. To connect the first participant to the multi-party call, press ⋮ for **Options** and then 4GHI for **Join**.

4. To add additional people (up to six) to the multi-party call, repeat the steps as needed.

   Note: You can add incoming callers by pressing ⋮ for **Accept** to answer the call, and then pressing ⋮ for **Options** and 4GHI for **Join**.

SGH X426

Standby Menu

Main Menu	Menu Level 1	Menu Level 2
1. Messages ⇨	1. Inbox	
	2. Outbox	
	3. Write New	
	4. Templates	
	5. Settings ⇨	1. Setting 1 *
		2. Setting 2 *
		3. Common Setting
	6. My Objects ⇨	1. My EMS Melody
		2. My EMS Picture
		3. My EMS Animation
		4. Delete All
	7. Delete All ⇨	1. Inbox
		2. Outbox
		3. All Messages
		4. CB Message
	8. Memory Status	
	9. Voice Mail ⇨	1. Connect to Voice Server
		2. Voice Server Number
	0. Broadcast ⇨	1. Read
		2. Receive
		3. Channel List
		4. Language
2. Call Records ⇨	1. Missed Calls	
	2. Incoming Calls	
	3. Outgoing Calls	
	4. Delete All ⇨	1. Missed Calls
		2. Incoming Calls
		3. Outgoing Calls
		4. All Calls
	5. Call Time ⇨	1. Last Call Time
		2. Total Outgoing
		3. Total Incoming
		4. Reset Timers
3. Sound Settings ⇨	1. Ring Tone	
	2. Ring Volume	
	3. Alert Type	
	4. Keypad Tone	
	5. Message Tone ⇨	1. SMS Tone
		2. SMS-CB Tone
	6. Folder Tone	
	7. Power On / Off	
	8. Extra Tones	
4. Phone Settings ⇨	1. My Settings ⇨	1. Wallpaper
		2. Menu Style
	2. Greeting Message	
	3. Own Number	
	4. Language	
	5. Security ⇨	1. PIN Check
		2. Change PIN
		3. Phone Lock
		4. Change Password
		5. SIM Lock
		6. FDN Mode *
		7. Change PIN2*
	6. Display Settings ⇨	1. Contrast
		2. Back Light
		3. Auto Light
		4. Service Light
		5. Graphic Logo
	7. Extra Settings	
	8. Short Cut ⇨	1. Key Up
		2. Key Down
		3. Key Right
		4. Key Left
	9. Reset Settings	

Main Menu	Menu Level 1	Menu Level 2
5. Organizer ⇨	1. Calendar	
	2. To Do List	
	3. Time & Date ⇨	1. Set Time
		2. Set Date
		3. World Time
		4. Time Format
	4. Alarm ⇨	1. Once Alarm
		2. Daily Alarm
		3. Morning Call
		4. Remove Alarm
		5. Autopower
	5. Calculator	
	6. Currency Exchange	
6. Network Services ⇨	1. Call Forwarding ⇨	1. Forward Always
		2. Busy
		3. No Reply
		4. Unreachable
		5. Cancel All
	2. Call Barring* ⇨	1. All Outgoing
		2. International
		3. International Except to Home
		4. All Incoming
		5. Incoming While Abroad
		6. Cancel All
		7. Change Barring Password
	3. Call Waiting	
	4. Network Selection	
	5. Caller ID	
	6. Closed User Group ⇨	1. Index List
		2. Outside Access
		3. Default Group
		4. Deactivate*
7. Funbox ⇨	1. WAP Browser	1. GoRogers
		2. Settings
		3. Clear Cache
		4. Push Message
	2. Downloads ⇨	1. Games & More
		2. Sounds
		3. Pictures

* Option available if supported by SIM card.

Phone Specifications

Dual-Band
• GSM 850 MHz
• GSM 1900 MHz

Dimensions
• 3.3 x 1.8 x 0.8 (in inches w/ standard battery)

Weight
• 2.8 ounces (w/ standard battery)

Display
• 128 x 160 Pixel, UFB, 65K Color Display
• Battery Charge Status, Signal Strength,
  Vibration Alert, No Service / In Use, Text
  Message, Voice Mail, and Alarm Indicators

Battery
• 3.7 Volt Lithium Ion
• 800 mAh
• Up to 5 hours Talk Time
• Up to 200 hours Standby Time

Memory
• Internal Phone Book
    - Non-Volatile
    - Holds 500 Alphanumeric Entries Plus
      SIM Card Memory
      (Up To 250 Additional Names/Numbers)
    - Supports up to 40 Digits, 16 Characters
    - 8 One-Touch Dialing Numbers
• Call Logs
    - Last 20 Incoming
    - Last 20 Outgoing
    - Last 20 Missed

Phone Specifications (Continued)

Advanced Features
• GPRS – Class 8 PBCCH
• Mobile Internet
• Java™ Support for application download
• 2-Way Short Message Service*
• Enhanced Message Service*
• Personal Organizer
  (Calendar, Calculator, To-Do List, Currency converter)
• T-9 Easy Text Input
• Tone & Image Download
• 3-Color LED
• Games

Optional Accessories
• Standard Lithium Ion Battery
• Travel Charger
• Battery Charger
• Car Power Charger
• Simple Hands-Free Car Kit
• Hands-Free Headset
• Data Kit
• Leather Case
• Holster

Standard Package Contains:

• Dual-Band x426 Handset
• Standard Li-Ion Battery
• Travel Charger
• Hand Strap
• User Guide

www.samsung.ca

ATHENS 2004

WORLDWIDE PARTNER

SAMSUNG TELECOMMUNICATIONS AMERICA
1301 East Lookout Drive
Richardson, TX 75082
1-888-987-HELP

9/03 50 000
19210   53