Feature operation

Hold

Place a call on hold			
Return to a held call			

Transfer

	Trans		▶Trans

Conference

	Conf		▶Conf

Ring Again

Activate	RngAgn	
When notified		▶RngAgn
Deactivate	▶RngAgn	

Call Forward

Activate	Fwd		▶Fwd
Deactivate	▶Fwd		
Reinstate	Fwd	▶Fwd	
View number	Disply	▶Fwd	

Call Pickup

		Pickup

Message

Legend

Icon	Action
	Press the Hold key.
	Dial a number.
	Press the Line key.
	Press the Services key.
	Press the Message (Inbox) key.
	Press the Navigation keys.
>>	Press the Shift soft key to access the second layer of soft keys.
▶Fwd	The ▶ flashes when a feature is being programmed. The ▶ is steady when a feature is active.
▼	The ▼ indicates there is additional text or prompts on the display. Press the navigation keys to scroll the display.

Services and Telephone Options menu

Services Menu

		Select	

Telephone Options

Volume adjustment

Ringer	Select		Select	
Speaker	Select		Select	
Buzzer	Select		Select	

Contrast adjustment

	Select	

Language

	Select	Select	

Date/Time

	Select	

Local DialPad Tone

	Select	

Ring type

	Play	Select	

Live Dial Pad

	Turn On or Off	Select Cancel	

For additional information about your IP Phone 2033, see the *IP Audio Conference Phone 2033 User Guide* (NN43111-100).

Nortel IP Audio Conference Phone 2033

- Status indicator LEDs
- Microphone (hidden)
- Speaker
- LCD display screen
- Navigation keys
- Services key
- Message (Inbox) key
- Hold key
- Microphone
- Soft keys (self-labeled)
- Line key
- Goodbye key
- Dialpad
- Mute key
- Volume control keys
- Microphone

Nortel IP Audio Conference Phone 2033

For Nortel Communication Server 1000

Quick Reference Card

To provide feedback or report a problem in this document, go to www.nortel.com/documentfeedback.