JENSEN®

HEAVY DUTY

JHD1510 Quick Reference Guide

Basic Operation

AUDIO MENU: With each press of the button choose from the following AUDIO ADJUSTMENT options: BASS, TREBLE, BALANCE (left to right), and FADER (front to back). Use the rotary encoder knob to adjust desired mode. Press and hold to access the SYSTEM MENU.

MUTE: Press to MUTE audio.

MODE: With each press of the button the radio will change through the following modes: AM/FM, *SAT, *iPOD, and AUX.

Volume & Power On/Off: Push to turn power ON or OFF. Turn to INCREASE or DECREASE volume.

EQ/LOUD: Press to choose one of the predefined bass and treble curves. Press and hold to turn loudness ON/OFF.

AUXILIARY INPUT: Insert stereo connector from any portable audio player.

AM/FM/RBDS/WB Controls

PTY: Press to get program list type. Use rotary encoder knob to select. Press and hold SEEK < or > to tune to selected program type station.

MUTE: Press to MUTE audio.

BAND: Press to select preset group FM1, FM2, FM3, AM1, or AM2 each with 6 channel memory locations.

WB: Press and hold to listen to WEATHERBAND.

TUNE: Press > to tune UP in frequency. Press < to tune DOWN in frequency. Press and hold to fast search.

AS/PS: Press to SCAN through currently stored presets. Press & hold to STORE strongest broadcast stations in your area.

STATION STORE BUTTONS:
Press & hold to store current channel playing.
Momentarily press to recall stored channel.
NOTE: you can store up to 18 channels
(6 channels per band FM1, FM2, FM3, AM1, AM2).

SIRIUS® Radio Controls*

PTY: Press and hold to change channel lock code.

MUTE: Press to MUTE audio.

MODE: Press and hold to enter CHANNEL LOCK function.

TUNE/SEEK: Press >> to tune UP in frequency. Press << to tune DOWN in frequency. Press and hold to fast search.

S-MOD/ENTER: Press to access CATEGORY MODE and confirm selection. Press TUNE/SEEK to change category. Press again to select. Press and hold to return to channel tuning mode.

AS/PS: Press to scan through currently stored presets. Press and hold to access preset tuning mode.

BAND: Press to select preset group SR1, SR2, or SR3 each with 6 channel memory locations.

STATION STORE BUTTONS:
Press & hold to store current channel playing.
Momentarily press to recall stored channel.
NOTE: you can store up to 18 channels
(6 channels per band SIR1, SIR2, SIR3).

DISP/SCROLL: Press to change display info between single and dual line text display.

*Some features may not be available depending on installed factory options.

JENSEN®

HEAVY DUTY

iPod® Controls*

MUTE: Press to MUTE audio.

TUNE/TRK: Press to tune to next track. Press and hold to FAST FORWARD or RE-WIND current track playing.

S-MOD/ENTER: Press to access PLAYLIST selection mode. Use DN/UP to navigate list.

DISP/SCROLL: Press to change display info between single and dual line text display.

PLAY/PAUSE: Press to PLAY or PAUSE current audio.

RPT: Press to REPEAT current playing song. Press to release function.

RDM: Press to play each song in RANDOM order. Press again for NORMAL play.

DN: Scroll DOWN playlists in playlist selection mode. Press PLAY to select.

UP: Scroll UP playlists in playlist selection mode. Press PLAY to select.

Clock Settings

NOTE: To SET CLOCK, turn vehicle ON and radio OFF.

Press << to adjust the HOURS.
Press >> to adjust the MINUTES.

DISP: Press & hold to enter CLOCK SETTING MODE. Set HOURS using TUNE/SEEK. Press again to set the MINUTES. Press again to set clock.

Activating your SIRIUS® Subscription —

Before you can listen to SIRIUS Satellite Radio, you must subscribe to the service.

1. With the radio power ON, press the MODE button to enter SIRIUS Ready mode.
   After displaying the SIRIUS logo, the Receiver will update all the SIRIUS channels.

NOTE: Don't push any buttons or perform any operations until updating has been completed.

2. Once updated and the SIRIUS channels are received, the display will change to "Call 1-888-539-SIRIUS to Subscribe" and will place you in SIRIUS Satellite Radio's Preview Channel. Channel 184 is the SIRIUS preview channel.
   You will not be able to tune to any other SIRIUS Radio channels until you activate your subscription.

3. You will need to access your SIRIUS ID, which is displayed on channel 000. Use the TUNE/SEEK button to tune to channel 000. This will display your unit's unique 12-digit SIRIUS ID Number.

4. Write the SIRIUS ID number down and have your credit card handy.

5. Contact SIRIUS on the Internet: https://activate.siriusradio.com/
   Follow the prompts to activate your subscription. You can also call SIRIUS toll-free at: 1-888-539-SIRIUS (1-888-539-7474).