


SAMSUNG

# MICROWAVE OVEN


## Owner's Instructions

**M187DN**




Oven .....	2
Accessories .....	2
Control Panel.....	2
Using this Instruction Booklet .....	3
Safety Precautions.....	3
Installing Your Microwave Oven .....	4
Setting the Time.....	5
What to Do if You are in Doubt or Have a Problem.....	5
Cooking / Reheating .....	6
Power Levels .....	6
Stopping the Cooking .....	7
Adjusting the Cooking Time.....	7
Setting a Standing Time .....	7
Using the Auto Reheat Feature .....	8
Auto Reheat Settings.....	8
Using the Cafeteria Feature .....	8
Cafeteria Settings .....	9
Using the Auto Power Defrost Feature.....	9
Auto Power Defrost Settings .....	10
Using the Power Steam Function .....	10
Using the Deodorization Feature .....	11
Switching the Beeper Off.....	12
Safety-Locking Your Microwave Oven .....	12
Cookware Guide.....	13
Cleaning Your Microwave Oven .....	14
Storing and Repairing Your Microwave Oven .....	14
Technical Specifications .....	15

## Oven




## Control Panel




## Accessories


Depending on the model that you have purchased, you are supplied with several accessories that can be used in a variety of ways.



1. **Coupler**, already placed over the motor shaft in the base of the oven.  
Purpose : The coupler rotates the turntable.



2. **Roller ring**, to be placed in the centre of the oven.  
Purpose : The roller ring supports the turntable.



3. **Turntable**, to be placed on the roller ring with the centre fitting to the coupler.  
Purpose : The turntable serves as the main cooking surface; it can be easily removed for cleaning.



4. **Power steam cooker**, see page 10.  
Purpose : Use the plastic steam cooker when using power steam function.

**DO NOT** operate the microwave oven without the roller ring and turntable.

## Using this Instruction Booklet

You have just purchased a SAMSUNG microwave oven. Your Owner's Instructions contain much valuable information on cooking with your microwave oven:

- Safety precautions
- Suitable accessories and cookware
- Useful cooking tips

At the front of the booklet you will find illustrations of the oven, and more importantly the control panel, so that you can find the buttons more easily.

The step-by-step procedures use three different symbols.



Important

Note

Turn

### PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

Failure to observe the following safety precautions may result in harmful exposure to microwave energy.

- (a) Under no circumstances should any attempt be made to operate the oven with the door open or to tamper with the safety interlocks (door latches) or to insert anything into the safety interlock holes.
- (b) Do not place any object between the oven door and front face or allow food or cleaner residues to accumulate on sealing surfaces. Ensure that the door and door sealing surfaces are kept clean by wiping after use first with a damp cloth and then with a soft dry cloth.
- (c) Do not operate the oven if it is damaged until it has been repaired by a qualified microwave service technician trained by the manufacturer. It is particularly important that the oven door closes properly and that there is no damage to the:
  - (1) Door, door seals and sealing surfaces
  - (2) Door hinges (broken or loose)
  - (3) Power cable
- (d) The oven should not be adjusted or repaired by anyone other than a properly qualified microwave service technician trained by the manufacturer.

## Safety Precautions

GB

### Important Safety Instructions.

Read Carefully and keep for future reference.

Before cooking food or liquids in your microwave oven, please check that the following safety precautions are taken.

1. **DO NOT** use any metallic cookware in the microwave oven:
  - Metallic containers
  - Dinnerware with gold or silver trimmings
  - Skewers, forks, etc.
- Reason: Electric arcing or sparking may occur and may damage the oven.
2. **DO NOT** heat:
  - Airtight or vacuum-sealed bottles, jars, containers  
Ex) Baby food jars
  - Airtight food.  
Ex) Eggs, nuts in shells, tomatoes

Reason: The increase in pressure may cause them to explode.  
Tip: Remove lids and pierce skins, bags, etc.
3. **DO NOT** operate the microwave oven when it is empty.  
Reason: The oven walls may be damaged.  
Tip: Leave a glass of water inside the oven at all times.  
The water will absorb the microwaves if you accidentally set the oven going when it is empty.
4. **DO NOT** cover the rear ventilation slots with cloths or paper.  
Reason: The cloths or paper may catch fire as hot air is evacuated from the oven.
5. **ALWAYS** use oven gloves when removing a dish from the oven.  
Reason: Some dishes absorb microwaves and heat is always transferred from the food to the dish. The dishes are therefore hot.
6. **DO NOT** touch heating elements or interior oven walls.  
Reason: These walls may be hot enough to burn even after cooking has finished, even though they do not appear to be so. Do not allow inflammable materials to come into contact with any interior area of the oven. Let the oven cool down first.
7. To reduce the risk of fire in the oven cavity:
  - Do not store flammable materials in the oven
  - Remove wire twist ties from paper or plastic bags
  - Do not use your microwave oven to dry newspapers
  - If smoke is observed, keep the oven door closed and switch off or disconnect the oven from the power supply
8. Take particular care when heating liquids and baby foods.
  - **ALWAYS** allow a standing time of at least 20 seconds after the oven has been switched off so that the temperature can equalize.
  - Stir during heating, if necessary, and **ALWAYS** stir after heating.
  - Take care when handling the container after heating. You may burn yourself, if the container is too hot.

## Safety Precautions (continued)

- A risk of delayed eruptive boiling exists.
  - To prevent delayed boiling and possible scalding, you should put a plastic spoon or glass stick into the beverages and stir before, during and after heating.
- Reason: During the heating of liquids the boiling point can be delayed; this means that eruptive boiling can start after the container is removed from the oven. You may scald yourself.
- In the event of scalding, follow these FIRST AID instructions:
    - \* Immerse the scalded area in cold water for at least 10 minutes.
    - \* Cover with a clean, dry dressing.
    - \* Do not apply any creams, oils or lotions.
  - **NEVER** fill the container to the top and choose a container that is wider at the top than at the bottom to prevent the liquid from boiling over. Bottles with narrow necks may also explode if overheated.
  - **ALWAYS** check the temperature of baby food or milk before giving it to the baby.
  - **NEVER** heat a baby's bottle with the teat on, as the bottle may explode if overheated.
  - 9. Be careful not to damage the power cable.
    - Do not immerse the power cable or plug in water and keep the power cable away from heated surfaces.
    - Do not operate this appliance if it has a damaged power cable or plug.
  - 10. Stand at arm's length from the oven when opening the door.  
Reason: The hot air or steam released may cause scalding.
  - 11. Keep the inside of the oven clean.  
Reason: Food particles or spattered oils stuck to oven walls or floor can cause paint damage and reduce the efficiency of the oven.
  - 12. You may notice a "Clicking" sound during operation (especially when the oven is defrosting).  
Reason: This sound is normal when the electrical power output is changing.
  - 13. When the microwave oven is operating without any load, the power will be cut off automatically for safety. You can operate normally after letting it stand for over 30 minutes.

### IMPORTANT SAFETY INSTRUCTIONS



During cooking, you should look into the oven from time to time when food is being heated or cooked in disposable containers of plastic, paper or other combustible materials.

### IMPORTANT

Young children should **NEVER** be allowed to use or play with the microwave oven. Nor should they be left unattended near the microwave oven when it is in use. Items of interest to children should not be stored or hidden just above the oven.

## Installing Your Microwave Oven

*Place the oven on a flat, level surface that is strong enough to safely bear the weight of the oven.*



1. When you install your oven, Make sure there is adequate ventilation for your oven by leaving at least 10 cm (4 inches) of space behind, and on the sides of the oven, at least 20 cm (8 inches) of space above the oven.
2. Remove all packing materials inside the oven. Install the roller ring and turntable. Check that the turntable rotates freely.
3. This microwave oven has to be positioned so that plug is accessible.

☞ **Never** block the air vents as the oven may overheat and automatically switch itself off. It will remain inoperable until it has cooled sufficiently.

☞ For your personal safety, plug the cable into a 3-pin, 230 Volt, 50Hz, AC earthed socket. If the power cable of this appliance is damaged, it must be replaced by a special cable (I-SHENG SP022, KDK KKP4819D, EUROELECTRIC 3410, SAMIL SP-106B, MOONSUNG EP-48E, HIGH PROJECT H.P 3). Contact your local dealer to have it replaced. The power cable of ISRAEL is PENCON(ZD16A), S/AFRICA APEX LEADS SA16 and NIGERIA, GHANA, KENYA and U.A.E is PENCON(UD13A1).


☞ **Do not** install the microwave oven in hot or damp surroundings like next to a traditional oven or radiator. The power supply specifications of the oven must be respected and any extension cable used must be of the same standard as the power cable supplied with the oven. Wipe the interior and the door seal with a damp cloth before using your microwave oven for the first time.

## Setting the Time

Your microwave oven has an inbuilt clock. The time can be displayed in either the 24-hour or 12-hour notation. You must set the clock:

- When you first install your microwave oven
- After a power failure

 Do not forget to reset the clock when you switch to and from summer or winter time.




1. To display the time in the... Then press the  button...


24-hour notation	Once
12-hour notation	Twice




2. Turn the **dial knob** to set the hour.



3. Press the  button.



4. Turn the **dial knob** to set the minute.



5. Press the  button.

## What to Do if You are in Doubt or Have a Problem

GB

If you have any of the problems listed below try the solutions given.


- ◆ This is normal.
  - Condensation inside the oven.
  - Air flow around the door and outer casing.
  - Light reflection around the door and outer casing.
  - Steam escaping from around the door or vents.
- ◆ The oven does not start when you press the  button.
  - Is the door completely closed?
- ◆ The food is not cooked at all
  - Have you set the timer correctly and/or pressed the  button?
  - Is the door closed?
  - Have you overloaded the electric circuit and caused a fuse to blow or a breaker to be triggered?
- ◆ The food is either overcooked or undercooked
  - Was the appropriate cooking length set for the type of food?
  - Was an appropriate power level chosen?
- ◆ Sparking and cracking occur inside the oven (arcing)
  - Have you used a dish with metal trimmings?
  - Have you left a fork or other metal utensil inside the oven?
  - Is aluminium foil too close to the inside walls?
- ◆ The oven causes interference with radios or televisions
  - Slight interference may be observed on televisions or radios when the oven is operating. This is normal. To solve this problem, install the oven away from televisions, radios and aerials.
  - If interference is detected by the oven's microprocessor, the display may be reset. To solve this problem, disconnect the power plug and reconnect it. Reset the time.
-  If the above guidelines do not enable you to solve the problem, contact your local dealer or SAMSUNG after-sales service.

## Cooking / Reheating

**The following procedure explains how to cook or reheat food.**


**ALWAYS check your cooking settings before leaving the oven unattended.**

**First, place the food in the centre of the turntable. Then, close the door.**



1. Press the button.

Result : The 850W (maximum cooking power) indications are displayed:  
Select the appropriate power level by pressing the button again until the corresponding wattage is displayed. Refer to the power level table.



2. Set the cooking time by turning the **dial knob** as required.



3. Press the button.

Result : The oven light comes on and the turntable starts rotating.  
Cooking starts and when it has finished the oven beeps four times.

- ☛ **Never** switch the microwave oven on when it is empty.
- ☒ If you wish to heat a dish for a short period of time at maximum power(850W), simply press the **+30s** button once for each 30 seconds of cooking time. The oven starts immediately.

## Power Levels

**You can choose from among the power levels below.**

Power Level	Output
HIGH	850 W
MEDIUM HIGH	600 W
MEDIUM	450 W
MEDIUM LOW	300 W
DEFROST	180 W
LOW / KEEP WARM	100 W

- If you select the higher power level, the cooking time must be decreased.
- ☒  If you select the lower power level, the cooking time must be increased.

**If you want to add the cooking time by turning dial knob.**


Time	Increasing Time
Up to 1 min	5 sec. unit
1 - 3 min	10 sec. unit
3 - 10 min	30 sec. unit
10 - 20 min	1 min unit
20 - 40 min	2 min unit
40 - 99 min	5 min unit

●


●

## Stopping the Cooking

You can stop cooking at any time to check the food.



1. To stop temporarily:  
Open the door.  
**Result :** Cooking stops. To resume cooking, close the door and press again.



2. To stop Completely:  
Press the button.  
**Result :** The cooking stops.  
If you wish to cancel the cooking setting, press the Cancel( ) button again.

You can cancel any setting before you start cooking by simply pressing **Cancel( )**.


## Adjusting the Cooking Time

You can increase the cooking time by pressing the **+30s** button once for each 30 seconds to be added.



Press the **+30s** button once for each 30 seconds to be added.

You can only adjust the time during cooking when the Microwave, Auto Reheat/Cook, Cafeteria or Power Steam modes are selected.




During the cooking, to increase or decrease the cooking time of your food, turn the **dial knob** right or left.


## Setting a Standing Time

The Hold Time can be used to set a standing time automatically (without microwave cooking).

GB



1. Press the button.



2. Select the standing time by turning the **dial knob**.




3. Press the button.

**Result :** Standing time starts. When it has finished:

- 1) The oven beeps four times.
- 2) The end reminder signal will beep 3 times (once every minute)
- 3) The current time is displayed again.

## Using the Auto Reheat Feature

The Auto Reheat feature has two pre-programmed cooking times. You do not need to set either the cooking times or the power level. You can adjust the number of servings by turning the dial knob. First, place the food in the centre of the turntable and close the door.



1. Select the type of food that you are cooking by pressing the **Auto Reheat** (  ) button once or more times.
2. Select the size of the serving by turning the **dial knob**. (Refer to the table on the bottom.)
3. Press the  button.  
**Result :** Cooking starts. When it has finished:  
1) The oven beeps four times.  
2) The end reminder signal will beep 3 times (once every minutes)  
3) The current time is displayed again.

- Use only recipients that are microwave-safe.

## Auto Reheat Settings

The following table presents the various Auto Reheat Programmes, quantities, standing times and appropriate recommendations.


Code/ Food	Serving Size	Standing Time	Recommendations
<b>1</b> 	300-350 g	3 min.	Put on a ceramic plate and cover with microwave cling film. This programme is suitable for meals consisting of 3 components (e.g. meat with sauce, vegetables and a side dishes like potatoes, rice or pasta).
<b>2</b> 	300 - 350 g	4 min.	Take frozen ready meal and check if dish is suitable for microwave. Pierce film of ready meal. Put the frozen ready meal in the centre. This programme is suitable for frozen ready meals consisting of 3 components (e.g. meat with sauce, vegetables and a side dish like potatoes, rice or pasta).

## Using the Cafeteria Feature

With the Cafeteria feature, the cooking time is set automatically.

You can adjust the number of servings by turning the dial knob.

First, place the food in the centre of the turntable and close the door.



1. Select the type of food that you are cooking by pressing the **Cafeteria** button once or more times.
2. Select the size of the serving by turning the **dial knob**.
3. Press the  button.  
**Result :** Cooking starts. When it has finished:  
1) The oven beeps four times.  
2) The end reminder signal will beep 3 times (once every minute)  
3) The current time is displayed again.

**Example:** Press the **Cafeteria** button one times to reheat one cups of coffee and select the serving size by turning the **dial knob**. Refer to the table on the next page.

- Use only recipients that are microwave-safe.

## Cafeteria Settings

The following table presents Auto Programmes for reheating drinks and defrosting frozen cake pieces.

It contains its quantities, standing times and appropriate recommendations.

Button	Food	Serving Size	Standing Time	Recommendations
1	 <b>Drinks</b>	150 ml Coffee, milk, (1 cup) tea, water (room- temperature)	1-2 min. 250 ml (1 mug)	Pour into a ceramic cup (150 ml) or mug (250 ml) and place in the centre of turntable. Reheat uncovered. Stir carefully before and after standing time. Be careful while taking the cups out (see safety instructions for liquids).
2  ***	<b>Frozen Cake Pieces</b>	100 g (1pc) 200 g (2pcs) 300 g (2-3pcs) 400 g (3-4pcs) 500 g (4pcs)	5-15 min.	Put flat frozen cake pieces (-18°C) directly on metal rack. Put bigger pieces and muffins on turntable. Put one piece in the centre, put 2 pieces opposite to each other and 3-4 cake pieces in a circle. By the help of the heater the cake will be warmed and crisp up.  This programme is suitable for cake pieces such as apple cake with crumble topping, streusel cake, cake with poppy seeds and muffins. It is not suitable for a whole cake, cake with cream filling and cake with chocolate topping.


## Using the Auto Power Defrost Feature

The Auto Power Defrost feature enables you to defrost meat, poultry or fish. The defrost time and power level are set automatically.

GB


- Use only dishes that are microwave-safe.

First, place the frozen food in the centre of the turntable and close the door.



1. Press the **Auto Power Defrost**(\*\*) button.

Result : The following indication is displayed:



2. Select the food weight by turning the **dial knob**.  
It is possible to set up to a maximum of 1500g.



3. Press **◊** button.

Result :

- ◆ Defrosting begins.
- ◆ The oven beeps halfway through defrosting to remind you to turn the food over.
- ◆ Press **◊** button again to finish defrosting

- You can also defrost food manually. To do so, select the microwave cooking/reheating function with a power level of 180W. Refer to the section entitled "Cooking/Reheating" on page 6 for further details.

## Auto Power Defrost Settings

The following table presents the Power Defrost programme, quantities, standing times and appropriate recommendations.

Remove all kind of package material before defrosting. Place meat, poultry and fish on a flat ceramic plate.

Food	Portion	Standing Time	Recommendation
Meat, Poultry or Fish	200-1500g	15-60min.	Shield the edges with aluminium foil. Turn the pieces over, when the oven beeps. This programme is suitable for meat such as steaks, chops or minced meat, chicken pieces, whole chicken or fish fillets.

## Using the Power Steam Function


With the power steam feature, the cooking time is set automatically.

You can adjust the number of servings by turning the dial knob.

Use the plastic steam cooker when using power steam function.

First, place the plastic steam cooker in the centre of the turntable and close the door.

- 1. Select the type of food that you are cooking by pressing the **Power Steam** button once or more times.



- 2. Select the size of the serving by turning the **dial knob**. (Refer to the table on the next page.)



- 3. Press the button.  
Result : Cooking starts. When it has finished:  
1) The oven beeps four times.  
2) The end reminder signal will beep 3 times (once every minute)  
3) The current time is displayed again.



- Use only recipients that are microwave-safe.

## Using the Power Steam Function (continued)

The following table presents the 4 Auto Programs of the Power Steam function, quantities, standing times and appropriate recommendations. Use the plastic steam cooker when using power steam function.


Code / Food	Serving Size	Standing Time	Recommendations
1  White Rice	250 g	4-5 min.	Put white rice (parboiled) into the steam cooker. Add 500 ml cold water when cooking 250 g rice and add 750 ml water for 375 g rice. Close lid of steam cooker. After cooking remove moisture in the cavity by using kitchen paper.
	375 g		
2  Peeled Potatoes	100-150 g	2-3 min.	Weigh the potatoes after peeling, washing and cutting into similar size. Put them into the steam cooker.
	200-250 g		
	300-350 g		
	400-450 g		Add 15-30 ml (1-2 tablespoons) water when steaming 100-350 g, add 45-60 ml (3-4 tablespoons) for 400-550 g. Close lid of steam cooker.
	500-550 g		
3  Fresh Vegetables	100-150 g	1-2 min.	Weigh the vegetables after washing, cleaning and cutting into similar size. Put them into the steam cooker.
	200-250 g		
	300-350 g		
	400-450 g		Add 30 ml (2 tablespoons) water, when steaming 100-350 g, add 45 ml (3 tablespoons) for 400-450 g. Close lid of steam cooker. After steaming stir carefully before standing time.
4  Fruit Compote	100-150 g	2-3 min.	Weigh the fresh fruits after peeling and washing and cut into similar slices or cubes. Put into steam cooker. When steaming 100-350g fruits add 15-30 ml (1-2 tbsp.) water, for 400-450 add 45ml (3 tbsp.). Additionally add 1-2 tbsp. sugar. Close lid of steam cooker.
	200-250 g		
	300-350 g		
	400-450 g		
			After steaming stir carefully. This programme is suitable for apples, pears, plums, apricots, mangoes or pineapple.

## Using the Deodorization Feature

GB

Use this feature after cooking odorous food or when there is a lot of smoke in the oven interior.

First clean the oven interior.




Press the **Deodorization**() button after you have finished cleaning. you will hear four beeps.

- The deodorization time has been specified as 5 minutes. It increases by 30 seconds whenever the **+30s** button is pressed.
- You can also adjust deodorization time by turning the dial knob right or left.
- The maximum deodorization time is 15 minutes.



## Switching the Beeper Off


You can switch the beeper off whenever you want.



1. Press the and buttons at the same time.

Result :

- ◆ The following indication is displayed.
- ◆ The oven will not beep each time you press a button.



2. To switch the beeper back on, press the and buttons again at the same time.


Result :

- ◆ The following indication is displayed.
- ◆ The oven operates with the beeper on again.

## Safety-Locking Your Microwave Oven

Your microwave oven is fitted with a special Child Safety programme, which enables the oven to be “locked” so that children or anyone unfamiliar with it cannot operate it accidentally.


The oven can be locked at any time.



1. Press the and buttons at the same time.

Result :

- ◆ The oven is locked (no functions can be selected).
- ◆ The display shows “L”.



2. To unlock the oven, press the and buttons again at the same time.

Result : The oven can be used normally.

# Cookware Guide

GB

**To cook food in the microwave oven, the microwaves must be able to penetrate the food, without being reflected or absorbed by the dish used.**

**Care must therefore be taken when choosing the cookware. If the cookware is marked microwave-safe, you do not need to worry.**

**The following table lists various types of cookware and indicates whether and how they should be used in a microwave oven.**

Cookware	Microwave-Safe	Comments
Aluminium foil	✓ X	Can be used in small quantities to protect areas against overcooking. Arcing can occur if the foil is too close to the oven wall or if too much foil is used.
Browning plate	✓	Do not preheat for more than eight minutes.
China and earthenware	✓	Porcelain, pottery, glazed earthenware and bone china are usually suitable, unless decorated with a metal trim.
Disposable polyester cardboard dishes	✓	Some frozen foods are packaged in these dishes.
Fast-food packaging		
• Polystyrene cups containers	✓	Can be used to warm food. Overheating may cause the polystyrene to melt.
• Paper bags or newspaper	X	May catch fire.
• Recycled paper or metal trims	X	May cause arcing.
Glassware		
• Oven-to-table ware	✓	Can be used, unless decorated with a metal trim.
• Fine glassware	✓	Can be used to warm foods or liquids. Delicate glass may break or crack if heated suddenly.
• Glass jars	✓	Must remove the lid. Suitable for warming only.

Metal			
• Dishes	X	May cause arcing or fire.	
Paper			
• Plates, cups, napkins and Kitchen paper	✓	For short cooking times and warming. Also to absorb excess moisture.	
• Recycled paper	X	May cause arcing.	
Plastic			
• Containers	✓	Particularly if heat-resistant thermoplastic. Some other plastics may warp or discolour at high temperatures. Do not use Melamine plastic.	
• Cling film	✓	Can be used to retain moisture. Should not touch the food. Take care when removing the film as hot steam will escape.	
• Freezer bags	✓ X	Only if boilable or oven-proof. Should not be airtight. Prick with a fork, if necessary.	
Wax or grease-proof paper			
	✓	Can be used to retain moisture and prevent spattering.	

✓ :Recommended

✓ X :Use Caution

X :Unsafe

## Cleaning Your Microwave Oven

**The following parts of your microwave oven should be cleaned regularly to prevent grease and food particles from building up:**

- Inside and outside surfaces
- Door and door seals
- Turntable and Roller rings

 **ALWAYS** ensure that the door seals are clean and the door closes properly.

1. Clean the outside surfaces with a soft cloth and warm, soapy water. Rinse and dry.
2. Remove any splashes or stains on the inside surfaces or on the roller ring with a soapy cloth. Rinse and dry.
3. To loosen hardened food particles and remove smells, place a cup of diluted lemon juice on the turntable and heat for ten minutes at maximum power.
4. Wash the dishwasher-safe plate whenever necessary.

 **DO NOT** spill water in the vents. NEVER use any abrasive products or chemical solvents. Take particular care when cleaning the door seals to ensure that no particles:
 

- Accumulate
- Prevent the door from closing correctly

## Storing and Repairing Your Microwave Oven

**A few simple precautions should be taken when storing or having your microwave oven serviced.**

**The oven must not be used if the door or door seals are damaged:**

- Broken hinge
- Deteriorated seals
- Distorted or bent oven casing

**Only a qualified microwave service technician should perform repair**

-  **NEVER** remove the outer casing from the oven. If the oven is faulty and needs servicing or you are in doubt about its condition:
  - Unplug it from the wall socket
  - Contact the nearest after-sales service centre
-  If you wish to store your oven away temporarily, choose a dry, dust-free place.  
**Reason:** Dust and damp may adversely affect the working parts in the oven.
-  This microwave oven is not intended for commercial use.
- 
-

## Technical Specifications

**SAMSUNG** strives to improve its products at all times. Both the design specifications and these user instructions are thus subject to change without notice.

<b>Model</b>	M187DN
<b>Power source</b>	230V ~ 50 Hz
<b>Power consumption</b> Microwave	1250 W
<b>Output power</b>	100 W / 850 W (IEC-705)
<b>Operating frequency</b>	2450 MHz
<b>Magnetron</b>	OM75P(31)
<b>Cooling method</b>	Cooling fan motor
<b>Dimensions (W x H x D)</b> Outside	489 x 275 x 393 mm
Oven cavity	330 x 211 x 329 mm
<b>Volume</b>	23 liter
<b>Weight</b> Net	13.5 kg approx

## Note

•

•

•

---

## *Note*

---

GB











## ملاحظة

## المواصفات الفنية

شركة سامسونج تسعى الى تحسين المنتجات في جميع الأوقات. التصاميم والمواصفات وتعليمات المالك هذه عرضة للتغيير بدون إشعار.

الموديل	M187DN
مصدر الطاقة	٢٣. فولت ~ ٥٠ هرتز
استهلاك الطاقة الميكروويف	١٢٥. واط
طاقة المزوج	(IEC-705) ١٠٠ واط / ٨٥. واط
التردد للتشغيل	٢٤٥. ميغاهرتز
المغناطرون	(٢١) OM75P
طريقة التبريد	موتور مروحة التبريد
الخارجية (عرض × ارتفاع × عمق)	٤٨٩ × ٢٧٥ × ٣٩٣ ملم
تجويف الفرن	٣٣٠ × ٢١١ × ٣٢٩ ملم
السعة	٢٣ لتر
الوزن الصافي	١٣.٥ كجم تقريبا

## تنظيف فرن المايكروويف

AR

لا بد من تنظيف الأجزاء التالية من فرن المايكروويف لمنع الشحوم وجسيمات الطعام من بقائها:

- الأسطح الداخلية والخارجية لفرن المايكروويف
- الباب وأختام الباب
- الصينية الدوارة وحلقة بالعجلات

تأكد دائماً من أن اختام الباب نظيفة والباب مغلق بإحكام.

١. نظف الأسطح الخارجية بقطعة من القماش الناعم مع الماء الصابوني الدافئ، اشطفها و Giovها.

٢. امسح أي بقعة أو وسخ على الأسطح الداخلية أو حلقة الملف بقطعة من القماش مع الصابون، واشطفها و Giovها.

٣. لإزالة جسيمات الطعام المتصلبة وإزالة الروائح الكريهة، ضع كوباً من عصير الليمون الرقيق على الصحن الزجاجي وسخنه لمدة عشر دقائق على أقصى طاقة.

٤. اغسل الأوانى الأمانة المناسبة لطاقة المايكروويف كلما كنت في الحاجة اليه.

• لا تنصب الماء في فتحات الفرن. لا تستخدم أي مادة كاشطة أو محلولات كيميائية أبداً. خذ عناية خاصة عند تنظيف أختام الباب لضمان عدم وجود جسيمات من الطعام:

- متراكمه
- تمنع الباب من إغلاقه كما ينبغي

## حفظ فرن المايكروويف وإصلاحه

لا بد من اعتبار بعض التحذيرات البسيطة عند حفظ فرن المايكروويف وطلب إصلاحه.

لا بد من استخدام الفرن في حالة حدوث ضرر في الباب أو أختام الباب:

- المفصلة المنكسرة
- الأختام المفسدة
- هيكل الفرن الملتوي أو المشوه

لا بد من إصلاح فرن المايكروويف من قبل فني مختص لخدمات فرن المايكروويف فقط.

• لا تسحب هيكل فرن المايكروويف الخارجي من الفرن أبداً. اذا حدث خلل في الفرن واحتاجت الى طلب الخدمات للفرن أو كان عندك شكوك في حالة الفرن:

- اخرج قابس التيار من مخرج التيار الجداري
- اتصل بأقرب مركز للخدمات بعد الشراء.

إذا إردت حفظ الفرن مؤقتاً، اختر مكاناً جافاً حالياً من الغبار.

- السبب: الغبار والرطوبة قد تؤدي الى إحداث مشكلة في الأجزاء العاملة في الفرن.

فرن المايكروويف هذا غير مصمم للأغراض التجارية.




الأنواعية المعدنية	الأوعية الزجاجية	الأوعية الميكرويف	الأوعية الميكرويف	الأوعية المنيومية
التعليمات	الأوعية المعدنية	الأوعية الميكرويف	الأوعية الميكرويف	نمير الطعام
يمكنك استخدامها باشتناء الأوعية المزخرفة بطارف معدنية.	✓ الأوعية للفرن والطاولة	✓ الأوعية للفرن والطاولة	لا بد من الاعتناء باختيار الأوانى للطبخ بالميكرويف. اذا كانت علامة الأمان لطاقة الميكرويف مطبوعة في الأوانى، لا تقلق.	من أجل طبخ الطعام في فرن الميكرويف، لا بد من نفوذ الميكرويف من الطعام، بدون انعكاس الميكرويف أو امتصاصه في الطبق المستخدم.
يمكنك استخدامها لتدفئة الأطعمة أو السوائل. قد ينكسر الزجاج الضعيف أو ينشق في حالة تسخينها مفاجأة.	✓ الأوعية الزجاجية الواضحة			
لا بد من إزالة الغطاء. هذه مناسبة للتدفئة فقط.	✓ الزجاجات			
قد تؤدي الى إحداث القوس الكهربائي او الاحتراق.	✗ الأطباق			
مناسبة للطبخ لمدة قصيرة وللتدفئة. مناسبة أيضاً لامتصاص الرطوبة كثيراً.	✗ الكيس المختوم بشكل ملتوي			
قد يؤدي الى إحداث القوس الكهربائي.	✓ الأوعية الورقية	✓ الأطباق ، الاكواب ، الفوطات ، ومناشف الطبع	يمكنك استخدامها في كمية قليلة من الطعام لغرض حماية أجزاء الطعام من تسخينها المفرط. قد يحدث إحداث القوس الكهربائي في حالة اقتراب الرقاقة من جدران الفرن جداً أو استخدام كمية كبيرة جداً منها.	
على الأخص البلاستيكي المضاد للحرارة مناسبة . بعض المواد البلاستيكية قد تلتوي أو تتغيرلونها على درجة الحرارة العالية. لا تستخدم المواد البلاستيكية القيتامينية.	✓ الأوعية البلاستيكية	✓ أفلام بلاستيكية	لا تسخن الفرن مسبقاً لمدة أكثر من 8 دقائق.	نمير الطعام
يمكنك استخدامها للاحتفاظ بالرطوبة. لا بد من عدم ملامسة الطعام. خذ عناية عند إزالة الفيلم عن الطعام لأن البخار الساخن يخرج.	✓ أكياس للفريزر		بعض الأطعمة المجمدة معيبة بهذه الأطباق.	الأطباق من الورقة المقواة البوليستيرورية المستخدمة مرة واحدة
استخدمها اذا كانت قابلة للتغليق أو مضادة للفرن. لا بد من عدم سدود الهواء. اثقب بشوكة عند الحاجة.	✗			
يمكنك استخدامها لاحتفاظ بالرطوبة ومنع نشر الطعام.	✓ الورق المضاد للشمع أو الشحم			
<b>✓ : موصى به</b>		<b>✗ : استخدم بعناية</b>		
<b>✗ : غير آمن</b>				
الجدول التالي يبيّن مختلف أنواع من الأوانى وتشير الى أن أي إناء يمكن استخدامه وكيف يستخدم في فرن الميكرويف.				

## إيقاف انطلاق الصفاراة


يمكنك إيقاف انطلاق الصفاراة كلما تريده.

- ا. اضغط على زر و زر في نفس الوقت.  
النتيجة: ◆ عندها تم إغلاق ضوابط الفرن (لا يمكنك اختيار أي وظيفة).  
◆ يعرض حرف "L" على شاشة العرض.



- بـ. لا تنطلق صفاراة من الفرن كلما ضغطت على زر.

- جـ. للرجوع إلى إنطلاق الصفاراة مرة أخرى، اضغط على زر و زر في نفس الوقت مرة أخرى.  
النتيجة: ◆ عندها يعرض المؤشر التالي على الشاشة.




- دـ. تنطلق صفاراة من الفرن مرة أخرى.


## الإغلاق الألماني لفرن الميكروويف

فرن الميكروويف يحتاج إلى برنامج أمان الأطفال الخاص، والذي يتم به «إغلاق» ضوابط الفرن بحيث لا يستطيع الأطفال أو أي شخص لا يطلع على الفرن تشغيل الفرن مفاجئاً.  
يمكنك إغلاق ضوابط الفرن في أي وقت.

- ا. اضغط على زر و زر في نفس الوقت.  
النتيجة: ◆ عندما تم إغلاق ضوابط الفرن (لا يمكنك اختيار أي وظيفة).  
◆ يعرض حرف "L" على شاشة العرض.



- بـ. لإلغاء إغلاق الفرن، اضغط على زر و زر في نفس الوقت مرة أخرى.  
النتيجة: يمكنك تشغيل الفرن كما ينبغي.




## استخدام وظيفة إزالة الرائحة الكريهة

AR

استخدم هذه الوظيفة بعد انتهاء طبخ الطعام ذي الرائحة أو في حالة وجود دخان كثير داخل الفرن.

### أولاً نظف الأسطح الداخلية للفرن.

اضغط على زر إزالة الرائحة الكريهة (  ) بعد انتهاء التنظيف. عندها تسميع صفارة أربع مرات.



وقت إزالة الرائحة الكريهة محدد مثل ٥ دقائق. ويزيد الوقت بواقع ٣٠s .



يمكنك ضبط وقت إزالة الرائحة الكريهة بتدوير الحلقة الى اليمين أو الى اليسار.



وقت إزالة الرائحة الكريهة على الاقصى يصل الى ١٥ دقيقة.



الجدول التالي يقتصر ببرامج أوتوماتيكية لوظيفة البخار القوي، الكميات ، وأوقات الانتظار والنصائح المناسبة. استخدم جهاز الطبخ البلاستيكي بالبخار عند استخدام وظيفة البخار القوي.

الرمز/ الطعام	حجم التقديم	وقت الانتظار	النطance
١  الأرز الأبيض	٤٠ جرام ٣٧٥ جرام	٤-٥ دقائق	ضع الأرز الأبيض (مسلوق) في جهاز الطبخ بالبخار. ٣٧٥ جرام اضاف ٥٠٠ ملilتر من الماء البارد لطبخ ٢٥٠ جرام من الأرز و ٧٥٠ ملilتر من الماء البارد لطبخ ٢٧٥ ملilتر من الأرز. اغلق غطاء جهاز الطبخ بالبخار. بعد الطبخ، ازل الرطوبة في تجويف الفرن باستخدام فوطة مطبخ.
٢  البطاطس المقشورة	٨٨٠ جرام ٦٠ جرام	٢-٣ دقائق	قس وزن البطاطس بعد القشر، اغسله واقطعه بحجم متشابه. ضعها في جهاز الطبخ بالبخار. اضاف ٣٠-٤٥ ملilتر (١-٢ ملعقة طعام) من الماء عند تبخير ٣٥-٤٥ جرام واضف ٦٠-٩٠ ملilتر (٣-٤ ملاعق طعام) لتبخير ٤٥-٥٥ جرام.
٣  الطازجة الفواكه	١٥٠-١٠٠ جرام ٢٥٠-٢٠٠ جرام ٣٥٠-٣٠٠ جرام ٤٥٠-٤٠٠ جرام	٢-٣ دقيقة	قس وزن الخضروات بعد الغسيل، والتنظيف والقطع بحجم متشابه. ضعها في جهاز الطبخ بالبخار. اضاف ٣٠ ملilتر (١ ملعقة طعام) من الماء عند تبخير ٣٥-٤٠ جرام. اضاف ٤٥ ملilتر (٣ ملاعق طعام) لتبخير ٤٥-٤٠ جرام. اغلق غطاء جهاز الطبخ بالبخار. بعد التبخير، حرك بعناية قبل وقت الانتظار.
٤  كومبوت فاكهه	١٥٠-١٠٠ جرام ٢٥٠-٢٠٠ جرام ٣٥٠-٣٠٠ جرام ٤٥٠-٤٠٠ جرام	٢-٣ دقائق	قس وزن الفواكه الطازجة بعد القشر والغسيل والقطع بشرائح أو مكعبات متشابهة. ضعها في جهاز الطبخ بالبخار. عند تبخير ٣٥-٤٠ جرام من الفواكه ، اضاف ٣٠-٤٥ ملilتر (١-٢ ملعقة طعام) من الماء. لتبخير ٤٥-٤٠ جرام، اضاف ٤٥ ملilتر (٣ ملاعق طعام) من الماء. اضاف ٢-١ ملعقة طعام من السكر إضافيا. وأغلق غطاء جهاز الطبخ بالبخار. بعد التبخير، حرك بعناية. هذا البرنامج مناسب للتفاح ، والكمثرى ، وشمر البرقوق ، والممشمش ، والمنجا ، أو الأنثاس.


## ضبط إزابة الشلح القوية الأوتوماتيكية

AR


الجدول التالي يقدم برنامج إزابة الشلح القوية ، والكميات ، وأوقات الانتظار ، والنصائح المناسبة.

ازل أشياء التغليف من أي نوع قبل إزابة الشلح. ضع اللحم، والدجاج والسمك على صحن خزفي مسطح.

١. اختر نوع الطعام الذي تريد طبخه بالضغط على زر البخار القوي مرة أو أكثر.



٢. اختر حجما للتقديم بتدوير الملقحة.  
(راجع الجدول الموجود في الصفحة التالية.)



٣. اضغط على زر ◆ النتائج: ◆  
١) تنطلق صفارة من الفرن أربع مرات.  
٢) وتنطلق صفارة ثلاث مرات لتذكير الانتهاء  
(مرة كل دقيقة)  
٣) يعرض الوقت الحالي من جديد.



استخدم الأواني الأمانية للماكرورويف فقط. 

النطائج	وقت الانتظار	الكمية	الطعام
احجب الأطراف برقاقة المنيومية. قلب القطع عند انطلاق صفارة.	٦٠ دقيقة	١٥٠..٢٠٠ جرام	اللحم، الدجاج أو السمك

هذا البرنامج مناسب للحم مثل شرائح اللحم ، واللحم المقطوع واللحم المفروم ، وقطع الدجاج ، والدجاج الكامل أو شرائح السمك.

●

●

●

## ضبط وظيفة القفطير

الجدول التالي يقائم البرامج الأوتوماتيكية لإعادة تسخين المشروبات وإذابة الثلج من قطع الكعك المجمدة. هذا يحتوي على كيماتها وأوقات انتظارها والنصائح المناسبة.

## استخدام وظيفة إذابة الثلج الأوتوماتيكية القوية


AR

وظيفة إذابة الثلج الأوتوماتيكية القوية تمكنك من إذابة الثلج من اللحم والدجاج والسمك. يتم ضبط وقت إذابة الثلج ومستوى الطاقة أتوماتيكيا.


استخدم الأطباق الأمامية للمايكروويف فقط

أولاً ، ضع الطعام المجمد في وسط الصينية الدوارة واغلق الباب.

- اضغط على زر إذابة الثلج القوية التقليدية (❖).  
النتيجة: عندما يعرض المؤشر التالي:



- اختر وزن الطعام بتحوير الحلقة.  
يمكنك ضبط الوزن حتى ١٥٠٠ جرام على الأقصى.



- اضغط على زر ❖.  
النتيجة: ◆ عندما يبدأ الفرن بإذابة الثلج  
◆ تنطلق الصفارة من الفرن أثناء إذابة الثلج  
للاشارة الى تقليل الطعام.  
◆ اضغط على زر ❖ مرة اخرى لانتهاء اذابة  
الثلج.




يمكنك إذابة الثلا يدويا أيضا. من أجل هذا، اختر وظيفة الطبخ بالمايكروويف/إعادة التسخين على مستوى الطاقة بـ ١٨٠ واط. راجع الجزء بعنوان "الطبع/إعادة التسخين" في الصفحة ٦ لمزيد من التفاصيل.

النوع	الطعام	الكمية للتقديم	وقت الانتظار	الصنانة
١ المشروبات	١٥. قهوة، حليب، شاي، ماء (درجة حرارة الغرفة)	١٥. مليتر (١ كوب)	٢-١ دقيقة	صبها في كوب خزفي (٥٠٠ مليتر) أو كوز (٢٥٠ مليتر) وضعها في وسط الصينية الدوارة. اعد تسخينها بدون غطاء. حرّكها بعناية قبل وبعد وقت الانتظار.خذ عناية اثناء إخراج الأكواب من الفرن (راجع التعليمات من أجل السلامة الخاصة بالسوائل).
٢ قطع كعك مجده	١٠٠ جرام (١ قطعة)	١٥-٥ دقيقة	ضع قطع كعك مجمدة مسطحة (١٨٠°م) مباشرة على الرف المعدني. ضع قطع أكبر والموفينية على الصينية الدوارة. ضع قطعة واحدة في الوسط، ضع قطعتين متقابلتين في دائرة و٤-٣ قطع في دائرة. بمساعدة السخان، سيصبح الكعك دافنا ورقيقا أكثر.	هذا البرنامج مناسب لقطع الكعب مثل كعب التفاح مع طبقة علوية مختلفة ، كعك ستريوسيل ، و كعك ببذور خشخاش مع والموفينية. هذا مناسب لكعك كله .. وكعك بامتناء كريم وكعك بطبقة شوكولات.

## استخدام وظيفة القفطير

بواسطة وظيفة القفطير ، يتم ضبط وقت الطبخ أوتوماتيكيا . يمكنك ضبط عدد الأشخاص للتقديم بتدوير الحلقة . أولا ، ضع الطعام في وسط الصينية الدوارة وأغلق الباب .

١. اختر نوع الطعام الذي تريد طبخه بالضغط على زر **Cafeteria**



٢. اختر حجما للتقديم بتدوير الحلقة.



٣. اضغط على زر

النتيجة: عندما يبدأ الجهاز بالطبخ. عند الانتهاء :

- (١) تنطلق صفارة من الفرن أربع مرات.
- (٢) وتتنطلق صفارة ثلاثة مرات لتنذير الانتهاء (مرة كل دقيقة)
- (٣) يعرض الوقت الحالي مرة ثانية.


على سبيل المثال: اضغط على زر القفطير مرة لإعادة تسخين كوب من القوهه واختر حجما للتقديم بتدوير الحلقة . راجع الجدول الموجود في الصفحة التالية .

٤. استخدم الأواني الأمانية للمايكرويف فقط .


## استخدام وظيفة إعادة التسخين الأوتوماتيكية

وظيفة إعادة التسخين الأوتوماتيكية لها نوعان من وقت الطبخ الذي تم برمجتها مسبقا . ولا تحتاج إلى ضبط وقت الطبخ ومستوى الطاقة . يمكنك ضبط عدد التقديم بتدوير الحلقة . أولا ، ضع الطعام في وسط الصينية الدوارة وأغلق الباب .

١. اختر نوع الطعام الذي تريد طبخه بالضغط على زر إعادة التسخين الأوتوماتيكية مرة أو أكثر .



٢. اختر حجما لتقديم الطعام بتدوير الحلقة . (راجع الجدول الموجودة في الصفحة التالية .)



٣. اضغط على زر .
- النتيجة: عندما يبدأ الفرن بالطبخ. عند انتهاء الطبخ :
- (١) تتنطلق الصفارة أربع مرات من الفرن .
  - (٢) تتنطلق الصفارة ٣ مرات للإشارة الى النهاية (مرة كل دقيقة).
  - (٣) يعرض الوقت الحالي مرة ثانية.



استخدم الأواني الأمانية للمايكرويف فقط .

## ضبط إعادة التسخين الزوتوماتيكية

الجدول التالي يقدم الأنواع المختلفة . برامج إعادة التسخين الأوتوماتيكية ، والكميات ، وأوقات الانتظار ، والنماص المناسبة .

الرمز / الطعام الكمية للتقديم وقت الانتظار النصائح


- |   |                          |             |         |  |
|---|--------------------------|-------------|---------|--|
| ١ | الوجبة الظاهرة (المبردة) | ٣٥.-٣٠ جرام | ٢ دقائق | ضع الوجبة في صحن خزفي وغطيه بالفينيل المناسب للمايكرويف. هذا البرنامج مناسب للوجبات الحトوية على ٣ مكونات (على سبيل المثال، لحم مع صلصة، خضار وأطباق جانبية مثل البطاطس، الأرز أو القفطير). |
|---|--------------------------|-------------|---------|--|

- |   |                         |             |         |  |
|---|-------------------------|-------------|---------|--|
| ٢ | الوجبات الظاهرة (مجمدة) | ٣٥.-٣٠ جرام | ٤ دقائق | خذ الوجبات الظاهرة المجمدة وتتأكد من أن الصحن مناسب للمايكرويف. أثقب الفليم للوجبات الظاهرة. ضع الوجبات الظاهرة المجمدة في وسط الفرن. هذا البرنامج مناسب للوجبات الظاهرة المجمدة التكونة من ٣ مكونات (على سبيل المثال، لحم مع صلصة، خضار وأطباق جانبية مثل البطاطس، الأرز أو الفطيرة). |
|---|-------------------------|-------------|---------|--|

## إيقاف الطبخ


يمكنك إيقاف الطبخ في أي وقت لفحص الطعام.

- إيقاف الطبخ مؤقتا:  
فتح الباب.



النتيجة: عندما يتوقف الفرن من الطبخ. وللعودة إلى الطبخ، أغلق الباب واضغط على زر ⌂ مرة أخرى.

- إيقاف الطبخ تماما:  
اضغط على زر ⌂.



النتيجة: عندما يتوقف الفرن عن الطبخ.  
إذا أردت إلغاء وضعية الطبخ، اضغط على الإلغاء (ⓧ) مرة أخرى.

يمكنك إلغاء أي وضعيات الضبط قبل البدء بالتشغيل بالضغط على زر الإلغاء (ⓧ).

## ضبط وقت الطبخ

يمكنك زيادة وقت الطبخ بالضغط على زر **30s +** (زيادة ٣٠ ثانية) مرة لزيادة ٣٠ ثانية كل مرة.

اضغط على زر **30s +** (زيادة ٣٠ ثانية) مرة لزيادة ٣٠ ثانية كل مرة.



- يمكنك ضبط الوقت فقط أثناء الطبخ عند اختيار وضعيات المايكروويف، وإعادة التسخين/الطبخ الآوتوماتيكي، والقفطير أو البخار القوي.

من أجل زيادة وقت الطبخ أو نقصه أثناء طبخ الطعام، دورّ الحلقة إلى اليمين أو اليسار.



## الطبخ / إعادة التسخين

الإجراءات التالية تشرح كيفية الطبخ وإعادة التسخين.

تأكد من وضعية الطبخ الذي تم ضبطها دائمًا قبل ترك الفرن عند غيابك.

أولاً، ضع الطعام في وسط الصينية الدوارة. اغلق الباب.


- اضغط على زر

النتيجة: عندما يعرض مؤشر ٨٥٠ واط (أقصى طاقة طبخ):

اختر مستوى الطاقة المناسب بالضغط على زر

مرة ثانية حتى يعرض الواط المطلوب.

راجع جدول مستوى الطاقة في الصفحة التالية.



- اضغط وقت الطبخ بتدوير الحلقة كما تريده.



- اضغط على زر

النتيجة: عندما يضاء ضوء الفرن وتبدأ الصينية الدوارة بتدويرها.

ويبدأ الطبخ وتنطلق الصفاراة أربع مرات من الفرن عند انتهاء الطبخ.



- لا تشغّل فرن المايكروويف عند تغريف.



إذا أردت تسخين طبق لمدة قصيرة على أقصى طاقة (٨٥٠ واط)، اضغط فقط على زر (زيادة ٣٠ ثانية) مرة كلما تريده إضافة ٣٠ ثانية من وقت الطبخ. وعندما يبدأ الفرن بالطبخ فوراً.



## مستويات الطاقة

يمكنك اختيار مستوى الطاقة من بين مستويات الطاقة المبينة أدناه.

قوية الفروع	مستوى الطاقة
٨٥٠ واط	عالي
٦٠٠ واط	متوسط عالي
٤٥٠ واط	متوسط
٣٠٠ واط	متوسط منخفض
١٨٠ واط	إذابة ثلج
١٠٠ واط	منخفض/تدفئة مستمرة

إذا اخترت مستوى الطاقة الأعلى، لا بد من نقص وقت الطبخ.



إذا اخترت مستوى الطاقة الأسفل، لا بد من زيادة وقت الطبخ.



إذا أردت تغيير وقت الطبخ أكثر أو أقل بتدوير الحلقة.

وقت الزيادة	الوقت
بواقع ٥ ثوانٍ	حتى ١ دقيقة
بواقع ١٠ ثوانٍ	٣-١ دقائق
بواقع ٢٠ ثوانٍ	١٠-٣ دقائق
بواقع دقيقة	٢٠-١.
بواقع دقيقتين	٤٠-٢.
بواقع ٥ دقائق	٩٩-٤.

## ماذا تفعل في حالة وجود شكوك أو حدوث مشكلة

إذا حصلت المشاكل المبينة أدناه، حاول حلها مراجعاً للحلول التالية.

- ◆ هذا أمر طبيعي:
  - التكاثف داخل الفرن
  - تدفق الهواء حول الباب وخارج الفرن
  - انعكاس الإضاءة حول الباب وخارج الفرن
  - خروج البخار من حول الباب أو الفتحات
  
- ◆ لا يبدأ الفرن بالتشغيل عند الضغط على زر .
  - هل تغلق الباب تماماً؟
  
- ◆ لا يتم طبخ الطعام أبداً
  - هل ضبطت المؤقت بشكل صحيح و/أو ضغطت على زر ؟
  - هل أغلقت الباب ؟
  - هل وصلت أجهزة كثيرة إلى مخرج التيار الجداري أكثر من اللازم والأمر يسبب في قطع صهيرية أو انفجار قاطعة ؟
  
- ◆ يتم طبخ الطعام مفرطاً أو غير كامل
  - هل طبّلت وقت الطبخ مناسباً لنوع الطعام ؟
  - هل اخترت مستوى الطاقة المناسب ؟
  
- ◆ تحدث الشارة والفرقة النارية داخل الفرن (القوس الكهربائي)
  - هل استخدم طبقاً مع أطرافه المعدنية ؟
  - هل تركت شوكة أو إبراء معدني آخر داخل الفرن ؟
  - هل الرقاقة الالمونيومية قريبة من جدران الفرن جداً ؟
  
- ◆ الفرن يؤدي إلى إحداث التداخل في أجهزة الراديو والتلفزيون
  - قد تحدث تداخل قليل في أجهزة التلفزيون أو الراديو أثناء تشغيل الفرن.
  - هذا أمر طبيعي. من أجل حل هذه المشكلة، ركب فرن المايكروويف بعيداً عن أجهزة التلفزيون والراديو والهواي.
- ◆ اذا وجدت التداخل في الكمبيوتر الصغير للفرن، قد يتم ضبط إعادة الضبط على نافذة العرض. من أجل هذه المشكلة، افصل قابس التيار واعد توصيله الى المخرج. واعد ضبط الوقت.


إذا لم تحل المشكلة مراجعة من القائمات المذكورة أعلاه، اتصل باللوزع المحلي أو مركز الخدمات بعد الشراء من سامسونج.

فرن المايكروويف مزود بساعة داخلية. ويمكنك عرض الوقت بنظام 24 ساعة أو 12 ساعة. لا بد من ضبط الساعة:


- عند تركيب فرن المايكروويف لأول مرة
- بعد انقطاع الطاقة الكهربائية

لا تنس إعادة ضبط الساعة عند التوقيت الصيفي والتوقيت الشتوي.


فاضغط على زر ...  
مرة 24 ساعة  
مرتين 12 ساعة




2. دور الحلة لضبط الساعة.




3. اضغط على زر .



4. دور الحلة لضبط الدقيقة.



5. اضغط على زر .



## تحذيرات من أجل السلامة (متابع)

- خذ العناية في حالة تناول الاناء بعد تسخين الطعام. الأمر قد يؤدي إلى ضرر في جسمك في حالة أن الاناء ساخن جدا.
- خطر فيضان الطعام الغالي وإمكانية إحراق الطعام، لا بد من وضع ملعقة بلاستيكية أو عمود زجاجي في المشروبات و تحريك الطعام قبل تسخينه وأثناءه وبعدة.
- السبب: أثناء تسخين السوائل، قد تتراجل نقطة التغليبة؛ هذا يعني أن الفيضان الغالي قد يبدأ بعد سحب الاناء من الفرن. قد يؤدي إلى إحداث ضرر في الجسم.
- في حالة إحراق الطعام، اتبع تعليمات المساعدة الأولى:
  - \* أغمض المنطقة الحرقـة من الطعام في الماء البارد لمدة ١٠ دقائق على الأقل.
  - \* غطي بالمرق النظيف والجاف.
  - \* لا تضف أي كريم، زيت أو مستحضر سائل.
  - \* لا تتملا الوعاء بالطعام حتى يصل إلى أعلى الوعاء واختـر الوعاء الذي الطرف العلوي أعرض من القعد لمنع فيضان الطعام الغالي. الزجاج بالعنق الضيق قد تتفجر بسبب الحرارة المفرطة.
  - \* افحض درجة الحرارة لأطعمة الأطفال أو الحليب قبل إعطائـها إلى الأطفال دائمـا.
  - \* لا تسخن زجاجات لأطعمة الأطفال مع حملـة الثدي ، لأن الزجاجات قد تتفجر بسبب الحرارة المفرطة.
- ٩. احذر عن عدم إحداث ضرر في سلك التيار الكهربائي.
  - لا تغمر سلك التيار الكهربائية أو قابس التيار بالماء واحفظ سلك التيار بعيدا عن مصادر الحرارة.
  - لا تشغل هذا الجهاز في حالة حدوث ضرر في سلك التيار وقابس التيار.
  - اترك طول الذراع من الفرن عند فتح الباب.
  - السبب: الهواء الساخن أو البخار المتسرـب قد يؤدي إلى إحداث الاحتراق.
  - ١١. احتفظ بالأسطح الداخلية النظيفة للفرن.
  - السبب: القطعة الصغيرة من الطعام أو الزيوت المنتشرة التي تسد جدران الفرن أو الأرض قد يؤدي إلى إحداث ضرر في الأسطح المغطاة بالدهان وحفظ كفاءة الفرن.
  - ١٢. قد يصدر صوت "الإغلاق" أثناء التشغيل، خاصة في وضعية إذابة الثلج.
  - السبب: عند تغيير الطاقة الكهربائية، قد تسمع هذا الصوت. هذا أمر طبيعي.
  - ١٣. عند تشغيل فرن المايكرورويف بدون أي شيء، تقطع الطاقة الكهربائية أو تمويماتيكيا من أجل السلامة. بعد أكثر من ٣٠ دقيقة من الانتظار، يمكنك تشغيل الفرن كما ينبغـي.

## تعليمات هامة من أجل السلامة

أثناء الطبخ، لا بد من مشاهدة داخل الفرن من حين الى آخر عند تسخين الطعام أو الطبخ في الأوعية المستخدمة مرة واحدة من البلاستيك ، أو الورق، أو المواد المستهلكة الأخرى.


## الهام

لا تسمح للأطفال الصغار لتشغيل فرن المايكرورويف أو العبث به أبدا. ولا تتركهم عند غيابك قريباً من فرن المايكرورويف عند تشغيله. لا تحفظ المواد الذي يهتم بها الأطفال أو تخفيها فوق فرن المايكرورويف.

## تركيب فرن المايكرورويف

ضع الفرن على أرض مستوية وثابتة لتحمل ثقل الفرن.

١. عند تركيب الفرن، تأكد من التهوية المناسبة للفرن بترك مسافة ١٠ سم على الأقل (اربع بوصات) خلف فرن المايكرورويف وفي جانبي الفرن وترك مسافة ٢٠ سم (ثمانية بوصات) فوق الفرن.



٢. ازيل جميع مواد الحشية داخل الفرن.  
ركب حلقة المف والصحن الزجاجي.  
تأكد من ان الصحـن الزجاجـي يدور بشكل حرـ.
٣. فرن المايـكروـيف هذا لا بد من وضعـه بحيث يصل قابـسـ الفرن الى مخرج التـيار.

→ لا تسد فتحـاتـ الهـواءـ لأنـ الفـرنـ قدـ يـعرـضـ لـالـحرـارـةـ المـفـرـطـةـ وـيـتـوقـفـ الفـرنـ عـنـ الـعـمـلـ ذاتـيـاـ.ـ وـالـفـرنـ يـبـقـيـ فيـ حـالـةـ أـنـهـ لاـ يـعـمـلـ حتـىـ يـبـرـدـ بشـكـلـ كـافـ.

٤. من أجل السلامة الشخصية، ادخل قابـسـ التـيارـ الىـ مـخـرـجـ التـيـارـ المـتـرـدـدـ ذـيـ ٢٣٠ـ فـوـلـتـ،ـ ٥ـ هـرـتزـ،ـ وـالـمـوـصـلـ بـالـسـلـكـ الـأـرـضـيـ .ـ إـذـاـ كـانـ حدـثـ ضـرـرـ فيـ سـلـكـ التـيـارـ لـهـذـاـ الجـهاـزـ،ـ لاـ بـدـ مـنـ تـبـدـيـلـهـ مـنـ قـبـلـ فـنـيـ مـخـتصـ لـسـلـكـ التـيـارـ)ـ (ـEUROELECTRICـ 3410ـ Dـ I-SHENGـ SP022ـ ،ـ KDKـ KKPـ 4819ـ Dـ ،ـ MOONSUNGـ EP-48Eـ ،ـ SAMILـ SP-106Bـ ،ـ PENCONـ (ZD16A)ـ (ـSA16ـ (ـHIGH~PROJECT~H.P3ـ ،ـ بالـلـوـزـ الـمـلـحـيـ مـنـ أـحـلـ تـبـدـيـلـهـ.ـ وـسـلـكـ التـيـارـ فـيـ إـسـرـائـيـلـ مـنـ نـوـعـ (ـUD13A1ـ (ـW肯ـيـاـ وـالـإـمـارـاتـ الـعـرـبـيـةـ الـمـتـحـدـةـ مـنـ نـوـعـ (ـPENCONـ (ـUD13A1ـ).

٥. لا تترك فرن المايـكروـيفـ فيـ مـكـانـ حـارـ أوـ رـبـطـ مـثـلـ مـكـانـ قـرـيبـ منـ فـرنـ تقـلـيـدـيـ أوـ جـهاـزـ التـدـفـقـةـ.ـ وـلـاـ بـدـ مـنـ مـرـاعـاـتـ الـمـواـصـفـاتـ الـكـهـرـبـائـيـةـ وـلـاـ بـدـ مـنـ تـمـدـيـدـ سـلـكـ التـيـارـ الـكـهـرـبـائـيـ منـ نـفـسـ النـوـعـ الـقـيـاسـيـ معـ سـلـكـ التـيـارـ المـزـوـدـ معـ فـرنـ المـايـكـروـيفـ هـذـاـ.ـ أـمـسـحـ الـأـسـطـحـ الـدـاخـلـيـةـ وـخـتـمـ الـبـابـ بـقـطـعـةـ مـنـ الـقـمـاشـ الـمـبـلـلـ قـبـلـ اـسـتـخـدـمـ فـرنـ المـايـكـروـيفـ لـأـوـلـ مـرـةـ.

لقد اشتريت فرن المايكروويف من سامسونج . وتعليمات المالك تحتوي على المعلومات المفيدة الكثيرة عن الطبخ بواسطة فرن المايكروويف.

- تحذيرات من أجل السلامة
- الملحقات وأواني الطبخ المناسبة
- لمحات الطبخ المفيدة

في الوجه الداخلي لصفحة الغلاف تجد الدليل السريع للنظر الذي يشرح ثلاثة تشغيلات الطبخ الأساسي:

- طبخ الطعام
- إذابة الثلج الأوتوماتيكية من الطعام
- ضبط وقت طبخ إضافي

في الجزء السامي من تعليمات المالك تجد رسوم الفرن ولوحة التحكم ذات أكثر أهمية، فتجد الأزرار بسهولة أكثر.

تستخدم الإجراءات خطوة خطوة ثلاثة رموز مختلفة.



دوار



ملاحظة



هام

### التحذيرات لتجنب إحتمال التعريض لطاقة المايكروويف المفرطة

الفشل في تبع التحذيرات من أجل السلامة التالية قد يؤدي إلى التعريض الضار لطاقة المايكروويف.

(أ) محاولة تشغيل الفرن مع بابه المفتوح بدون أي شيء في الفرن أو العبث بالغلق الأمامي الداخلي (مزلاجي الباب) أو إدخال أي شيء إلى فتحات الغلق الأمامي الداخلي.

(ب) لا تضع أي شيء بين باب الفرن والوجه الأمامي أو تترك الطعام أو مادة التنظيف حتى تترانكم على سطح الختم. تتأكد من المحافظة على النظافة في الباب وأسطح ختم الباب من خلال مسحها أولاً بعد استخدام الفرن بقطعة من القماش الملل ثم بقطعة من القماش الناعم الجاف.

(ج) لا تشغيل فرن المايكروويف في حالة حدوث ضرر فيه حتى يتم إصلاحه من قبل فني مختص لخدمات فرن المايكروويف الذي تم تدريبه في المنتج.

من المهم جداً إغلاق الفرن بإحكام وعدم ضرر في :

(١) الباب، أختمام الباب وأسطع الختم  
(٢) مفصلات الباب (مكسورة أو غير مربوطة بإحكام)

(٣) سلك التيار  
(د) لا بد من عدم تعديل الفرن أو إصلاحه من قبل أي شخص بدلًا من فني مختص لخدمات فرن المايكروويف الذي تم تدريبه في المنتج.

## تحذيرات من أجل السلامة

تعليمات هامة من أجل السلام

اقرأها بعناية واحتفظ بها للمراجعة في المستقبل.

قبل طبخ الطعام أو السوائل في فرن المايكروويف، الرجاء التأكد من تبع التحذيرات من أجل السلامة.

١. لا تستخدم أي إناء طبخ معدني في فرن المايكروويف.

• أواني معدنية

• أواني الوجبات بالأطراف الذهبية والفضية

• سفافيد ، أشواك ... الخ

السبب: قد يحدث القوس الكهربائي أو الشرارة وقد يحدث ضرر في الفرن.

٢. لا تسخن

• الزجاجات والمرطبات المسودة الهواء أو المختومة على سبيل المثال) زجاجات أطعمة الأطفال

• الطعام المسود الهواء على سبيل المثال) البيضات والجوزات غير المقشورة ، الطماطم

السبب: زيادة الضغط قد تؤدي إلى انفجار هذه الأطعمة.

لحة: ازل قشرة وثقب القشرة والأكياس ... الخ.

٣. لا تشغّل فرن المايكروويف في حالة فراغه.

السبب: هذا قد يؤدي إلى إحداث ضرر في جدران الفرن.

لحة: ضع فنجانًا من الماء داخل الفرن دائمًا. والماء يمتص موجات المايكرو في حالة تشغيل الفرن مع أنه فارغ مفاجئًا.

٤. لا تعطي فتحات التهوية في اللوحة الخلفية بالأقمشة أو الورق.

السبب: الأقمشة أو الأوراق قد تؤدي إلى إحداث احتراق لأن الهواء الساخن يخرج من الفرن.

٥. استخدم قفاز الفرن دائمًا عند إخراج طبق من الفرن.

السبب: تمتص بعض الأطباق موجات المايكرو وتتنقل الحرارة من الطعام إلى الطبق دائمًا. الأطباق تتنقل الحرارة.

٦. لا تلامس عنصر التسخين أو جدران الفرن الداخلية.

السبب: هذه الجدران قد تصبح ساخنة بدرجة كافية تحرق حتى بعد انتهاء الطبع بالرغم أن الحرارة لا تظهر كما هي. لا تترك المواد القابلة للاشتعال تدخل المنطبق الداخلية للفرن. دعنا الفرن يبرد أولاً.

٧. لخفض خطر الاحتراق في تجوييف الفرن:

• لا تحفظ المواد القابلة للاشتعال في الفرن.

• ازول سلكا متلوياً مربوطة بالأوراق أو الأكياس البلاستيكية.


• لا تستعمل فرن المايكروويف لتجفيف أوراق الأخبار.

• اذا حدث دخان، ابق فتح باب التيار واضغط على زر التيار الكهربائي للإيقاف او اخرج قابس التيار من مخرج التيار الجداري.


٨. خذ عناية كبيرة عند تسخين السوائل والأطعمة للأطفال. ن اترك الطعام لوقت الانتظار دائمًا لمدة ٢٠ ثانية على الأقل بعد إيقاف الفرن عن العمل لتساوي درجة الحرارة.

• حرك الطعام أثناء تسخينه عند الحاجة وكرر الطعام بعد تسخينه دائمًا.

## لوحة التحكم




٧. زر اختيار إذابة اللح القوية
٨. اختيار إعادة التسخين الآوتوماتيكية
٩. اختيار القفطير
١٠. زر ضبط مستوى الطاقة
١١. زر التشغيل/مقبض الباب  
(وقت الطبخ، الوزن وحجم للتقديم)
١. العرض
٢. ضبط وقت الانتظار
٣. زر إزالة الرائحة الكريهة
٤. اختيار البخار القوي
٥. زر الإيقاف/إلغاء
٦. زر ضبط الساعة




## الملحقات

اعتماداً على الموديل الذي اشتريته، جهاز الفرن مزود بالملحقات المختلفة التي يمكنك استخدامها بطرق مختلفة.


١. المقرانة، تم وضعها مسبقاً فوق عمود المотор في قعد الفرن.  
الهدف: تدور المقرانة الصينية الدوارة.




٢. حلقة عجلات، تم وضعها في وسط الفرن.  
الهدف: تستند الحلقة بالعجلات الصينية الدوارة.



٣. الصينية الدوارة، تم وضعها على الحلقة بالعجلات في وسط الفرن ملائمة للمقرانة.  
الهدف: تستخدم الصينية الدوارة كساند الطبخ الرئيسي؛ يمكنك إزالة قطعة من الطعام للتنظيف بسهولة.



٤. جهاز الطبخ بالبخار القوي ، راجع صفحة ١٠.  
الهدف: استخدم جهاز الطبخ البلاستيكي بالبخار عند استخدام وظيفة البخار القوي.



لا تشغّل فرن المايكروويف بدون الحلقة بالعجلات والصينية الدوارة.

# فرن المايكروويف

## تعليمات المالك ودليل الطبخ

M187DN

٢	الفرن .....
٢	الملحقات .....
٢	لوحة التحكم .....
٣	كيفية استخدام تعليمات المالك هذه .....
٣	تحذيرات من أجل السلامة .....
٤	تحذيرات من أجل السلامة (متتابع) .....
٤	تركيب فرن المايكروويف .....
٥	ضبط الوقت .....
٥	ماذا تفعل في حالة وجود شكوك أو حدوث مشكلة .....
٦	الطبخ/إعادة التسخين .....
٦	مستويات الطاقة .....
٧	إيقاف الطبخ .....
٧	ضبط وقت الطبخ .....
٧	ضبط وقت الانتظار .....
٨	استخدام وظيفة إعادة التسخين الأوتوماتيكية .....
٨	ضبط إعادة التسخين الروتاماتيكية .....
٨	استخدام وظيفة القفطير .....
٩	ضبط وظيفة القفطير .....
٩	استخدام وظيفة إزالة الثلوج الأوتوماتيكية القوية .....
١٠	ضبط إزالة الثلوج القوية الأوتوماتيكية .....
١٠	استخدام وظيفة البخار القوي .....
١١	استخدام وظيفة البخار القوي (متتابع) .....
١١	استخدام وظيفة إزالة الرائحة الكريهة .....
١٢	إيقاف انطلاق الصفاراة .....
١٢	الإغلاق الآمني لفرن المايكروويف .....
١٣	دليل الأواني .....
١٤	تنظيف فرن المايكروويف .....
١٤	حفظ فرن المايكروويف وإصلاحه .....
١٥	المواصفات الفنية .....

