Franklin®

DBE-1440

Spanish Professor
Profesor de inglés

USER'S GUIDE / MANUAL DEL USUARIO

BOOKMAN® II

License Agreement

READ THIS LICENSE AGREEMENT BEFORE USING ANY BOOKMAN® PRODUCT.

YOUR USE OF THE BOOKMAN PRODUCT DEEMS THAT YOU ACCEPT THE TERMS OF THIS LICENSE. IF YOU DO NOT AGREE WITH THESE TERMS, YOU MAY RETURN THIS PACKAGE WITH PURCHASE RECEIPT TO THE DEALER FROM WHICH YOU PURCHASED THE BOOKMAN PRODUCT AND YOUR PURCHASE PRICE WILL BE REFUNDED. BOOKMAN PRODUCT means the software product and documentation found in this package and FRANKLIN means Franklin Electronic Publishers, Inc.

LIMITED USE LICENSE

All rights in the BOOKMAN PRODUCT remain the property of FRANKLIN. Through your purchase, FRANKLIN grants you a personal and nonexclusive license to use the BOOKMAN PRODUCT on a single FRANKLIN BOOKMAN at a time. You may not make any copies of the BOOKMAN PRODUCT or of the data stored therein, whether in electronic or print format. Such copying would be in violation of applicable copyright laws. Further, you may not modify, adapt, disassemble, decompile, translate, create derivative works of, or in any way reverse engineer the BOOKMAN PRODUCT. You may not export or reexport, directly or indirectly, the BOOKMAN PRODUCT without compliance with appropriate governmental regulations. The BOOKMAN PRODUCT contains Franklin's confidential and proprietary information which you agree to take adequate steps to protect from unauthorized disclosure or use. This license is effective until terminated. This license terminates immediately without notice from FRANKLIN if you fail to comply with any provision of this license.

Table of Contents

Welcome to the world of Franklin! With the Spanish Professor you can find over 2,000,000 translations, correct misspellings, conjugate words, study the Grammar Guide, save words to My Word List, sharpen your spelling and increase your Spanish vocabulary with six learning exercises, and play seven fun, educational word games.

Installing Batteries **5**
Changing the Language **5**
Installing Book Cards **6**
Selecting a Book **6**
Bookcard Color Keys **7**
Using the Main Menu **7**
Viewing a Demonstration or Tutorial **8**
Changing the Settings **8**
Translating Spanish Words **9**
Translating English Words **10**
Using Learning Exercises **11**
Using the Grammar Guide **13**
Highlighting Words **14**
Advanced Verb Conjugations **14**
Finding Letters in Words **17**
Translating Traveller's Phrases **17**
Using My Word List **18**
Playing the Games **20**
Using the Calculator **23**
Using the Converter **24**
Transferring Words Between Books **25**
Resetting Your Product **25**

Key Guide

Color Keys

conj Conjugates a word.

lang Toggles the entry language between Spanish and English.

dict Goes to the dictionary.

learn Goes to the Exercises menu (for learning exercises).

Function Keys

Turns the product on or off.

help Displays a help message. When at an inflection screen, displays Grammar Guide section about the inflection you were viewing.

clear In the dictionary, goes to the Word Entry screen. Clears the calculator. In the converter, goes to its main menu.

back Backs up, erases a letter, or turns off the highlight at an entry.

enter Enters a word, selects an item, or begins a highlight in an entry.

menu Displays the main menus for the dictionary.

*?** At the Word Entry screen, types a ? to stand for a letter in a word. At a menu, displays a menu item. At a dictionary entry, displays the headword. In games, reveals the word and forfeits the game.

cap Shifts to type capital letters and punctuation marks.

fn Shifts to allow ***prev***, ***next***, ***pg up***, ***pg dn*** and to type a hypen (**-**) or *ñ*.

Toggles between the calculator and converter.

card Exits the book you were reading.

Direction Keys



Move in the indicated direction.

space At menus and dictionary entries, pages down. At the Word Entry screen, types a space.

➤ Opening the Lid

To open the lid, push the notch towards the back of the unit and lift up.

Key Guide

Combination Keys*

fn + ↑ or ↓	At a dictionary entry, pages up or down.
fn + → or ←	At a dictionary entry, displays the next or previous entry.
cap + ↑ or ↓	At a menu, goes to the first or last item. At a dictionary entry, goes to the start or end of the entry.
fn + card	Transfers a word between books.
fn + *j*	Types a hyphen.
fn + *n*	Types an *ñ*.
fn + ?*	Goes to the traveller's phrases menu.
cap + ?*	At the Word Entry screen, types an asterisk to stand for a series of letters in a word. In games, gives a hint.

**Hold the first key while pressing the second.*

Calculator/Converter Keys

a (1/x)	Calculates a reciprocal.
s (√x)	Calculates a square root.
d (x^2)	Squares a number.
f (%)	Calculates a percentage.
g (.)	Inserts a decimal point.
z (+/-)	Changes the number on the screen to a negative or positive number.
x (M+)	Adds the number to the number stored in the memory.
c (M-)	Subtracts the number from the number stored in the memory.
v (MR)	Recalls the number stored in the memory.
b (MC)	Clears the memory.

Installing Batteries

Your product is powered by two CR-2032 lithium, 3-volt batteries. Follow these easy instructions to install or replace them.

1. Turn your product over.

2. Lift the battery cover on the back of your product by pushing up on the catch.

3. Install the batteries with the positive side facing up.

4. Replace the battery cover.

Warning: If the batteries wear-out completely, or if you take more than approximately a minute while changing the batteries, any information that was entered in the built-in book or book card except My Word List will be erased. You should always keep written copies of your important information.

➤ Help is Always at Hand

You can view a help message at any screen by pressing help. Press space or ↓ to read. To exit help, press clear.

Changing the Language

Message Language

When you turn on this product for the first time, you must choose the message language. Press ***a*** for English or press ***b*** for Spanish.

The message language is the language of prompts, help, and other messages. You can change the message language after your initial decision. See "Changing the Settings" to learn how.

Entry Language

The entry language is the language in which you enter words at the Word Entry screen. This determines which dictionary you will use, Spanish or English.

1. Press menu.

2. Use the direction keys to highlight ESP ENG., and then press enter to access the Spanish-to-English dictionary.

Select ENG ESP. at the icon menu to go to the English-to-Spanish dictionary.

Or you can press lang at the Word Entry screen to switch between Spanish and English.

Installing Book Cards

1. Turn your product off.

2. Turn your product over.

3. Align the tabs on the book card with the notches in the slot.



4. Press the book card down until it snaps into place.

➤ Removing Book Cards

Warning: Never install or remove a book card while your product is on. Any information that was entered in the built-in book or book card will be erased.

➤ About Screen Illustrations

Some screen illustrations in this User's Guide may differ slightly from what you see on screen. This does not mean that your product is malfunctioning. The examples in the English half of this manual use English as the message language.

Selecting a Book

Once a book card is installed in the product, you can select which book you want to use.

1. Turn your product on.

2. Press *card*.

These are sample books.

3. Press ⊕ or ⊖ to highlight your selection.

For information on available Franklin Bookman products, highlight the Bookman Info Icon, INFO.

4. Press *enter* **to select it.**

5. Press *card* **to return to the card menu.**

Bookcard Color Keys

The red, green, yellow, and blue keys on your product change functions according to the book card you select. Their functions are labelled on individual cards.



When in your book card:

For…	Press…
the red key	conj
the green key	lang
the yellow key	dict
the blue key	learn

You can also press and hold fn to learn how the color keys on your *book card* correspond to the main keys on your *product*.

Using the Main Menu

When you press menu, you will see ten icons. Use these to quickly take you to different parts of your Spanish Professor.

Use the arrow keys to highlight the icon you want and press enter.

➤ Understanding the Menu

- Goes to the English-to-Spanish dictionary.
- Goes to the Spanish-to-English dictionary.
- Goes to the Exercises menu (learning exercises).
- Goes to the Games menu.
- Goes to the English conjugation prompt.
- Goes to the Spanish conjugation prompt.
- Goes to the English traveller's phrases menu.
- Goes to the Spanish traveller's phrases menu.
- Goes to My Word List.
- Goes to the Tools menu.

Viewing a Demonstration or Tutorial

You can view a demonstration or tutorial of this dictionary at any time.

1. Press menu**.**

2. Use the arrow keys to highlight **and press** enter**.**



3. Press ↓ **to highlight either *Tutorial* or *View Demo* and press** enter**.**

To stop the demonstration or exit from the Tutorial and go to the Word Entry screen, press clear.

To go to the main menu, press menu.

When a book card is installed in your product, select *View Demo* from the Setup menu to see the demonstration for that card.

➤ Follow the Arrows

The flashing arrows on the right of the screen show which arrow keys you can press to move around menus or view more text.

Changing the Settings

When using this dictionary, you can activate the *Learn a Word* feature, or adjust the screen contrast, the shutoff time, the type size, and the message language. The shutoff time is how long your product stays on if you forget to turn it off.

1. Press menu **in the dictionary, calculator, or converter.**

2. Use the arrow keys to highlight **and press** enter**.**

3. *Settings* will be highlighted. Press enter **to select it.**

4. Press ↓ **or** ↑ **to move ➤ to *Learn a Word*, *Contrast*, *Shutoff*, *Type Size*, or *Mensajes* (*Message language*).**

5. Press ← **or** → **to change the setting.**

Your changes are automatically saved.

6. Press enter **when done.**

Press clear to return to the Word Entry screen.

➤ Learn a New Word

Your dictionary comes with a *Learn a Word* feature to help you increase your Spanish or English vocabulary. Each time you turn your Spanish Professor on, you can see a random headword taken from the dictionary.

If you wish to turn this feature on, press menu. Highlight and press enter. Press enter again to select *Settings*. Press ◄ or ► to turn the feature on and press enter when done.

Translating Spanish Words

Your Spanish Professor is fully bilingual. Try translating a Spanish word.

1. Press lang to change the entry language from English to Spanish, if needed.

2. Type a word (e.g., *estudiar*).
To erase a letter, press back. To type accents, type the letter (e.g., *e*) and press ↑ repeatedly until the accent you want appears (e.g., *é*). If you want to type an ñ, then hold fn and press *n*. To type a capital, hold cap and press a letter key. To type a number, hold fn and press *q*-*p*. To type a hyphen, hold fn and press *j*.

3. Press enter to view the English translation.



Press space or ↓ to scroll.

4. Hold fn and press ► or ◄ to view the next or previous definition.

5. Press clear when done.

➤ Understanding Definitions

Dictionary entries consist of headwords, parts of speech, the translation, and/or definitions. Other forms of the word may follow the headword. Capitalized words indicate the category for which the word is used. After the translation or definition, you may see a list of usage examples.

1. **Type *saber*.**
2. **Press** (enter).



➤ Explanation of Genders

Spanish nouns are different than English nouns in that they must either be masculine or feminine. Each definition of a noun indicates which gender it is with *m* or *f*.

➤ Misspelling Words

If you enter a misspelled word, a list of corrections appears. Highlight the word you want and then press (enter) to see its dictionary entry.

Translating English Words

You can also use the Spanish Professor to translate English words into Spanish.

1. **Press** (lang) **to change the entry language from Spanish to English, if needed.**
2. **Type a word (e.g., *read*).**

   To erase a letter, press (back). To type accents, type the letter (e.g., *e*) and press ↑ repeatedly until the accent you want appears (e.g., *é*). To type a capital, hold (cap) and press a letter key. To type a number, hold (fn) and press ***q*-*p***. To type a hyphen, hold (fn) and press ***j***.
3. **Press** (enter) **to view the Spanish translation.**



   Press (space) or ↓ to scroll.
4. **Hold** (fn) **and press → or ← to view the next or previous definition.**
5. **Press** (clear) **when done.**

➤ Choosing Multiple Forms

Some words in this dictionary have more than one form (e.g. sí, si). When the word you are looking up has multiple forms, the different forms appear in a list.

Simply highlight the form you want and press (enter) to see its dictionary entry. For example, enter *si* at the Word Entry screen.





Highlight the form you want and press (enter) to see its dictionary entry. To go back to the Multiple Forms list, press (back).

Using Learning Exercises

Using learning exercises, you can read cultural notes, test your spelling, improve your vocabulary, browse the Franklin® TOEFL® Test Word List, and get grammar guidance (see "Using the Grammar Guide" on page 13).

Cultural Notes

1. Press (menu), highlight [icon] and press (enter).

Or you can press (learn).

2. Use ↓ to highlight *Cultural Notes* and press (enter).

You can choose to read either English cultural notes which refer to the United Kingdom and the United States, or Spanish cultural notes which refer to Spain and Latin America.

Spelling Bee

1. Press (menu), highlight [icon] and press (enter).

Or you can press (learn).

2. Use ↓ to highlight *Spelling Bee* and press (enter).

TOEFL is a registered trademark of Educational Testing Service (ETS). This product is not endorsed or approved by ETS.

You can choose *My Spelling Bee (English)* which uses English words from My Word List, *My Spelling Bee (Spanish)* which uses Spanish words from My Word List, or the Franklin® *TOEFL® Test Spelling Bee* which uses words from the TOEFL® Test Word List.

3. Highlight the list you want and press enter**.**

A word will flash on the screen for you to spell.

4. Type in the word you just saw and press enter **to see if you spelled it right.**

Press enter to see the definition. Press back to return to Spelling Bee.

5. Press space **for a new word.**

6. Press clear **when done.**

Flashcards

1. Press menu**, highlight** **and press** enter**.**

Or you can press learn.

2. Use ↓ **to highlight *Flashcards* and press** enter**.**

You can choose *My Flashcards (English)* which uses English words from My Word List, *My Flashcards (Spanish)* which uses Spanish words from My Word List, or *TOEFL® Test Flashcards* which uses words from the TOEFL® Test Word List.

3. Highlight the list you want and press enter**.**

A word will be displayed on the screen for you to study or define. Press enter to see the definition. Press back to return to Flashcards.

4. Press space **to see a new word.**

5. Press clear **when done.**

Viewing the TOEFL® Test Word List

1. Press menu**, highlight** **and press** enter**.**

Or you can press learn.

2. Use ↓ **to highlight *TOEFL® Test Word List* and press** enter **to view the list.**

Press ↓ or ↑ to scroll.

You can also type the first few letters of a word to find it on the list (e.g., type *col* to find *collaborate*).

Press enter or conj at any word to view its definition or to conjugate it. Press back to return to the list.

Using the Grammar Guide

Your Spanish Professor includes a helpful grammar guide that describes parts of speech. You can view it by selecting from the main menu or by pressing learn.

From the Exercises Menu

1. **Press** menu**.**
2. **Highlight** **and then press** enter**.**

   Or you can press learn.
3. **Press ↓ to highlight *Grammar Guide* and then press** enter**.**



4. **Press ↓ to highlight the topic you want to study and then press** enter**.**
5. **Press** space **or ↓ to read.**
6. **Press** fn **+ → or ← to view the next or previous topic.**

From an Inflection Screen

1. **Press** menu**, highlight** **or** **, and then press** enter**.**
2. **Type a word to conjugate, and then press** conj**.**
3. **Press** fn **+ → or ← repeatedly to find the tense you want to read about in the Grammar Guide.**



4. **Press** help**.**



   Information about the tense will be displayed along with usage examples.
5. **Press** back **to return to the inflection screen or press** clear **to return to the Word Entry screen.**

Highlighting Words

Another way to look up words is by highlighting them in dictionary entries or word lists. You can then find *their* definitions, phrases, or add them to My Word List.

1. At any text, press (enter) to start the highlight.



To turn the highlight off, press (back).

2. Use the arrow keys to move the highlight to the word you want.



To …	Press …
define the word	(enter)
find a phrase	(fn)+(?*)
add word to My Word List	(learn)

3. Press (clear) when done.

Advanced Verb Conjugations

Conjugations show inflections, or changes in a word's gender, tense, etc. This dictionary includes extensive inflections of nouns, verb, modifiers, and other words.

From the Icon Menu

1. For example, press (menu), use the arrow keys to highlight [DAR DOY DADO.] (Spanish Conjugation) and then press (enter).

To choose English conjugation, press [GIVE GAVE GIVEN.]. You can also press (conj) and then (lang) to choose the language.

2. Type a word (e.g., *leer*).

3. Press (conj).

If needed, highlight the part of speech or translation you want and press (enter).



These are the principal forms of the Spanish verb "leer". The English translations are below each Spanish inflection.

4. Press (space) or ↓ to scroll.

Press (?*) to display the root word.

5. Press either (conj) or hold (fn) and press ⊕ repeatedly to view more inflections.

If the word is a noun, an adjective, or another modifier, then there won't be any other inflections.

6. Press (clear) when done.

From a Dictionary Entry

Some words have different parts of speech or multiple translations. You can easily find which part of speech or specific translation you will need to conjugate by first looking up the word and then pressing (conj). Follow this example.

1. Press (menu), use the arrow keys to highlight [ESP ENG.], and then press (enter).

To choose English, press [ENG ESP.]. You can also press (conj) and then (lang) to choose the language.

2. Type a word (e.g., *estudiar*).

3. Press (enter) to look it up.



Advanced Verb Conjugations

Read the definition to find the verb you want (e.g., *to study*).

4. Press (conj) to conjugate the headword, *estudiar*.

Highlight the translation you want (e.g., *study*) and press (enter).



These are the principal forms of the Spanish verb "estudiar". The English translations are below each Spanish inflection.

5. Press (space) or ↓ to scroll.

Press (?*) to display the root word.

6. Press either (conj) or hold (fn) and press ⊕ repeatedly to view more inflections.

If the word is a noun, an adjective, or another modifier, then there won't be any other inflections.

7. Press (clear) when done.

➤ Accenting Letters

You can look up accented words without typing accents. If there are no Multiple Forms, the Spanish Professor will take you directly to the word. If there are Multiple Forms, you will have to choose the correct word from a Multiple Forms list. See “Choosing Multiple Forms” on page 11 for more information.

Remember, if you want to enter an accent yourself, type the letter and press ↑ until the appropriate accent appears. You can also hold *fn* and press ***n*** to get an ñ.

➤ Getting Grammar Guidance

When viewing inflections, you can press *help* to go directly to the Grammar Guide and view detailed descriptions of how to use the inflections you were viewing along with usage examples.



Advanced Verb Conjugations

➤ Viewing English Inflections

If you are unfamiliar with inflections, it may be helpful to look at some inflected forms of English verbs. Switch the entry language back to English, type *write*, and press *conj* to see the different forms of the English verb “to write”.



This will give you a good idea of each inflection form.

➤ Verb Conjugations

The Spanish Professor conjugates verbs into the following forms: present, imperfect, preterite, future, conditional, present subjunctive, imperfect subjunctive, imperfect subjunctive 2, present perfect, pluperfect, preterite anterior, future perfect, conditional perfect, present perfect subjunctive, pluperfect subjunctive, pluperfect subjunctive 2, imperative, present progressive, and past progressive.

Finding Letters in Words

If you are uncertain about how to spell a word, type a question mark (?) in place of each unknown letter. To find prefixes, suffixes, and other parts of words, type an asterisk (✻) in a word. Each asterisk stands for a series of letters. Note: If you type an asterisk at the beginning of a word, it may take a little while to find the matching words.

1. Press (lang) to switch to the Spanish Word Entry screen, if needed.

2. Type a word with ?s and ✻s.



To type an asterisk, hold down (cap) and press (?*).

3. Press (enter).



4. Press ↓ to move the highlight to the word you want and press (enter) to view its definition.

5. Press (clear) when done.

Translating Traveller's Phrases

There are two ways in which you can translate several helpful phrases in categories ranging from *Emergencies* to *Business Communication* to *Time & Dates*.

Browsing Through Phrases

1. Press (menu).

2. Use the arrow keys to highlight [ENG.] and then press (enter) to view the English phrases.

Press [ESP.] to view the Spanish phrases.

You can also hold (fn) and press (?*) to go straight to the Phrases menu in the same language as the lookup language.

3. Press ↑ or ↓ to highlight the category you want and press (enter).

Press ↑ or ↓ to highlight a subcategory, if needed, and press (enter).



4. Press ↑ or ↓ to highlight the phrase you want to translate and then press enter.



Searching for a Specific Phrase

1. Press clear and then press lang to select the look-up language, if needed.
2. Type a keyword for which you'd like to find a phrase (e.g., *ticket*).
3. Hold fn and press ?*.





4. If more than one phrase is found, press space or ↓ to scroll.

Using My Word List

You can save up to 40 words total, in both English and Spanish, in My Word List for personal study or review. My Word List is saved between sessions unless your product is reset.

Adding Words from the Exercises Menu

1. Press menu.
   Or you can press learn and then press enter.
2. Highlight and then press enter.



3. Press lang to switch from the English to the Spanish List, if needed.
4. Press ↑ or ↓ to highlight *Add a word* and press enter.
5. Type a word.
6. Press enter to add the word.
7. Press clear when done.

➤ Adding Highlighted Words

You can also add words to My Word List from definitions and correction lists. First highlight a word and then press learn. *Add "your word"* will be highlighted. Press enter to add the word.

Adding Words from the Word Entry Screen

You can also add words to My Word List directly from the Word Entry screen.

1. Press (clear)**.**

2. Press (lang) **to choose the language of the word you want to add (e.g., Spanish).**

English words will be added to the English List; Spanish words will be added to the Spanish List.

3. Type the word you want to add to your word list (e.g., *elegante*).



4. Press (learn)**.**



Your selection is included in the menu item.

5. Press (enter) **to add the word.**

6. Press (clear) **to return to the Word Entry screen.**

Using My Word List

Viewing My Word List

1. Press (menu)**.**

Or you can press (learn) and then press (enter).

2. Highlight **and then press** (enter)**.**

3. Press (lang) **to switch to the English or Spanish List, if needed.**

English list: Empty (or *Spanish list: Empty*) will be displayed if either is empty.

4. *English List* (or *Spanish List*) will be highlighted. Press (enter) **to view the list.**

This is a user list of one word.

5. Highlight a word on the list.

6. Press (enter) **to view its definition(s) or** (conj) **to view its inflections.**

Removing a Word from My Word List

1. **Press** menu.

   Or you can press learn and then press enter.

2. **Highlight** **and then press** enter.

3. **Press** lang **to switch to the English or Spanish List, if needed.**

4. **Select *Delete a Word* and then highlight the word you want to delete.**

5. **Press** enter **to delete that word.**

Erasing My Word List

1. **Press** menu.

   Or you can press learn and then press enter.

2. **Highlight** **and then press** enter.

3. **Press** lang **to switch to the English or Spanish List, if needed.**

4. **Select *Erase the List*.**

   Press ***y*** to erase the list or press ***n*** to cancel.

   Note: When you erase one list, the other list is not erased.

Playing the Games

You have seven fun games to choose from.

Changing Game Settings

Before you play, you can choose the source of the words, the skill level, the language, and whether or not graphics will be used.

1. **Press** menu**, highlight** **and press** enter.

2. **Hold down** cap **and press** ↓ **to highlight *Game Settings* and press** enter.

3. **Use** ↑ **or** ↓ **to move** ▶ **to *Words* or *Skill.***

   Words chooses the source of the words: All of them, the Franklin® TOEFL® Test List, My Word List, or Enter your own.

   Skill determines how easy or difficult a game is.

4. **Use** ← **or** → **to change the setting(s) you want.**

5. **Press** enter **when done.**

Playing the Games

Selecting a Game

In the Games list, use ↓ or ↑ to move the highlight to the game of your choice and press enter.



Getting Help in the Games

During any game you can read instructions by pressing help.

You can get a hint by holding cap and pressing ?* or reveal the game word by pressing ?*.

Note: If you reveal the game word, you lose the round.

Hangman

Hangman selects a mystery word and challenges you to guess it letter by letter. The letters of the mystery word are hidden by question marks. The number of guesses remaining is indicated by #'s.

Type letters that you think are in the mystery word. If you are correct, the letter appears in place of the corresponding question mark(s). To see the definition of the game word, press enter. Press back to return to the game.

Conjumania!™

Conjumania! teaches verb conjugations. It shows you an infinitive verb and asks you to enter a conjugation. Your conjugation must be spelled correctly, including accents. Type your guess and then press enter. To see the definition of the game word, press enter. Press back to return to the game. To try a new conjugation, press space.

Gender Tutor™

Gender Tutor asks you to guess the gender of Spanish nouns. Press ***m*** for masculine and ***f*** for feminine. To see the definition of the game word, press enter. Press back to return to the game.

Word Train™

In Word Train, you and the train take turns typing letters to form a word. Whoever types the last letter of the word wins. To view the letters you can type at your turn, hold cap and press ?*. Press ?* to end

Playing the Games

a round and reveal the word. To see the definition of the game word, press enter. Press back to return to the game.

Guess the Word

In Guess the Word, you must type the missing letters in the mystery word. To read the definition of the mystery word, press ↓, if needed. Press ← or →, if needed, to select a missing letter, and then type the letter that you think belongs there. Continue typing letters until the word is complete or no more tries are left. Or press ? to give up and reveal the word. To see the definition of the game word, press enter. Press back to return to the game. Press space to play a new round.

Word Auction™

In Word Auction, you try to bid on all the letters of a mystery word, before your cash runs out. The amount of each bid depends on the frequency of the letter. All bids will cost you whether correct or incorrect. If you guess the word by revealing all of the letters, your remaining cash is added to the next round. To see the definition of the game word, press enter. Press back to return to the game.

Word Blaster™

In Word Blaster you try to guess the mystery word before all its letters appear. As soon as you know the word press enter. Then type your guess and press enter. If you're wrong, Word Blaster asks you for another word. The speed at which the letters appear is set by the skill level. To see the definition of the game word, press enter. Press back to return to the game.

Making Calculations

1. Press [+ − ÷ ×] until you see the calculator.



2. Type a number.

Note: ***q-p*** will type numbers 0-9 automatically. You can type up to 10 digits. To type a decimal, press ***g*** (.). To change the sign of a number, press ***z*** (+/-).

3. Press a math function key.



4. Type another number.

5. Press enter**.**

To repeat the calculation, press enter again.

6. Press clear **to clear the current calculations.**

To Calculate...	Press...
reciprocals	***a*** (1/x)
squares	***d*** (x^2)
percentages	***f*** **(%)**
square roots	***s*** ($\sqrt{}$ x)
negative numbers	***z*** **(+/-)**

Using the Calculator Memory

1. In the Calculator, make a calculation or type a number.

2. To add the number on the screen to the number stored in memory, press *x* (M+). To subtract the number on the screen from the number stored in memory, press *c* (M-).



M indicates the number is stored in memory.

3. To retrieve the number from memory, press *v* (MR).

4. To clear the memory, press *b* (MC).

Using the Converter

The converter allows you to convert measurements and currency.

Making Metric Conversions

1. **Press [+ − ÷ ×] until you see the Conversions menu.**



2. **Use [↓] to select a conversion category (e.g., *Weights*).**
3. **Select a conversion (e.g., *grams/ounces*).**



4. **Type a number after one of the units.**
   Note: ***q-p*** will type numbers 0-9 automatically. Press [↓] or [↑] to move between the lines. Press (back) to delete a number.
5. **Press (enter) to convert it.**

Making Currency Conversions

1. **Press [+ − ÷ ×] until you see the Conversions menu.**
2. **Press (cap)+[↓] to select *Currency Converter* and then press (enter).**



3. **Enter a conversion rate.**
   The rate should be in units of the other currency per one unit of the home currency (n other/1 home).
4. **Enter an amount for the home or other currency.**
   Press [↓] or [↑]. to move between the lines. Use (back) to delete a number.
5. **Press (enter) to convert it.**

Transferring Words Between Books

This dictionary can transfer words with certain other BOOKMAN book cards. To send a word to another book, you must first install a book card in your product, and that book card must be able to send or receive words in the selected language. To learn if a book card can send or receive words, read its User's Guide.

1. Highlight a word in this dictionary.

To highlight a word in a dictionary entry, press enter to start the highlight, and use the arrow keys to move the highlight to the word you want.

2. Hold fn and press card.

3. Highlight the icon of the other book.

4. Press enter.

The word you highlighted appears in the other book.

5. Press enter again if needed to search for that word.

This unit may change operating modes due to Electrostatic Discharge. Normal operation of this unit can be re-established by pressing the reset key, ⏻, or by removing/replacing batteries.

Resetting Your Product

If the keyboard fails to respond, or if the screen performs erratically, perform a system reset by following the steps below.

1. Hold clear and press ⏻ *(on/off)*.

If nothing happens, try Step 2.

2. Use a paper clip to gently press the reset button on your unit.

The reset button is recessed in a pin-sized hole to the right of the book card slot.

Warning! Pressing the reset button with more than light pressure may permanently disable your product. In addition, resetting product erases settings and information entered in its built-in book, and in an installed bookcard.



Copyrights, Trademarks, and Patents

Model DBE-1440: *Spanish Professor/ Profesor de inglés*

- Batteries: two CR-2032 3 volt lithium
- Size: 13.5 x 9.0 x 1.5 cm
- Weight: 113.4 g

© 2000 Franklin Electronic Publishers, Inc., Burlington, N.J. 08016-4907 USA. All rights reserved.
© 1993 Larousse Bordas
All rights reserved.
FOR HOME OR OFFICE USE.
U.S. Patents 4,490,811; 4,830,618; 4,891,775; 5,113,340; 5,249,965; 5,203,705; 5,218,536; 5,229,936; 4,406,626; 5,295,070; 5,497,474; 5,627,726; 5,396,606; 5,333,313
German Patents: M9409743.7 and M940744.5;
Euro. Pat. 0 136 379
PATENTS PENDING.
ISBN 1-56712-520-4

Limited Warranty (outside U.S.)

This product, excluding batteries, is guaranteed by Franklin for a period of one year from the date of purchase. It will be repaired or replaced with an equivalent product (at Franklin's option) free of charge for any defect due to faulty workmanship or materials.

Products purchased outside the United States that are returned under warranty should be returned to the original vendor with proof of purchase and description of fault. Charges will be made for all repairs unless valid proof of purchase is provided.

This warranty explicitly excludes defects due to misuse, accidental damage, or wear and tear. This guarantee does not affect the consumer's statutory rights.

FCC Notice

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

– Reorient or relocate the receiving antenna.

– Increase the separation between the equipment and receiver.

– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

– Consult the dealer or an experienced radio/TV technician for help.

NOTE: This unit was tested with shielded cables on the peripheral devices. Shielded cables must be used with the unit to insure compliance.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Limited Warranty (U.S. only)

LIMITED WARRANTY, DISCLAIMER OF WARRANTIES AND LIMITED REMEDY

(A) LIMITED WARRANTY. FRANKLIN WARRANTS TO THE ORIGINAL END USER THAT FOR A PERIOD OF ONE (1) YEAR FROM THE ORIGINAL DATE OF PURCHASE AS EVIDENCED BY A COPY OF YOUR RECEIPT, YOUR FRANKLIN PRODUCT SHALL BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP. THIS LIMITED WARRANTY DOES NOT INCLUDE DAMAGE DUE TO ACTS OF GOD, ACCIDENT, MISUSE, ABUSE, NEGLIGENCE, MODIFICATION, UNSUITABLE ENVIRONMENT OR IMPROPER MAINTENANCE. THE SOLE OBLIGATION AND LIABILITY OF FRANKLIN, AND YOUR EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY, WILL BE REPAIR OR REPLACEMENT WITH THE SAME OR AN EQUIVALENT PRODUCT OF THE DEFECTIVE PORTION OF THE PRODUCT, AT THE SOLE OPTION OF FRANKLIN IF IT DETERMINES THAT THE PRODUCT WAS DEFECTIVE AND THE DEFECTS AROSE WITHIN THE DURATION OF THE LIMITED WARRANTY. THIS REMEDY IS YOUR EXCLUSIVE REMEDY FOR BREACH OF THIS WARRANTY. THIS WARRANTY GIVES YOU CERTAIN RIGHTS; YOU MAY ALSO HAVE OTHER LEGISLATED RIGHTS THAT MAY VARY FROM JURISDICTION TO JURISDICTION.

(B) DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITY. EXCEPT FOR THE LIMITED WARRANTIES EXPRESSLY RECITED ABOVE, THIS FRANKLIN IS PROVIDED ON AN "AS IS" BASIS, WITHOUT ANY OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABLE QUALITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR THOSE ARISING BY LAW, STATUTE, USAGE OF TRADE, OR COURSE OF DEALING. THIS WARRANTY APPLIES ONLY TO PRODUCTS MANUFACTURED BY FRANKLIN AND DOES NOT INCLUDE BATTERIES, CORROSION OF BATTERY CONTACTS OR ANY OTHER DAMAGE CAUSED BY BATTERIES. NEITHER FRANKLIN NOR OUR DEALERS OR SUPPLIERS SHALL HAVE ANY LIABILITY TO YOU OR ANY OTHER PERSON OR ENTITY FOR ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, BUT NOT LIMITED TO, LOSS OF REVENUE OR PROFIT, LOST OR DAMAGED DATA OR OTHER COMMERCIAL OR ECONOMIC LOSS, EVEN IF WE HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR THEY ARE OTHERWISE FORESEEABLE. WE ARE ALSO NOT RESPONSIBLE FOR CLAIMS BY A THIRD PARTY. OUR MAXIMUM AGGREGATE LIABILITY TO YOU, AND THAT OF OUR DEALERS AND SUPPLIERS, SHALL NOT EXCEED THE AMOUNT PAID BY YOU FOR THE FRANKLIN PRODUCT AS EVIDENCED BY YOUR PURCHASE RECEIPT. YOU ACKNOWLEDGE THAT THIS IS A REASONABLE ALLOCATION OF RISK. SOME STATES/COUNTRIES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IF THE LAWS OF THE RELEVANT JURISDICTION DO NOT PERMIT FULL WAIVER OF IMPLIED WARRANTIES, THEN THE DURATION OF IMPLIED WARRANTIES AND CONDITIONS ARE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY GRANTED HEREIN.

(C) WARRANTY SERVICE: UPON DISCOVERING A DEFECT, YOU MUST CALL FRANKLIN'S CUSTOMER SERVICE DESK, 1-800-266-5626, TO REQUEST A RETURN MERCHANDISE AUTHORIZATION ("RMA") NUMBER, BEFORE RETURNING THE PRODUCT (TRANSPORTATION CHARGES PREPAID) TO:

FRANKLIN ELECTRONIC PUBLISHERS, INC.
ATTN: SERVICE DEPARTMENT
ONE FRANKLIN PLAZA
BURLINGTON, NJ 08016-4907

IF YOU RETURN A FRANKLIN PRODUCT, PLEASE INCLUDE A NOTE WITH THE RMA, YOUR NAME, ADDRESS, TELEPHONE NUMBER, A BRIEF DESCRIPTION OF THE DEFECT AND A COPY OF YOUR SALES RECEIPT AS PROOF OF YOUR ORIGINAL DATE OF PURCHASE. YOU MUST ALSO WRITE THE RMA PROMINENTLY ON THE PACKAGE IF YOU RETURN THE PRODUCT, OTHERWISE THERE MAY BE A LENGTHY DELAY IN THE PROCESSING OF YOUR RETURN. WE STRONGLY RECOMMEND USING A TRACKABLE FORM OF DELIVERY TO FRANKLIN FOR YOUR RETURN.

IPB-28012-00
P/N 7201930 Rev. A