Questions?

Visit www.nandahome.com or email service@nandahome.com

LIMITED WARRANTY TO ORIGINAL PURCHASER

Nanda LLC ("Nanda") warrants this Nanda-branded hardware product against defects in materials and workmanship under normal use for a period of ninety (90) days from the date of retail purchase by the original end-user purchaser ("Warranty Period"). If a defect in the product is covered by this warranty and the product is returned to Nanda during the Warranty Period, (1) repair the hardware defect at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product, in Nanda's sole discretion. Nanda may require that you require defective parts with new or refurbished user-installable parts that Nanda provides in fulfillment of its warranty obligation. A replacement product or part, including a user-installable part that has been installed in accordance with the instructions provided by Nanda, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Nanda's property.

EXCLUSIONS AND LIMITATIONS

This limited warranty applies only to the product Clocky® manufactured by or for Nanda that can be identified by the "Nanda" name, trademark or logo affixed to the product.

This warranty does not apply: (a) to damage caused by accident, abuse, misuse, tampering with or alteration to the product or any condition whatsoever that are beyond the control of Nanda (b) to damage caused by operating the product outside the permitted or intended uses described in Nanda; or (c) if the product has been opened, Service or repair of this product by anyone other than Nanda voids the warranty.

THERE ARE NO EXPRESS WARRANTIES OTHER THAN THOSE LISTED AND DESCRIBED ABOVE. NO WARRANTIES WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SHALL APPLY AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE, AND NO OTHER EXPRESS WARRANTY OR GUARANTEE GIVEN BY ANY PERSON, FIRM OR CORPORATION WITH RESPECT TO THIS PRODUCT SHALL BE BINDING ON NANDA.

EXCEPT AS PROVIDED IN THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW, NANDA IS NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO LOSS OF USE, LOSS OF REVENUE, LOSS OF ACTUAL OR ANTICIPATED PROFITS, LOSS OF THE USE OF MONEY, LOSS OF BUSINESS, OR LOSS OF OPPORTUNITY. NOR SHALL RECOVERY OF ANY KIND AGAINST NANDA BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE PRODUCT SOLD BY NANDA AND CAUSING THE ALLEGED DAMAGE.

WITHOUT LIMITING THE FOREGOING, PURCHASER ASSUMES ALL RISK AND LIABILITY FOR LOSS, DAMAGE OR INJURY TO PURCHASER AND PURCHASER'S PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF THE USE OF THIS PRODUCT SOLD BY NANDA INSOFAR AS SUCH LOSS, DAMAGE OR INJURY IS NOT CAUSED DIRECTLY BY THE NEGLIGENCE OF NANDA. THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT OR NONTRANSFERABLE AND STATES YOUR EXCLUSIVE REMEDY.

CONSUMER'S PROTECTION LAWS

This warranty gives you specific legal rights, and you may also have other rights which vary under local laws. Any implied warranties required by law shall be limited in duration to the Warranty Period. These implied warranties will continue in force after the expiration of the express warranty. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This above limitations will not apply in case of personal injury where and to the extent that applicable law requires such liability.

ORDERING WARRANTY SERVICE

Please access and review the online resources before requesting warranty service. If the product is still not functioning properly after a reasonable time, thereafter, please contact Nanda for warranty service by emailing service@nandahome.com, or calling toll-free 855-494-2696.

Nanda may send the product to a Nanda repair service location for service by (i) sending you prepaid way bills (and if you no longer have the original packaging, Nanda ships send you packaging material) to enable you to ship the product to Nanda's repair service location, or (ii) by sending you a Nanda-branded, pre-paid shipping container and a replacement product, or parts to enable you to service or exchange your own product ("RZF Service"). Upon receipt of the replacement product or part, the original product or part becomes the property of Nanda and you agree to follow instructions, including, if required, arranging pick-up of the product or part you are returning to Nanda. Nanda will repair or exchange the product or part, using the original product or part, Nanda may require a credit card authorization as security for the retail price of the replacement product or part and applicable shipping costs. If you follow instructions, Nanda will cancel the credit card authorization, so you will not be charged for the product or part and shipping costs. If you fail to return the replaced product or part as instructed, Nanda will charge the credit card for the authorized amount. Service options are subject to change at any time.

© 2006 Nanda LLC. All rights reserved. This product is produced from original artwork. All copyright and trademark rights in this artwork belong to Nanda and may not be reproduced without permission. Nanda, Clocky® is a trademark of Nanda. Distributed by Nanda. nandahome.com. Printed in China. Patent Pending.

- English -

This is a guide for the newest addition to your family, Clocky®, the alarm clock that runs away and hides to get you out of bed. To reduce the risk of injury, prevent loss of warranty, and/or damage to this product, follow these instructions as you welcome Clocky into your home.

Quick start

Install batteries Turn Clocky around and unscrew the battery door using a small screwdriver. Insert 4 Alkaline AAA batteries. Follow the labels printed inside the battery compartment to install the batteries in the right direction.

A just string is used for easy removal of batteries when first needed replacing. Place it as shown when the batteries are first installing.

Select 12 or 24 hour mode To switch between 12 and 24 hour mode, press and hold this ⅊ button for 3 seconds. To distinguish between AM and PM in 12 hour mode, look the presence or absence of PM sign.

Set Time Press the ⅊ button once. The current time screen will begin flashing. Use the ⅊ and ⅊ buttons to increment hour and minutes until the correct time is reached. To increment hours and minutes faster, press and hold the ⅊ or ⅊ buttons. To save and return to normal mode, press the ⅊ button again or wait until the current time screen stops flashing.

Set Alarm Time Press the ⅊ button once. The alarm time screen will begin flashing. Use the ⅊ and ⅊ buttons to increment hour and minutes until the alarm time is reached. To increment hours and minutes faster, press and hold the ⅊ or ⅊ buttons. To save and return to normal mode, press the ⅊ button again or wait until the alarm time screen stops flashing.

Set Snooze Time Press the ⅊ button twice rapidly. The snooze time is set to a 1 minute default. Press the ⅊ button to choose your desired number of snooze minutes 0-9. If 0 is chosen, the snooze button will be disabled. To leave this mode, press the ⅊ button again or just leave the current time screen to return.

Turn Alarm On Press the alarm bell button located on the clock face. A corresponding icon will show up on the screen to indicate that the alarm state is on.

Turn Wheels On Press the wheels button located on the clock face. A corresponding icon will show up on the screen to indicate that the wheels are on.

Alarm
Wheels
Snooze
Time
Set Alarm
Set Time
Snooze
Alarm
Wheels