

## **INSTALLATION INSTRUCTIONS FOR PART 99-9107B**

# **APPLICATIONS**

# Audi A4 / S4 2002-2008

(With Symphony Radio)

# 99-9107B


### KIT FEATURES

- DIN Head Unit Provision with Pocket
- ISO DIN Head Unit Provision with Pocket
- Double DIN Head Unit Provision
- Painted Matte Black to Match Factory



### KIT COMPONENTS

- A) Radio Housing
   B) Pocket
   C) Trim Plate
   D) ISO Brackets
   E) Double DIN Trim Plate
- F) Double DIN Brackets



**1**-800-221-0932 **www.metraonline.com** 



# 99-9107B

# TABLE OF CONTENTS

<u>Dash Disassembly</u>	
- Audi A4 / S4 2002-2008 w/Symphony Radio	1
<u>Kit Assembly</u>	
- DIN Head Unit Provision with Pocket	2
- ISO DIN Head Unit Provision with Pocket	j
- Double DIN Head Unit Provision	4
Final Assembly	1



KNOWLEDGE IS POWER Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.




Metra recommends MECP certified technicians..





### AUDI A4 / 54 2002-2008 W/SYMPHONY RADIO

- 1 Disconnect the negative battery terminal to prevent an accidental short circuit.
- 2 Insert Metra's 86-9001 into the slots in the factory head unit and pull the unit out.
  (Figure A)
- 3 Disconnect the wiring.








### DIN HEAD UNIT PROVISION WITH POCKET

- Snap the DIN cage into the Radio Housing and secure by bending the metal locking tabs down. (Figure A)
- 2 Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter from Metra or AXXESS. Re-connect the negative battery terminal and test the unit for proper operation.
- 3 Snap radio assembly into factory radio opening.
- 4 Slide the aftermarket radio into the cage and secure. (Figure B)
- 5 Snap the pocket into the Radio Housing until secure. (Figure C)

NOTE: Once the dash kit is snapped in, it cannot be removed without dash panel removal












### **ISO DIN HEAD UNIT PROVISION**

- 1 Mount the ISO Brackets to the head unit with the screws supplied with the unit. (Figure A)
- 2 Slide the head unit into the radio opening until the slide clips engage. (Figure B)
- 3 Snap the ISO Trim Plate into the Radio Housing. (Figure B)
- 4 Snap the pocket into the Radio Housing. (Figure C)
- 5 Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter from Metra or AXXESS. Re-connect the negative battery terminal and test the unit for proper operation.
- 6 Snap the radio assembly into the factory radio opening.

NOTE: Once the dash kit is snapped in, it cannot be removed without dash panel removal












### **DOUBLE DIN HEAD UNIT PROVISION**

- 1 Cut and remove center divider from radio housing. (Figure A)
- 2 Snap the DDIN brackets to the inside edge of the radio housing. (Figure B)
- 3 Slide the DDIN radio unit into the DDIN bracket/radio housing assembly and secure the unit to the kit using the screws supplied with the head unit. (Figure C)
- 4 Snap the DDIN trim-plate onto the housing/radio assembly. (Figure C)
- 5 Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter from Metra or AXXESS. Re-connect the negative battery terminal and test the unit for proper operation.
- 6 Snap radio assembly into factory radio opening.

NOTE: Once the dash kit is snapped in, it cannot be removed without dash panel removal









# 99-9107B

# **NOTES**

# 99-9107B INSTRUCTIONS