



EDELBROCK STRUT TOWER BRACE for 1994-2001 Acura Integra GSR

Catalog #5272

INSTALLATION INSTRUCTIONS

Please study these instructions carefully before installing your new Strut Tower Brace. If you have any questions or problems, please contact our Technical Hotline at: 1-800-416-8628, 7:00 am to 5:00 pm, Monday through Friday, Pacific Standard Time or e-mail us at edelbrock@edelbrock.com. Please fill out and mail your warranty card.

Suggested tools needed for installation:

- ☐ Combination wrenches
- ☐ Allen wrenches
- ☐ Sockets both metric and standard

DISASSEMBLY

1. Remove stock brace (if equipped), keep hardware to brace.
2. Unbolt and move throttle bracket away from the firewall. This bracket will be re-used.

ASSEMBLY

1. Remove large nuts on top of the strut tower, install Edelbrock Strut Tower Brace end bracket over studs, using original nuts and the bolts from original strut brace, snug hardware at this time. Brackets are stamped with a part number, left side #25-4054 and right side #25-4055.

2. Install Edelbrock Strut Tower Brace on to the end brackets and align the brace's firewall bracket with the holes in the firewall used for the throttle bracket. Using supplied 3/8 nuts, bolts and washers, bolt brace to the end brackets. Do not tighten bolts at this time. Using the 6 mm bolts and washers supplied, install the throttle bracket and brace to the firewall. Align strut tower brace and tighten all hardware at this time.
3. Check for any interference with the wiring, throttle cable, transmission kickdown cable, and miscellaneous hoses. Check for clearance between strut tower brace and hood before closing hood completely.

PARTS LIST

<u>Qty.</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>	<u>Part #</u>	<u>Description</u>
<input type="checkbox"/> 1	25-4053	Main Strut Tower Brace	<input type="checkbox"/> 2	60-9183	3/8 - 16 Nyloc Nut
<input type="checkbox"/> 1	25-4054	End Bracket (Left)	<input type="checkbox"/> 4	82-5230	3/8 AN washer
<input type="checkbox"/> 1	25-4055	End Bracket (Right)	<input type="checkbox"/> 2	68-0337	6mm bolt
<input type="checkbox"/> 2	68-8472	3/8 - 16 x 2-1/2 bolt	<input type="checkbox"/> 2	82-2895	1/4 flat washer

Edelbrock Corporation
2700 California Street
Torrance, CA 90503

Toll-Free Tech Line: 1-800-416-8628

Office: 310-781-2222

Tech E-Mail: edelbrock@edelbrock.com