

# EDELBROCK AXLE-BACK EXHAUST SYSTEMS For 2005-2008 Ford Mustang GT with 4.6L V8 Catalog #5644 (Aluminized), #5654 (Stainless Steel) INSTALLATION INSTRUCTIONS

Please study these instructions carefully before installing your new Axle-Back Exhaust System. If you have any questions, please contact our **Technical Hotline at: 1-800-416-8628**, 7:00 am to 5:00 pm, Monday through Friday, Pacific Standard Time or e-mail us at **Edelbrock@Edelbrock.com**.

### IMPORTANT NOTE:

Proper installation is the responsibility of the installer. Improper installation will void warranty and may result in poor performance and engine or vehicle damage.

## **Suggested tools needed for installation:**

- □ 13mm & 15mm deep sockets and ratchet
- ☐ Floor jack & jackstands
- □ Penetrating oil

#### **DISASSEMBLY**

- 1. Raise rear of vehicle on flat stable surface and support using jackstands.
- Use penetrating oil on OE clamps that hold mufflers to overaxle pipe. Loosen clamps, remove the stock muffler isolator brackets from frame and remove the stock muffler from vehicle.

#### **ASSEMBLY**

- 1. Install muffler assembly number #25-3233 on driver's side of vehicle using supplied band clamps and the stock muffler isolators and brackets removed in step 2 of disassembly.
- 2. Install muffler assembly #25-3234 on passenger's side of vehicle in the same manner as left muffler.

**NOTE:** The I-pipe /overaxle pipes can be adjusted to obtain better clearance, if needed.

## **WARNING!!!**

Exhaust gas contains carbon monoxide, a deadly invisible gas. Correct any leaks before driving.

## #5644 Parts List

Qty.	Part #	Description
<b>1</b>	25-3233	Muffler Assembly (Left Side)
<b>□</b> 1	25-3234	Muffler Assembly (Right Side)

#### #5654 Parts List

Qty.	Part #	Description
<b>1</b>	25-3243	Muffler Assembly (Left Side)
<b>1</b>	25-3244	Muffler Assembly (Right Side)

Edelbrock Corporation , 2700 California Street, Torrance, CA 90503 Toll-Free Tech Line: 1-800-416-8628 Office: 310-781-2222

Tech E-Mail: Edelbrock@Edelbrock.com