



# EDELBROCK AXLE-BACK EXHAUST SYSTEMS

For 2005-2008 Ford Mustang, 4.0L V6

Catalog #5694 (Stainless Steel)

## INSTALLATION INSTRUCTIONS

Please study these instructions carefully before installing your new Axle-Back Exhaust System. If you have any questions, please contact our **Technical Hotline at: 1-800-416-8628**, 7:00 am to 5:00 pm, Monday through Friday, Pacific Standard Time or e-mail us at [Edelbrock@Edelbrock.com](mailto:Edelbrock@Edelbrock.com).

### IMPORTANT NOTE:

**Proper installation is the responsibility of the installer. Improper installation will void warranty and may result in poor performance and engine or vehicle damage.**

### Suggested tools needed for installation:

- 13mm & 15mm deep sockets and ratchet
- Floor jack & jackstands
- Penetrating oil

## INSTALLATION INSTRUCTIONS

### DISASSEMBLY

1. Raise rear of vehicle on flat stable surface and support using jackstands.
2. Use penetrating oil on OE clamp that hold muffler to overaxle pipe. Loosen clamp, remove the stock muffler isolator brackets from frame and remove the stock muffler from vehicle.

### ASSEMBLY

1. Install muffler assembly number #25-3233 on vehicle using supplied band clamps and the stock muffler isolators and brackets removed in step 2 of disassembly.
2. Install tailpipe tip on outlet of muffler using supplied band clamp.

**NOTE:** The I-pipe /overaxle pipes can be adjusted to obtain better clearance, if needed.

### WARNING!!!

**Exhaust gas contains carbon monoxide, a deadly invisible gas. Correct any leaks before driving.**

### KIT CONTENT

Qty.	Part #	Description
<input type="checkbox"/> 1	25-3233	Muffler Assembly

**Edelbrock Corporation , 2700 California Street, Torrance, CA 90503**

**Toll-Free Tech Line: 1-800-416-8628**

**Tech E-Mail: Edelbrock@edelbrock.com**