Mand

# UNIVERSAL FIT STREET ROD HEADERS For LS Series V8s in Early Street Rods *Catalog #65172 & 65173* INSTALLATION INSTRUCTIONS

Please study these instructions carefully before installing your new Edelbrock Universal Fit LS1 Headers. If you have any questions, please contact our **Technical Hotline at: 1-800-416-8628**, 7am - 5pm, Monday-Friday, Pacific Standard Time or e-mail us at **Edelbrock@Edelbrock.com.** 

**DESCRIPTION:** These headers are designed to improve the exhaust efficiency of the LS series engine and have a universal design to accomodate a wide variety of street rod, musclecar and custom applications.

### **Suggested Tools for Installation:**

- □ SAE and metric sockets, ratchets, and wrenches
- □ Floor jack and load rated jackstands

### **KIT CONTENTS:**

#### #65172

Part Number	Quantity	Description
25-9819	1	Left Side Header
25-9820	1	Right Side Header
25-9677	2	Extension Pipes
22-6517	1	Installation Kit

## IMPORTANT NOTE:

Proper installation is the responsibility of the installer. Improper installation will void warranty and may result in poor performance and engine or vehicle damage.

#### #65173

Part Number	Quantity	Description
25-9817	1	Left Side Header
25-9818	1	Right Side Header
25-9677	2	Extension Pipes
22-6517	1	Installation Kit

## **INSTALLATION PROCEDURE**

- 1. Raise and support vehicle off the ground.
- 2. Remove any existing exhaust manifold and or pipes that will interfere with the installation of the headers.
- Install the headers on to the engine using the supplied gaskets, bolts, and washers. Install all the header bolts in the header before tightening them. Removal of the starter will make header installation easier in some applications.
- 4. Install supplied donut on to the collector outlet of the header.
- 5. Install collector extension pipes on to headers using supplied hardware (*See Figure 1*).



### WARNING!!!

Exhaust gas contains carbon monoxide, a deadly invisible gas. Correct any leaks before driving!

Edelbrock Corporation, 2700 California St., Torrance, CA 90503 Tech Line: (800) 416-8628 Office: (310) 781-2222 E-Mail: Edelbrock@Edelbrock.com