



EDELBROCK AXLE-BACK EXHAUST SYSTEMS

For 2007 Jeep Wrangler 3.8L V6

Catalog #5773

INSTALLATION INSTRUCTIONS

Please study these instructions carefully before installing your new Axle-Back Exhaust System. If you have any questions, please contact our **Technical Hotline at: 1-800-416-8628**, 7:00 am to 5:00 pm, Monday through Friday, Pacific Standard Time or e-mail us at Edelbrock@Edelbrock.com.

Suggested tools needed for installation:

- 13mm & 15mm deep sockets and ratchet
- Floor jack & jackstands
- Penetrating oil

IMPORTANT NOTE:
Proper installation is the responsibility of the installer. Improper installation will void warranty and may result in poor performance and engine or vehicle damage.

INSTALLATION INSTRUCTIONS

DISASSEMBLY

1. Raise rear of vehicle on flat stable surface and support using jackstands.
2. Use penetrating oil on OE clamp that hold muffler to overaxle pipe. Loosen clamp, remove the stock muffler isolator brackets from frame and remove the stock muffler from vehicle.

ASSEMBLY

1. Install muffler inlet pipe onto OE overaxle pipe. Install one of the supplied band clamps and snug the clamp.
2. Install the muffler with a band clamp on the inlet end. Rotate muffler for best ground clearance, and only snug the clamp at this time.

NOTE: The inlet of the muffler is marked.

3. Install a band clamp on the outlet end of the muffler, then insert the outlet pipe into the muffler and slip hanger into factory isolator.
4. Install the tailpipe using the last remaining band clamp.
5. Starting with the overaxle pipe, align and tighten the axle back system for the best clearance around chassis, suspension, and bumper.

KIT CONTENT

Qty.	Part #	Description
<input type="checkbox"/> 1	25-3296	Inlet Pipe
<input type="checkbox"/> 1	25-3297	Outlet Pipe
<input type="checkbox"/> 1	25-5582	Tailpipe Tip
<input type="checkbox"/> 1	25-55721	Muffler

WARNING!!!
Exhaust gas contains carbon monoxide, a deadly invisible gas. Correct any leaks before driving.

Edelbrock Corporation, 2700 California Street, Torrance, CA 90503

Toll-Free Tech Line: 1-800-416-8628

Tech E-Mail: Edelbrock@edelbrock.com