



Catalog #R08463S
Russell DOT Rear Brake Hose Kit
for 2006 Suzuki GSX-R600
INSTALLATION INSTRUCTIONS

Please study these instructions carefully before installing your new Brake Hose Kit. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am to 5:00 pm, Monday - Friday, Pacific Standard Time or e-mail us at **Edelbrock@Edelbrock.com**. Please fill out and mail your warranty card.

IMPORTANT NOTE:

Proper installation is the responsibility of the installer. Improper installation will void warranty and may result in poor performance and engine or vehicle damage.

INSTALLATION PROCEDURE

IMPORTANT NOTE: Do not allow the master cylinder to completely drain of brake fluid at any time during this process. Doing so may require removing the master cylinder from the vehicle for bench bleeding. Also, use care when handling brake fluid, as it can quickly damage finished surfaces (paint, plating, etc.).

1. Remove factory brake hose, noting routing.
2. Install side-bent banjo end of Russell hose onto caliper so that hose is pointed inward (**See Fig. 1**).
3. Install straight banjo end onto master cylinder, clocking so that hose is pointed approximately 45° inward (**See Fig. 2**).
4. Locate hose with two factory mounting points on swingarm.
5. Check hose clearance throughout entire suspension travel range.
6. Bleed system and check for leaks while applying pressure.



Edelbrock Corporation, 2700 California St., Torrance, CA 90503
Tech Line: 800-416-8628
Office: 310-781-2222
E-Mail: Edelbrock@Edelbrock.com