

TORQUE INSTRUCTIONS FOR 09693 NUT

TORQUE NUT TO 50 TO 60 LB-FT



250 SNAP-ON DRIVE PO BOX 1596 MURPHY, NC 28906 USA

250 SNAP-ON DRIVE PO BOX 1596 MURPHY, NC 28906 USA



TORQUE INSTRUCTIONS FOR 09693 NUT

TORQUE NUT TO 50 TO 60 LB-FT



Printed In U.S.A.

Printed In U.S.A.

Printed In U.S.A.

Form Z285

Date 1-98/A

Form Z285 Date 1-98/A

Form Z285 Date 1-98/A





250 SNAP-ON DRIVE ■ PO BOX 1596 ■ MURPHY, NC 28906 ■ USA ■



TORQUE INSTRUCTIONS FOR 09693 NUT

TORQUE INSTRUCTIONS FOR 09693 NUT

TORQUE NUT TO 50 TO 60 LB-FT




250 SNAP-ON DRIVE PO BOX 1596 MURPHY, NC 28906 USA



TORQUE INSTRUCTIONS FOR 09693 NUT

TORQUE NUT TO 50 TO 60 LB-FT





Form Z285 Date 1-98/A

Form Z285

Printed In U.S.A.

Date 1-98/A