INSTRUCTIONS FOR ASSEMBLY AND INSTALLATION

INSTRUCTION SHEET NO. R0391

READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE INSTALLING FIXTURE.

This fixture is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.

Retain these instructions for maintenance reference.

- Thread FIXTURE SCREWS into UNIVERSAL CROSSBAR.
- Secure UNIVERSAL CROSSBAR to OUTLET BOX with OUTLET BOX SCREWS.
- Support BACKPLATE and make connections: Black fixture lead or fixture lead without tracer mark to black supply lead; white fixture lead or fixture lead with tracer mark to white supply lead; fixture ground lead (uninsulated wire) to supply ground lead or other grounding terminal in OUTLET BOX. Use WIRE NUTS (local hardware item). Place connections in OUTLET BOX.
- Position BACKPLATE over FIXTURE SCREWS and secure with BRIDGE KNOBS.
- Lamp with the correct lamp type. 5. **CAUTION:** MAXIMUM WATTAGE MARKED ON FIXTURE MUST NOT BE EXCEEDED.
- 6. Slide one SPACER over each of the (2) SUPPORT STUDS.
- Place protective screen on top of SPACERS. 7.
- Position SCALINI STACKED GLASS ASSEMBLY over the SUPPORT STUDS so the (2) rear SUPPORT STUDS slide up through (2) holes in the GLASS ASSEMBLY.
- 9. Secure GLASS ASSEMBLY by threading the (2) GLASS FASTENERS into the ends of each of the (2) rear SUPPORT STUDS. Do not overtighten.
- 10. Slide END CAP up over BACKPLATE so BOSSES on the inside of the END CAP fit into SLOT in the bottom of the BACKPLATE. Secure by threading HOLDER KNOBS through the holes in side of END CAP.
- 11. To relamp fixture, remove the (2) GLASS FASTENERS and remove SCALINI GLASS ASSEMBLY. Lift protective screen and relamp with recommended lamp. Replace protective screen, SCALINI GLASS ASSEMBLY and GLASS FASTENERS.

