

### INSTRUCTION FOR INSTALLATION KUBIK LIGHT LINEAR FLUORESCENT LUMINAIRE

#### A. POWER SUPPLY:

1. Follow the instructions sheet on the appropriate power supply. (See series ISSL003)

#### B. COVER: (if required)

1. Carefully pull the lamp holder housing out from the channel. (Fig.1)
2. Insert the end of a small slot screwdriver into the slot. (Fig.2)
3. Lift the cover gently all along the channel. (Fig.2)
4. Adjust ball plunger pressure as needed. (Fig.4)

#### To reinstall the cover

1. Align one end of the cover with the block in the channel. (Fig.3)
2. Press the cover along the length of channel. (Fig.3)

#### C. DIRECTION:

1. Follow the instructions Sheet No. ISSL003H.

#### D. LAMP:

(does not apply to the extended blank model no. SL003F)  
**2" and 2-3/4" model**

1. Carefully pull the lamp holder housing out of the channel. (Fig.1)
2. Align the pins of the lamp with the lamp holder(s), and push in until they click. (Fig.5)

#### 13-7/8" model

1. Align the pins of the lamp with the lamp holder, and push in until they click. (Fig.6)
2. Gently push the stem outward and align the of the lamp with the lamp holder, and push together until they click. (Fig.6)

