ASSEMBLY INSTRUCTION

TI

ITEM# 31551

1. Tighten outlet box screw (longer) 2 full turns into mounting strip. Secure with 5/32" nut (to be fully tightened later). The outlet box scew should extend long enough to protrude the canopy when it is mounted.
2. Fasten mounting strip onto outlet box using outlet box screw (shorter).
3. Connect the wires from the fixture to the power supply wires from outlet box. Cover with wire connectors.
   a) Twist together white wire from the fixture with white wire from outlet box. Cover with connectors.
   b) Twist together black wire form the fixture with black wire form outlet box. Cover with connectors.
   c) Wrap the ground wires from the fixture and outlet box around the green ground screw located on the mounting strip. Tighten the green ground screw to the mounting strip.
4. Place the canopy over outlet box. Let heads of outlet box screw (longer) come through the holes of the canopy, then secure by tightening with cap nut.
5. Carefully unpack the glass shade from the box, and put the glass clip on the glass, insert the screw through the hole of the glass . Secure with cap nut.
6. Use the same method screwing the other side of the glass.
7. Install the bulbs (not included)into socket. Do not use greater than 60-watt the bulbs.
8. Restore electric power, and test your new fixture.

NOTE: Carefully remove the fixture from the carton. Check that all parts shown in package parts 1 and parts 2 are included. Be carefully not to misplace any of the screws or wire connectors, which are needed for installing the fixture.

Package parts

Wire connector	2	Glass shade	1
Mounting strip	1	Glass clip	1
Green ground screw	1	Screw	2
5/32" Nut	2		
Outlet box screw	2		
Support screw	2		
Cap nut	2		