Assembly Instructions: 186 CD / 132 DVD MM Tower





Instructions 1) Attach rod (A) to (B), then (G) 2) Place stopper (C) at desired height on all 4 assembled rods. All 4 stoppers must be at the same level. Place shelf on top of stoppers. 3) Follow Step 2 for remaining shelves. 4) Place PP board on each shelf.



U.S. AND OTHER FOREIGN PATENTS PENDING ALL RIGHTS RESERVED MADE IN CHINA R 1.0 040802