

## INSTALL INSTRUCTIONS LOCK FOR LAPTOP COMPUTER C-3090 & C-3490 APPLICATION C-TMLOCK

### TOOLS REQUIRED:

11/32" Socket head w/ratchet

### HARDWARE:

#### QTY: DESCRIPTION:

2 8-32 keps nut zinc plated  
2 8-32 X 1/2" Pem stud zinc plated

#### PART #:

GSM30027  
GSM32201

### INSTALLATION:

1. Remove 8-32 keps nuts that hold down OEM latch on laptop computer mount.
2. Remove Pem studs from laptop computer mount and replace with Pem studs included with C-TMLOCK assembly.
3. Move latch out of way and place C-TMLOCK over Pem studs. Place latch over top of C-TMLOCK.
4. Install keps nuts and tighten.

