



INSTALLATION INSTRUCTIONS MODEL WGI-C14

INTERIOR WINDOW GUARDS

2000-2004 CHEVY TAHOE & GMC YUKON

TOOLS REQUIRED:

Safety goggles
Power drill

Phillips screwdriver
1/8" drill bit

HARDWARE REQUIRED:

<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART #</u>
24	#10 x 1/2" Phillips flat head sheet metal screw	GSM33150
36	#10 x 3/4" Phillips pan head sheet metal screws	GSM33195

INSTALLATION PROCEDURE:

1. Determine the proper cage for each window. Each guard has part number on lower left corner.
2. **Side Passenger Door Windows** – Hold the screen up to the window frame. Make sure you have an even fit. Mark mounting holes and drill out with the 1/8" drill bit. Use #10 x 1/2" flat head sheet metal screws to attach screens to door window frame. **Note: Do not over tighten screws.** After the 1/8" holes are drilled, it is helpful to indent the holes inward with a punch. This will enable the mounting screws to grab better.
3. **Side Cargo Area Windows** – Carefully remove interior plastic trim that surrounds windows. Position window guard into window frame. (Guard will be approximately 1/2" from glass). Drill mount holes in window frame with 1/8" drill bit and attach guard with #10 x 3/4" sheet metal screws. Install interior trim back to original location.
Note: Trim should fit back on without modification, although plastic sometimes needs to be shaved to allow clips to go on properly.
4. **Rear Door Windows** – These guards are mounted the same way as the side cargo windows.

WINDOW GUARD POSITION MODEL WGI-C14

2000-2004 CHEVY TAHOE / YUKON

POSITION #1

DRIVERS
SIDE
PASSENGER
DOOR

C14-1

POSITION #6

PASSENGER
SIDE
PASSENGER
DOOR

C14-6

POSITION #2

DRIVERS
SIDE CARGO
AREA
WINDOW

C14-2

POSITION #5

PASSENGER
SIDE CARGO
AREA
WINDOW

C14-5

POSITION #3
DRIVER SIDE
REAR DOOR

C13-3

POSITION #4
PASSENGER SIDE
REAR DOOR

C13-4