



Manitowoc

K00119 BIN DEFLECTOR KIT

Installation Instructions

NOTE: This kit will convert a C-900/C-950 bin to a C-970 bin or a C-910/C-960 bin to a C-980 bin. This kit is also used on Manitowoc F-style bins, when stacking Q-1300/1600/1800 ice machines.

1. Remove the gasket material along the front and both sides of the bin.
2. Remove the #8 screws holding the current ice deflector. Save these screws – a total of six from a C-900/C-910; a total of eight from a C-950/C-960.
3. Remove the ice deflector.
4. Place new ice deflector in position and use the slots in the side flanges as guidance to drill four 1/8" holes.
5. Fasten the ice deflector using the screws removed in step 2 for the front and the four supplied screws, two each side, for the side flanges. NOTE: C-900/C-910 only – use additional two screws, shipped with the new ice deflector, on the front.
6. Install the new gasket material along the front and sides of the bin.

