

KENWOOD

SK-SYTL1

MOBILE VIDEO CONSOLE

INSTRUCTION MANUAL

**FOR USE WITH KENWOOD MOBILE
VIDEO PRODUCTS**

2000-up Chevy Suburban

2000-up GMC Yukon/XL

2000-up Chevy Tahoe

2001-up Chevy Avalanche

1999-up GM Ext.Cab Trucks.

KENWOOD CORPORATION

**Take the time to read through this instruction manual.
Familiarity with installation and operation procedures
will help you obtain the best performance from your
new mobile video system.**

Installation

Accessories

2 - #8-32 Inserts
(KMSI832)



1 - Monitor Bracket
(KMB701)



2 - #8-32 x 1/2"
Black Machine Screw
(KMSB832.5)



2 - 1/4-20 Star Nut
(KSN1420)



Remove Factory Console

Open the console lid and remove the (2) screws toward the rear of the console. Fold down the cup holder on the rear of the console until it hits the stops. Continue to push down on the cup holder snapping it past the stops. Remove the (2) screws inside the cup holder recess. Unsnap the rear portion of the console and disconnect wiring. The rear radio controls (if equipped) will be relocated to the Q-View console.

The power point can be relocated to the optional factory mounting location inside the console storage bin if so desired. (see picture at right)

NOTE: If installing into truck with console mounted air vents follow these instructions.

Remove the remaining five screws around the top edge of the console storage bin. Remove the four 10mm bolts in the bottom of the storage bin. Gently lift up and remove the bin. Pull out and remove the Y-shaped portion of the AC ductwork. Block off the ductwork near the front of the console and replace the console storage bin.

Prepare Video Console

Radio Control Unit Re-Installation:

Fit the previously removed rear radio control box into the video console. If the vehicle was not equipped with rear radio controls, fit the supplied color-matched filler plate into the recessed area and secure with the (2) supplied #8 x 1/2" sheet metal screws through the predrilled holes into the plastic housing.



Factory Console



Optional Power Port Location

Wiring and Connections

Route all wires and cables at this time. Install wiring and cables according to the instruction provided with electronic equipment. Run all cable for external video sources at this time.

Installation of Video Console

Prepare the monitor for installation by sliding the small studded bracket into the back panel of the monitor. Run the monitor data cable through the rectangular-shaped hole in the video console and connect to the monitor. Slide the monitor into the console and secure using the (2) supplied star nuts. (Do not overtighten)

Slide the metal bracket on the video console into place between the storage bin and the console and snap into place (Make sure that no cables are pinched). Make a mark on the console using the pre-drilled hole on each side towards the bottom of the video console as a guide. Remove the video console and install one of the supplied metal inserts into the oblong hole on each side of the console, at the mark previously made.)

Re-connect the factory harness to the rear radio control unit. Re-install the video console and secure with (2) supplied #8-32 x 1/2" machine-thread screws through the pre-drilled holes in the plastic housing into the threaded inserts (Do not overtighten). Replace the two factory screws under the console lid towards the rear of the console.



Install Threaded Inserts

Final Steps

Re-install all previously removed factory components and panels.

Turn on and test everything. (If system does not work properly, recheck all connections and fuses).

The installation of your new Video System is now complete.

