

K00117 ADAPTER KIT

Installation Instructions

- 1. Use the K00117 to install a 22" B, J, Q, S, and Flaker/Chip ice machines on a Manitowoc C-730 bin.
- 2. Installation (bin to be level before starting):
 - A. Remove the hinge on the right and left side of the bin.
 - B. Remove the foam tape on the right and left rail. Trim back the foam tape on the front and rear bin rails, as shown.
 - C. Position the adapter panels and hinges on bin and fasten with the four existing hinge screws.
 - D. Using the adapters as templates, drill four 5/32" (4 mm.) holes, .500" (12.7 mm.) deep maximum, in the rear of the bin (adapters must be level with bin). **Warning: Do not drill through interior liner.** Attach with the screws provided.
 - E. Apply foam tape to the edge of the adapters, as shown. Note: We recommend using RTV at intersections and along front inside edge of foam tape to prevent water tracking. Use double thickness with S-series ice machines.
- 3. Refer to ice machine installation manual for ice machine installation procedures.

