

Setup Instructions

Universal Clamp

Style Series: 8001

Description

A quick solution when an umbrella receptacle is not available.

Product Contains

- [1] Hose Clamp
- [1] Black Block with thumb screw

INSTRUCTIONS

NOTE: The Bracket Hose Clamp comes in a variety of sizes up to 8" which is adaptable to most shapes and can be purchased at your local automotive supply or hardware stores. (Ideal or Dixon clamps work best)

1. The hose clamp is to slide completely around the front section of the lighting unit.
2. When in place, insert the Bracket under the Hose Clamp (In the Harness Position)
3. Use a screwdriver to then tighten. Finally, insert umbrella shaft through mount until desired position is established, then tighten Set Screw Knob.

NOTE: When attaching to a portable Strobe, follow the above instructions for assembly and choose the required Hose Clamp size for your Strobe.

