



At home out there

### **WINDSOR 390**

1. Slide bag into awning rail on caravan and then screw in end stops (wing nuts) provided. Release bag and unfold awning – make sure you check first to make sure it will unfold in the correct direction. Then ensure all zips are closed and that all the adjustment straps attached to the flysheet are slackened off to give the maximum slack
2. Put together all 4 fibreglass poles and then feed each through the black pole sleeve, rubber end first, from the floor towards the caravan making sure the top end fits into the pocket at the end of the sleeve and then locate the end of each pole into the corresponding pin and ring on the pole anchor straps – this will require a little effort - and tension the pole end straps. Peg out the awnings through the rings and straps with the pegs supplied
3. Put together the 2 steel poles and take inside the awning – fit lengthways along the inside of the awning roof so each end fits into the pocket and once in the desired position tighten the screw so pole is rigid, repeat for both poles then tie with cross over tags attached to secure in place.
4. Peg out all anchor straps and guylines to stabilise awning.
5. Remaining steel poles join to make two door poles. Assemble when required and use to hold open any of the front panels if required so that you can move freely in and out of your awning.

**DO NOT KEEP POLES IN BAG ON SIDE OF VAN – POLES MUST BE STORED IN SEPARATE BAG PROVIDED**