Applicable Vehicles for Airbag Resetting

Manufacturer	Models	Remark
HONDA	Accord 2.2 (CD5)	
	Accord 2.3	
	2002 Accord 2.4	
	Odyssey	
	CRV	
	SV4-A91	
	SV4-A92	
	SV4-A93	
	S84-A84	
	S84-A86	
	S3N-N93	
	SXO-A84	
	Y614	
	Y615	
	Y630	
ΤΟΥΟΤΑ	2002 Camry	
	2002 Camry 2.4	
	VC-52180	
	VZ-52180	
	33100	
	33260	
	52120	
	60110	
NISSAN	Cefiro 2001	
	Bluebird	Non-standard IC
	209M000	

@2006 UIF Technology CO.,LTD.

www.uiftech.com

	7M806	
	A33	
	3L400	
	3L405	
	4Y715	
	Sunny	Non-standard IC
	Paladin	Non-standard IC
MITSUBISHI	MB942715	
	268157	
	268154	
	942715	
	Outlander	
	Pajero Sport (MR587804)	
HYUNDAI	ELANTRA	
	SONATA.	
VW	JETTA	
	SANTANA	
	AUDI	
	GOL	
	GOLF	VW3/VW5/VW6
	PASSAT	airbags reset by K-line or OBD-II line
	Superb	
	Octavia	
	Fabia	
	BORA	
	POLO	
GM	GL8	
	Regal	
	Excelle	

@2006 UIF Technology CO.,LTD.

www.uiftech.com

	SAIL	
MAZDA	B30E57K30B	
	M6(Double)	
	M6(GJ6a57K30c, 6 airbags)	
	Premacy (C17657K30b)	
FORD	MONDEO	

Resetting Vehicles not Listed

This is a very important feature! There are so many airbag models in the world that it is impossible to get airbag data for all airbag models. With this function, user can perform airbag resetting for most vehicles not listed in the above table by the following simple steps. This function is applicable to vehicles use chip model 93C46, 93C56, 93C66, 24C01A, 24C04, 24C08, 25160, 25320, 95080, and nonstandard 93C46.

1.To reset an airbag not listed in the above table, you just need to find a good airbag with same type;

2.Install the good airbag chip onto the adapter, and connect the adapter to this item;

3.Select chip type and press F1 key. This item will read and save the data of the good airbag chip automatically;

4.Take out the good airbag chip and insert the crashed airbag chip onto the adapter, and then press F2 key. This item will write the stored data into the crashed airbag chip automatically.

User's Manual Download

To have a good understanding of this item, please download the PDF File User's Manual