

SMART
POWER DESIGN



SMART
POWER
DESIGN

DOOR HANDLE RIM AND
COVER KIT SMART FORTWO
450

User Manual | Smart Power Design

Door Handle Rim and Cover Kit Smart Fortwo 450



Photo 1: Door Handle Rim and Cover Kit Smart Fortwo 450

Instructions

1. Firstly, check that the Rim and/or the Cover fit(s) fit to each Door Handle. Please note that you must not remove the protective adhesive tape yet.
2. Secondly, you should clean the Door Handle Rims and Cover and the areas that they are going to cover from the dirt and the dust.

3. The air temperature must be more than 20 C. The temperature of the car's surface must be the same as well.
4. Finally, remove the adhesive tape and attach the Rims and/or the Covers carefully. For the following three (3) days do not wash the car and do not drive in the rain.

Enjoy what you have just installed. We hope that you are not going to like it but to love it as it fits perfectly on your lovely Smart Fortwo 451.



We would like to thank you for purchasing from Smart Power Design a company specialized in Smart Tuning and Accessories.

If you have any problem or questions feel free to contact us via email at: info@smart-power-design.de or sales@smart-power-design.com or via telephone at: 0049-711-217-20291.



Company Information

Smart Power Design
Möhringer Str. 93 – Stuttgart
Zip: 70199 – Germany

Email: info@smart-power-design.de
sales@smart-power-design.de

Telephone: 0049 711 217 20291

Website: www.smart-power-design.de

Follow us

