

# Ni-NTA Agarose User Manual

384 Oyster Point Blvd, Suite 15 South San Francisco, CA 94080 Phone: 1 (888) MCLAB-88

Fax: 1 (650) 872-0253

www.mclab.com

# Contents

Introduction	3
Cell Lysates Preparation	-3
Insect Lysate Preparation	4
Mammalian Cell Lysate Preparation	5
Protein Purification—Native Conditions	5
Protein Purification—Denaturing Conditions	6
Protein Purification—Hybrid Conditions	7
Recharging Ni-NTA Resin	7
Recipes	8
Troubleshooting	- 9

Revised December 2011

#### Ni-NTA Purification

MCLAB Ni-NTA agarose beads are designed for high quality purification of 6xhis-tagged recombinant proteins from bacteria, insect and mammalian cells. Ni-NTA agarose beads are widely used for protein purification due to its high affinity and selectivity for recombinant fusion proteins that are tagged with six tandem histidine residues. Furthermore, the method of purification is easy and simple to use.

Proteins of interest can be purified under native, denaturing, or hybrid conditions. Elution of proteins bound to Ni-NTA resin through low pH buffer or competitive binding of molecules such as imidazole can be used.

#### **Native Versus Denaturing Conditions:**

Purify under native conditions if your protein of interest is soluble in the supernatant after lysis and preservation of protein activity is integral for downstream applications.

Purify under denaturing conditions if your protein of interest is insoluble in the supernatant after lysis or protein activity is not important.

Purify under hybrid protocol if your protein of interest is insoluble in the supernatant after lysis, but protein activity is important. Prepare lysate and columns under denaturing conditions. Use native buffers for wash and elution steps for protein refolding. Note that this is a general protocol and may not work for all proteins.

# Cell Lysates Preparation

#### Materials:

Buffer Recipes can be found on page 9

- Native Binding Buffer for lysates preparation under native conditions
- Sonicator
- 10 μg/ml RNase and 5 μg/ml Dnase I
- Centrifuge
- Sterile, distilled water
- SDS-PAGE sample buffer
- Guanidinium Lysis Buffer for lysates preparation under denaturing conditions
- Lysozyme for bacterial cell lysates preparation
- Bestatin or leupeptin for mammalian cell lysates preparation

The following instructions for lysate preparation and purification can be scaled up or down depending on user's preference. This manual exemplifies lysate preparation from a specific amount of starting material and purification using 2 ml resin.

# Bacteral Cell Lysate Preparation¬—Native Conditions

- Harvest bacterial cells from a 50 ml culture through by centrifugation at 5000 rpm for 5 minutes. Resuspend pellet in 8 ml of Native Binding Buffer.
- Add 8 mg lysozyme and incubate on ice for 30 minutes.
- Sonicate solution on ice with a microtip, using six 10-seconds bursts at high intensity with a 10-second cooling period between each burst.
- Optional: If lysate is very viscous, add RNase A (10 μg/ml) and Dnase I (5 μg/ml) and incubate for 10-15 minutes on ice.
- Pellet down cellular debris in lysate through a 15 minutes centrifugation at 3,000 x g. Supernatant should then be transferred to a new container.
- Prepare 5 μl of lysate for SDS-PAGE analysis and store the remaining on ice or frozen at –20 °C for later use.

#### **Bacterial Cell Lysate Preparation—Denaturing Conditions**

- Equilibrate the Guandinium Lysis Buffer, pH 7.8 to 37 °C.
- Harvest bacterial cells from a 50 ml culture through by centrifugation at 5000 rpm for 5 minutes. Resuspend pellet in 8 ml of Guanidinium Lysis Buffer.
- Mix the cells gently for 5-10 minutes at room temperature for thorough cell lysis.
- Sonicate solution on ice with a microtip, using three 5-seconds bursts at high intensity.
- Pellet down cellular debris in lysate through a 15 minutes centrifugation at 3,000 x g. Supernatant should then be transferred to a new container.
- Prepare 5 μl of lysate for SDS-PAGE analysis and store the remaining on ice or frozen at –20 °C for later use.

Note: Samples containing Guanidinium Lysis Buffer need to be diluted, dialyzed or TCA precipitated prior to SDS-PAGE to prevent SDS precipitation.

# Insect Lysate Preparation

The following protocols are for baculovirus-infected cells and are intended to be generic. They should be optimized for your specific cell lines.

Large scale protein expression should be carried out when the time point of maximal expression has been determined. Generally, protein expression is performed in 1 liter flasks seeded with cells at a density of 2 x 106 cells/ml in a total volume of 500 ml. The cells are infected with high titer viral stock at an MOI of 10 pfu/cell. At maximal expression, cells are harvested in 50 ml aliquots and pellet down by centrifugation and stored at –70 °C until needed.

# **Insect Cell Lysate Preparation—Native Conditions**

- Prepare 8 ml Native Binding Buffer containing 0.5 µg/ml of leupeptin.
- Harvest bacterial cells from a 50 ml culture through by centrifugation at 5000 rpm for 5 minutes. Resuspend pellet in 8 ml of Native Binding Buffer containing 0.5 µg/ml of leupeptin.
- Cells are lysed by freezing and thawing using liquid nitrogen or dry ice/ethanol bath and a 42 °C water.
- Shear the DNA by passing the lysate through an 18-gauge needle four times.
- Pellet down cellular debris in lysate through a 15 minutes centrifugation at 3,000 x g. Supernatant should then be transferred to a new container.
- Prepare 5 µl of lysate for SDS-PAGE analysis and store the remaining on ice or frozen at -20 °C for later use.

#### **Insect Cell Lysate Preparation—Denaturing Conditions**

- Harvest bacterial cells from a 50 ml culture through by centrifugation at 5000 rpm for 5 minutes and resuspend pellet in 8 ml Guanidinium Lysis Buffer.
- Pass lysate through an 18-gauge needle four times.
- Pellet down cellular debris in lysate through a 15 minutes centrifugation at 3,000 x g. Supernatant should then be transferred to a new container.
- Prepare 5  $\mu$ I of lysate for SDS-PAGE analysis and store the remaining on ice or frozen at -20 °C for later use. Note: Samples containing Guanidinium Lysis Buffer need to be diluted, dialyzed or TCA precipitated prior to SDS-PAGE to prevent SDS precipitation.

# Mammalian Cell Lysate Preparation

The following protocols for mammalian expression are intended to be generic and should be optimized for your specific cell lines.

Expression of your specific recombinant protein requires between  $5 \times 106$  and  $1 \times 107$  cells. Seed and grow the cells in the appropriate medium until they are 80-90% confluent. Trypsinization is used to harvest the cells. Freeze cell pellet in liquid nitrogen and store at -70 °C for later use.

#### **Mammalian Cell Lysate—Native Conditions**

- Resuspend cell pellet in 8 ml Native Binding Buffer containing protease inhibitors such as bestatin and leupeptin if necessary (this depends on the cell line and expressed protein).
- Cells are lysed by freezing and thawing using liquid nitrogen or dry ice/ethanol bath and a 42 °C water.
- Shear the DNA by passing the lysate through an 18-gauge needle four times.
- Pellet down cellular debris in lysate through a 15 minutes centrifugation at 3,000 x g. Supernatant should then be transferred to a new container.
- Prepare 5 µl of lysate for SDS-PAGE analysis and store the remaining on ice or frozen at -20 °C for later use.

# **Mammalian Cell Lysate Preparation—Denaturing Conditions**

- Resuspend cell pellet in 8 ml Guanidinium Lysis Buffer.
- Shear the DNA by passing the lysate through an 18-gauge needle four times.
- Pellet down cellular debris in lysate through a 15 minutes centrifugation at 3,000 x g. Supernatant should then be transferred to a new container.
- Prepare 5  $\mu$ I of lysate for SDS-PAGE analysis and store the remaining on ice or frozen at -20 °C for later use. Note: Samples containing Guanidinium Lysis Buffer need to be diluted, dialyzed or TCA precipitated prior to SDS-PAGE to prevent SDS precipitation.

#### **Protein Purification—Native Conditions**

Protein purification should be used with prepared Native Binding, Wash, and Elution buffers, columns and cell lysate under native conditions.

#### Materials:

Buffer Recipes can be found on page 9

- 3 M imidazole
- NaOH
- HCI
- Prepared Ni-NTA columns with native buffers
- Sterile, distilled water
- Native Purification Buffer
- Lysate prepared under native conditions

Note: Do not use strong reducing agents or strong chelating agents. These agents, such as DTT, EDTA or EGTA reduce nickel ions in the resin or strip the nickel from the columns.

# **Ni-NTA Column Preparation**

- Resuspend Ni-NTA agarose slurry in the bottled container.
- Pipet 1.5 ml slurry into a 10 ml purification column and allow resin to settle by gravity.
- Add 6 ml of sterile distilled water and resuspend resin.
- Let the resin settle by gravity and gently aspirate the supernatant.
- Add 6 ml of Native Binding buffer for purification under Native Conditions.
- Resuspend resin and Let the resin settle by gravity.
- Gently aspirate the supernatant.
- Repeat step 5 through 7.

Note: Prepared column containing resin can be stored at room temperature with the addition of 0.02% azide or 20% ethanol and capped or parafilmed.

# **Protein Purification—Native Conditions Protocol**

- Add 8 ml of lysate prepared under native conditions to a prepared Purification Column containing resin.
- Allow binding to take place for 30-60 minutes with gentle agitation to keep resin suspended in the lysate solution.
- Let resin settle by gravity and gently aspirate and save the supernatant at 4 °C for SDS-PAGE analysis.
- Wash resin with 8 ml of Native Wash Buffer. Allow resin to settle by gravity and carefully aspirate and save the supernatant at 4 °C for SDS-PAGE analysis.
- Repeat Step 4 three more times.
- Elute protein with 8-12 ml of Native Elution Buffer. Collect eluate in 1 ml fractions and analyze on SDS-PAGE. Note: Eluted fractions can be stored at 4 °C. Add glycerol to the fractions if –20 °C storage is required. Protease inhibitors should be added for long term storage.

Resins can be used again for purification of the same recombinant protein. Wash resin with 0.5 M NaOH for 30 minutes and resuspend in a suitable binding buffer. Refer to page 8 to recharge resin.

# **Protein Purification—Denaturing Conditions**

Protein purification should be used with prepared Denaturing Binding, Wash, and Elution buffers, columns and cell lysate under denaturing conditions.

#### **Materials**

- Prepared Ni-NTA Agarose with denaturing buffers
- Cell Lysate prepared under denaturing conditions
- Denaturing Binding Buffer
- Denaturing Wash Buffer,
- Denaturing Elution Buffer

# **Ni-NTA Column Preparation**

- Resuspend Ni-NTA agarose slurry in the bottled container.
- Pipet 1.5 ml slurry into a 10 ml purification column and allow resin to settle by gravity.
- Add 6 ml of sterile distilled water and resuspend resin.
- Let the resin settle by gravity and gently aspirate the supernatant.
- Add 6 ml of Native Binding buffer for purification under Denaturing Conditions.
- Resuspend resin and Let the resin settle by gravity.
- Gently aspirate the supernatant.
- Repeat step 5 through 7.

Note: Prepared column containing resin can be stored at room temperature with the addition of 0.02% azide or 20% ethanol and capped or parafilmed.

# **Protein Purification—Denaturing Conditions Protocol**

- Add 8 ml of lysate under denaturing conditions to a prepared Purification Column containing resin.
- Allow binding to take place for 15-30 minutes with gentle agitation to keep resin suspended in the lysate solution.
- Let resin settle by gravity and gently aspirate and save the supernatant at 4 °C for SDS-PAGE analysis.
- Wash resin with 4 ml of Denaturing Binding Buffer. Allow resin to settle by gravity and carefully aspirate and save the supernatant at 4 °C for SDS-PAGE analysis.
- Wash resin with 4 ml of Denaturing Wash Buffer, pH 5.3. Allow resin to settle by gravity and carefully aspirate and save the supernatant at 4 °C for SDS-PAGE analysis. Repeat this step one more time.
- Add 5 ml of Denaturing Elution buffer to elute protein. Collect 1 ml fractions of eluate and measure OD280 readings. Pool fractions with highest absorbance together and dialyze against 10 mM Tris, pH 8.0, 0.1% Trition X-100 overnight to remove urea. Dialyzed material can be concentrated through any standard method such as, using vacuum concentration instruments.

Resins can be used again for purification of the same recombinant protein. Wash resin with 0.5 M NaOH for 30 minutes and resuspend in a suitable binding buffer. Refer to page 8 to recharge resin.

# Protein Purification—Hybrid Conditions

Under certain circumstances in which your protein is insoluble and protein activity is integral, the following protocol can be used. This procedure is meant to be generic and will not work for all proteins.

#### **Materials**

Buffer Recipes can be found on page 9

- Cell lysate preparation under denaturing conditions
- Purification columns containing Ni-NTA resins prepared under denaturing conditions
- Denaturing Binding Buffer
- Denaturing Wash Buffer
- Native Wash Buffer
- Native Elution Buffer

#### **Ni-NTA Column Preparation**

Purification Columns should be prepared under denaturing conditions

## **Protein Purification—Hybrid Conditions Protocol**

- Add 8 ml of lysate under denaturing conditions to a prepared Purification Column containing resin.
- Allow binding to take place for 15-30 minutes with gentle agitation to keep resin suspended in the lysate solution.
- Let resin settle by gravity, aspirate and save the supernatant at 4 °C for SDS-PAGE analysis.
- Resuspend resin with 4 ml of Denaturing Wash Buffer, pH 6.0 for two minutes. Let resin settle by gravity, aspirate and save supernatant at 4 °C for SDS-PAGE analysis.
- Resuspend resin with 8 ml of Native Wash Buffer for two minutes. Let resin settle by gravity, aspirate and save supernatant at 4 °C for SDS-PAGE analysis.
- Elute with 8-12 ml Native Elution Buffer. Collect 1 ml fractions and analyze on SDS-PAGE.

Resins can be used again for purification of the same recombinant protein. Wash resin with 0.5 M NaOH for 30 minutes and resuspend in a suitable binding buffer. Refer to page 8 to recharge resin.

# Recharging Ni-NTA Resin

# Ni-NTA resin can be recharged following the procedures below:

- For 1 ml of resin, wash with 2 ml of 7 M GuHCl.
- Wash resin with 5 ml of deionized water.
- Wash resin with 3 ml of 2% SDS.
- Wash resin with 5 ml of deionized water.
- Wash resin with 5 ml of 100% EtOH
- Wash resin with 5 ml of deionized water.
- Wash resin with 5 ml of 100 mM EDTA (pH 8) to strip Ni+2 ions.
- Wash resin with 5 ml of deionized water.
- Wash resin with 5 ml of 100 mM NiSO4.
- Wash resin with 10 ml of deionized water.
- Preserve resin in 0.02% azide or 20% ethanol.

Recipes 10x Stock Solution A 200 mM sodium phosphate, monobasic
10x Stock Solution B200 mM sodium phosphate, dibasic
5x Native Purification Buffer250 mM sodium phosphate, monobasic
*Adjust pH of solution to pH 8.0 before filling to 200 mL
3 M Imidazole pH 6.0 3 M imidazole
Native Binding Buffer 5x Purification Buffer 6 mL 3 M Imidazole, pH 6.0 100 μL Adjust pH to 8.0 Deionized water to 30 mL
Native Wash Buffer  5x Purification Buffer 10 mL  3 M Imidazole, pH 6.0 335 μL  Adjust pH to 8.0  Deionized water to 50 mL
Native Elution Buffer  5x Purification Buffer

# **Guanidinium Lysis Buffer**

Adjust pH to 8.0

Guanidine Hydrochloride 57.3 g	
10x Stock Solution A 0.58 ml	L
10x Stock Solution B 9.42 ml	L
Adjust pH to 7.8	
Deionized water to 100 ml	_

Deionized water to...... 15 mL

Filter sterilize using 0.45  $\mu m$  filter.

# **Denaturing Binding Buffer**

Urea	48.1 g
10x Stock Solution A	. 0.58 mL
10x Stock Solution B	9.42 mL
Adjust pH 7.8	
Deionized water to	100 mL

Filter sterilize using 0.45 µm filter

# **Denaturing Wash Buffer**

Urea	48.1 g
10x Stock Solution A	. 7.38 mL
10x Stock Solution B	. 2.62 mL
Adjust pH to 6.0	
Deionized water to	. 100 mL

Filter sterilize using 0.45  $\mu m$  filter

# **Denaturing Elution Buffer**

Urea 48.1 g	
10x Stock Solution A 10 mL	
Adjust pH to 4.0	
Deionized water to 100 mL	-
Adjust pH to 4.0	-

Filter sterilize using 0.45 µm filter

# **Troubleshooting**

Problem	Cause	Solution
His-tagged protein is present in flow through and wash fractions	Protein overload	Load less protein or use more resin
Purified protein is contaminated with unspecific proteins	Wash steps are not stringent enough	Lower pH or include higher amount of imidazole. Resin can be washed more.
Protein of interest is not present after elution	Not enough sample loaded     Expression levels too low     Protein has high affinity for Ni-NTA	Load more amount of sample     Optimize expression levels following the guidelines provided in your expression manual Lower pH in elution buffer or increase imidazole content.