

## **710 Pen ARK Vaporizer – Instructions**

### **BATTERY INSTRUCTIONS**

**NOTE:** All batteries come in the OFF position.

**Step 1:** Press button 5 times rapidly to unlock/lock.

**Step 2:** Charge battery for 3-5 hours before use. While charging the light on the USB will be red and the battery light will be on when it is fully charged.

**Step 3:** When USB Indicator Light turns green, and the tip of battery turns off, the battery can be detached from the charger.

### **HOW TO USE SLIM KIT**

**Step 1:** Screw dry herb/waxy oil cartridge onto battery.

**Step 2:** Remove mouthpiece from the dry herb/waxy oil cartridge.

**Step 3:** With 710 T1 Tool, fill the dry herb/waxy oil cartridge with dry herbs or waxy oil.

**Step 4:** Attach mouthpiece back onto cartridge.

**Step 5:** Press and hold button on the battery.

**Step 6:** Prime battery until light flashes, then release the button.

**Step 7:** When flashing stops, hold the button and inhale.

**Step 8:** Repeat Step 7 for continual use.

**Step 9:** Device will automatically shut off if the button is held longer than 15 seconds.

### **HOW TO USE CERAMIC HERB CHAMBER (RETRO KIT)**

**Step 1:** Remove the chamber connector and mouthpiece from ceramic heating chamber.

**Step 2:** Insert onto screen inside of the ceramic heating chamber.

**Step 3:** Place your herbs on top of the screen.

**Step 4:** Screw the chamber connector and mouthpiece back into the ceramic heating chamber.

**Step 5:** Hold the Power button down for 2 seconds and then start inhaling slowly and steadily for no longer than 7 seconds.

**Step 6:** Release the power button for 3 seconds and repeat as desired.

### **HOW TO USE E-LIQUID TANK (RETRO & NANO KIT)**

**Step 1:** Remove mouthpiece from the cartomizer.

**Step 2:** Slowly fill your e-liquid.

**Step 3:** Attach mouthpiece back onto cartomizer.

### **HOW TO USE GLOBE ATOMIZER (RETRO & NANO KIT)**

**Step 1:** Remove Glass Globe from atomizer and screw on your desired cartridge.

**Step 2:** Place your wax or herb into cartridge.

**Step 3:** Attach Glass Globe back on to atomizer.