



800.604.6766

# HealthyHabitsWeb.com

## **QUICK START**

- 1. Open your lonPod® & remove the top mineral cartridge, inspection slip and/or pH reagent.
- 2. Replace the mineral cartridge.
- 3. Add hot water to your lonPod®. Replace the cap and shake.
- 4. Repeat the hot water rinse until the water runs clear, not cloudy.

### Your IonPod® is now ready to use. Leave the top mineral cartridge in place.

- Fill your IonPod® with water.
- Replace the cap.
- Wait approximately 5 minutes.
- Turn your IonPod® upside-down a few times during the 5 minutes.
- Enjoy your healthy alkaline, antioxidant water!

IonPod® water may be transferred to another container for drinking or short term storage. The IonPod® will alkalize hot, cold, regular or purified water.

#### You may use the following methods to determine water pH. pH reagent drops (May be provided.)

**Water pH Testing** 

1. Make IonPod® water according to the aforementioned instructions on pg 2.



pH CHART

- 2. Pour the specified amount of IonPod® water into a seperate container.
- 3. Add the specified amount of pH reagent to the test water. Do not add reagent to the IonPod®. 4. Match the color of the water to the pH color chart provided with the test
- strips. Discard water after test. IonPod® Cautions

#### 1. First time users should start with 10 oz daily and gradually increase to standard daily consumption.

- 2. Kidney or Liver stressed people should consult their healthcare professional prior to using the IonPod®.
- 3. Prescription drug users should not use IonPod® water to take drugs & should wait at least one hour before or after taking drugs before consuming IonPod® water.
- becomes uncomfortable.

4. As you begin consuming alkaline water your body may begin to cleanse. Please decrease consumption or stop using if this cleansing process



## **Monthly White Vinegar Cleaning Method:**

#### 2. Add 2-3 tablespoons of white vinegar & 4 oz of water to a separate container.

1. Remove the cap & leave off while cleaning.

3. Pour the vinegar solution through the top mineral

1. Rinse the IonPod® & mineral cartridge with hot water.

- cartridge and swirl in the IonPod® for 10 seconds (without the cap).
- 4. Remove top mineral cartridge & pour vinegar solution into a separate container. 5. Replace mineral cartridge & repeat until the white film
- and/or particles, disappear. 6. Rinse mineral cartridge & IonPod® with large amounts of clean water until no vinegar odor remains.

Questions, comments or ordering replacement mineral cartridges:

www.HealthyHabitsWeb.com

