



# Turn Signal Harness Adapter Install

(For Modern Classics) BC501-009-PR



### Kit Includes:

- 1. 2x Turn Signal Harness

### Fits The Following Motorcycles:

- Triumph Bonneville (01-Present)
- Triumph Scrambler 900 (06-Present)
- Triumph Thruxton 900 (04-Present)
- Triumph America (02-Present)
- Triumph Speedmaster (03-Present)

### Tools Required:

- Phillips Screwdriver
- 14mm & 17mm open end wrench

**WARNING:** Laws concerning this product vary from state/province to state/province. Your state/province may prohibit its use on public roads or restrict its use to novelty, show use, off-road areas, or race facility areas only. In some states/provinces off-road uses are also prohibited. The manufacturer and retailer assume no responsibility for any use or application of this product in violation of any applicable law. Before installing this product, please check your state/province and local/municipal laws and regulations.

**WARNING:** It is recommended that this kit be installed by a certified Triumph technician, following the Triumph service manual to aid in proper fitting. Verify all torque specs in Triumph service manual.

## Other Items We Think You May Like



**Turn Signal Relocation**



**Square Turn Signal**



**Small Bullet Turn Signal**



**Large Bullet Turn Signal**



# Turn Signal Harness Adapter Install

(For Modern Classics) BC501-009-PR

---



## **Step 1:**

Disconnect battery and remove the front turn signals by using a 14mm open end wrench to loosen the mounting nuts (2) located on the turn signal studs.



## **Step 2:**

Remove the headlight bucket Phillips screws (2) located on the underside of the headlight.



## **Step 3:**

Separate the headlight from the headlight bucket after removing the mounting screws and disconnecting the headlight connection.



## **Step 4:**

Locate the OEM turn signal connectors in the headlight bucket and disconnect. This will allow the turn signals to be removed.



# Turn Signal Harness Adapter Install

(For Modern Classics) BC501-009-PR



## **Step 5:**

Install the new aftermarket turn signals by routing the electrical wires in the same way as the stock turn signals with the connectors ending in the headlight bucket. Tighten down the mounting nuts using a 17mm open end wrench.



## **Step 6:**

First, connect the turn signal harness to the appropriate aftermarket turn signal connector by matching the color wires appropriately. See below:

*New Adapter: Black (-) = Black/White Turn Signal Wire (-)*

*New Adapter: Red (+) = Black Turn Signal Wire (+)*

Next, connect the turn signal harness to the appropriate OEM turn signal connector by matching the color wires appropriately. See Below:

*Left Side:*

*Black (New Adapter) = OEM Black Wire*

*Red (New Adapter) = OEM Green Wire*

*Right Side:*

*Black (New Adapter) = OEM Black*

*Red (New Adapter) = OEM Gray*



## **Step 8:**

Connecting the headlight and install the headlight onto the headlight bucket by using the OEM Phillips mounting screws removed in Step #2.



# Turn Signal Harness Adapter Install

(For Modern Classics) BC501-009-PR

---



## **Step 9:**

Reconnect the battery and turn the ignition key to the run position and test the turn signals for proper connection.

## **END**

CONGRATULATIONS! You have successfully completed the installation of your new British Customs product.