# Gärsnäs

# Maintenance and Operating Instructions of coated surfaces.

# Lacquered surfaces.

#### Note:

Lacquered wood surfaces are fully endured about 4 weeks after delivery.

Computers and other equipment with rubber feet can during this time react with the painted surface and can cause permanent marks, therefore the equipment during this time should be fitted with felt pads, or the table surface should be protected in other ways.

Never place hot and/or humid objects directly on the table surface.

Damp outsides of glasses, bottles, etc. with water, alcohol or otherwise, should not be left directly on the table surface.

Lacquered wood surfaces, aluminum parts and painted steel components are cleaned with a well wrung out cloth dampened with water.

For tough dirt, use a mild cleaning agent (without ammonia and/or abrasives). The cleaner should be diluted according to the manufacturer's recommendations.

After wiping with a damp cloth, surfaces should be wiped with soft cloth that does not scratch the surface.

## Cast Iron.

Cast iron is wiped with a dry cloth. For more severe contamination, the material can be wiped with a well-wrung cloth dampened with water in the areas concerned. If too much water is used, the cast iron will rust. Be very careful when cleaning the cast iron.

Never use solvents, acids, alkalis or other harsh detergents.

Never use steel wool, steelwool pad or other mechanical cleaning aids.

The above will result in permanent damage.

## Soaped surfaces.

Surfaces treated with soap, must be constantly re-treated. In daily use, the surfaces should be soaped again at least once every 14 days or as needed. Surfaces are cleaned with a well wrung-out cloth or dry dried.

Spills of leftovers or beverages should be removed immediately to eliminate stains /discoloration. Damp outsides of glass, bottles, etc. with water, alcohol or otherwise, should not be left directly on the table surface.

Surfaces that after a while feels rough can be sanded with fine sandpaper. Polishing must be carried in the fiber direction! Otherwise ugly cross scratches can occur.

After sanding, wipe surfaces with a well-wrung cloth. After polishing, it is recommended to retreat the surface with soap.