



How to Assemble the Phone Holder

1. Before installing the holder, visually check to make sure whether the car's air vents are compatible with the clips.
2. Attach part A and B by pushing each piece through the circle in the middle & sliding across as shown.
3. Attach vent mount to phone holder by putting the back of the vent mount into the phone holder and sliding upwards.

To use in your car, push the air vent clips into your car's air vent.

Insert your phone into the phone holder by opening the clamp (press the button on the side) and adjusting it until your phone is firmly secured.

****Please Note****

1. Don't force the holder while placing the mobile phone
2. Make sure the mobile phone is firmly secured in the holder
3. Do not install and position the holder where it may obstruct driving



