



## INSTALLATION INSTRUCTIONS

### MODEL WGI-C12 INTERIOR WINDOW GUARD KIT

### 2000-2005 CHEVY IMPALA

#### TOOLS REQUIRED:

Eye Safety Goggles  
Power Drill

1/8" Drill Bit  
Phillips Screw Driver

#### HARDWARE SUPPLIED:

<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART #</u>
22	#10 x 1/2" Phillips Sheet Metal Screw	GSM33194
1	Driver Side Window Guard	WGI-C12-1
1	Passenger Side Window Guard	WGI-C12-6

#### INSTALLATION:

1. First determine the correct window guard for each window. The bottom of each guard is numbered, signifying its' location.
2. Open door and hold the window guard up to the window door frame. NOTE: The angle at the bottom of the guard framework faces towards the outside of the car. The guard framework fits evenly around the window frame.
3. Mark a few holes at the top of the door frame using the pre-drilled holes on the guard framework as a guide.

*Note: Do not mark holes for the sides or bottom yet.*

4. Remove window guard and drill holes as marked with a drill bit.
5. Attach window guard by using #10 x 1/2" sheet metal screws. Now locate and mark balance of holes, drill and attach, starting at top and working your way down.
6. Follow the same steps for the other side of the vehicle.