

## **READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION**

## NOTICE:

Fuelpak is intended for racing or off-highway use only, and is not legal for sale or use in California on pollution-controlled vehicles.

## TOOLS NEEDED

- #1 Phillips Screwdriver
  10 & 12mm Socket Wrench
- Needle Nose Pliers
- Less than 1 hour



**INTRODUCTION:** Congratulations on your purchase of the Fuelpak Fuel Management System for fuel injected Yamaha V Star 1300 motorcycle. Please take the time to read the entire instruction manual before attempting to install. DO NOT adjust the Fuelpak until you have thoroughly read the instruction manual and the unit is fully installed. If you have questions, please call (562) 921-0071.

**SUMMARY:** To achieve the optimum performance from your application, it is recommended that you install a high performance air filter in conjunction with this unit. The Fuelpak will be installed in-line the factory injector wiring harness and the throttle position sensor. The Fuelpak will be tucked under the seat next to the tool tray.

## PLEASE NOTE: FUELPAK USE REQUIRES A HIGH PERFORMANCE AIR FILTER.

- 1. Be sure the main switch is in the off position during the installation process. Failure to do this will cause the "check engine" light to be set.
- 2. Remove seat exposing the tool tray and battery.
- 3. Remove the (2) 12mm Hex head bolts securing rear of tank. Prop up the rear of the tank.
- 4. Locate and unplug the white 4-pin connector under left side of tank as shown in figure 1.
- 5. Route Fuelpak as shown in figure 2. Plug Fuelpak white connectors to the factory connectors unplugged in step 4.
- 6. Connect brown and green wires to the negative side of the battery.
- Route Fuelpak long black wire under right side of tank and down to the horn as shown in figure 3.
   Disconnect the factory black / white wire from horn.
   Plug in Fuelpak long black wire to horn and then connect factory black / white wire to terminal on Fuelpak black wire.
- Locate the throttle position sensor on the throttle body located on right side of the tank. As shown in figure 4, attach T-tap to yellow / black wire on throttle position sensor. Connect Fuelpak violet wire to T-tap.
- 9. Using supplied Velcro, mount Fuelpak next to tool tray as shown in figure 5.
- 10. Reinstall tank with (2) 12mm Hex head bolts removed in step 3.
- 11. You are now ready to set-up your Fuelpak.



FUEL INJECTION MANAGEMENT SYSTEM

**NSTALLATION INSTRUCTIONS** 



WARRANTY INFORMATION

**WARRANTY:** Your Fuelpak unit is warranted against defects in materials and workmanship for the period of 90 days from the original retail purchase. In the event of an alleged defect in material or workmanship, Fuelpak's responsibility is strictly limited to repair or replace the defective product. Fuelpak shall not be responsible for (a) labor, transportation, or other incidental charges; (b) consequential or other damages incurred by use of any product. Fuelpak offers no other warranty beyond this limited warranty. This limited warranty does not apply to products which have been (a) modified or altered in any way; (b) subjected to adverse conditions, such as misuse, neglect, accident, improper installation or adjustment, contaminants, corrosion, or faulty repair; or (c) used in applications other than those recommended by Fuelpak. To initiate a warranty process, the consumer must first call technical support to receive a return authorization number. The product must be returned to Fuelpak complete with a dated receipt and a return authorization number.

> Fuelpak Attn: Warranty Claims 13861 Rosecrans Avenue Santa Fe Springs, CA 90670 (562) 921-0071