

INSTALLATION INSTRUCTIONS  
FOR

50-0300A-014 SERIES 1181282

50-0300A-002 SERIES 1181284

FORD EXPLORER / MERCURY MOUNTAINEER w/ SUNROOF  
OVERHEAD CONSOLE for use with FLIPDOWN VIDEO SYSTEM





These instructions are intended for use only by experienced professionals in the automotive customizing business. Special tools and equipment, as well as specialized handling and care of product during installation, may be required. Before beginning this installation, carefully read through the following instructions. **Use extreme care when cutting headliner material.** Check for wiring or other componentry above headliner material. Cut only where indicated.

Materials/ Tools required for this installation:

1. #2 Phillips screwdriver
2. Powered screwdriver or drill with adapter
3. Awl or similar tool
4. Razor knife or similar tool
5. 18 GA wire 4'-6'
6. 7mm Hex Socket Bit
7. Test Light
8. Audiovox Series 640/650 Video Module

MATERIALS PROVIDED FOR INSTALLATION:

ITEM	Description	QTY
1	SCREW, 6-32 X 3/4" PPH	6
2	WASHER, 3.5 mm	4
3	SCREW, # 8 X 1 1/2" PWH	1
4	SCREW, # 6 X 1/2" PPH	2
5	MOUNTING BRACKET	1
6	SPEAKER GRILLE	1
7	CONSOLE	1
8	COVER PLATE	1
9	COVER PLATE DECAL	1



## I. PREPARATION OF VEHICLE INTERIOR




FIGURE 1

1. Using the rear edge of O.E. sunroof opening as a reference location, carefully measure & trim headliner as shown. **Caution: Before cutting headliner material, check for wiring or other componentry above headliner. Cut only where indicated.** Make sure that the 7" cut is centered left to right in vehicle. See Figure 1. **DO NOT OVERCUT HEADLINER.**

2. Remove and retain lens from middle O.E. dome light.
3. Remove and retain (3) three screws which secure middle O.E. dome light. See Figure 2.



FIGURE 2





FIGURE 3

4. Construct a jumper harness that will connect the vehicle's dome light wires to the lights in video system. Connect the white wire from video system to the O.E. black/blue wire. Connect the black wire from video system to the chassis ground. See Figure 3.
5. Using a test light, test function of lights.
6. Install O.E. dome light in original manner.

7. Remove and retain (2) two O.E. screws from bracket. See Figure 4.
8. Carefully pull back edge molding from rear of sunroof opening. See Figure 4.



**FIGURE 4**



**FIGURE 5**

9. Insert mounting bracket (item 5 pg. 2) into headliner. Slide bracket forward between headliner and roof until tab engages O.E. roof panel. Align hole in bracket with center rivet on roof panel. See Figure 5.
10. Secure rear of bracket using (2) two O.E. screws, previously removed.
11. Slide edge molding back into original position around sunroof opening.

12. Install and route all video and audio cables, and any other added component requirements to their respective places in the vehicle. Refer to component installation instructions for wiring diagrams. The suggested routing of the video system cable is as follows: Above the headliner from video system to C-pillar. Down the C-pillar to the floor. Route the power lead to an accessory controlled source. Connect the ground lead to the vehicle chassis. Route the remaining wiring (RCA plugs, Remote Sensor extension, etc.) to the VCP location. See Figure 6. Connect per instructions included with the video system. If video system is to be used as a television, install an appropriate antenna per instructions included with the antenna.



FIGURE 6

## II. INSTALLATION OF CONSOLE

**IF SPEAKER UPGRADE KIT WAS PURCHASED, INSTALL PER INSTRUCTIONS PROVIDED.**



FIGURE 7

13. Raise console (item 6 pg.2) into approximate position against headliner. Loosely install using (2) two 6-32 x 3/4" screws (item 1 pg. 2) through the smaller holes in bracket on console into threaded clips on front of mounting bracket. See Figure 7.
14. Using a scribe or similar tool, align hole in rear of console with slot in rear of mounting bracket. Loosely secure rear of console using (1) one # 8 x 1 1/2" screw (item 3 pg. 2). Make sure console alignment is straight then tighten (2) two 6-32 screws previously installed. See Figure 7.

15. Release video screen from locked position. Lower video screen to viewing position for access to mounting location in top of video system housing.
16. Raise video system into approximate position and connect all wiring to components. Connect wiring and cabling to video system per instruction included with video system.
17. Check function of all component and lights. See operating instruction for video system operations check. For further assistance, refer to the video system manual for the technical support phone number listed for your area.



**FIGURE 8**

18. Insert video system into opening in console.

**Note : Make sure wires do not get pinched between video system and console.**

Align holes in housing with clips in mounting bracket. Secure using (4) four 6-32x 3/4" screws (item 1 pg.2) and (4) four 3.5mm washers (item 3 pg. 2). See Figure 8.

**Caution : Do not overtighten screws.**



**FIGURE 9**

19. Tighten screw previously installed to secure rear of console to headliner. **Caution: Do not overtighten screws or damage to vehicle roof may occur.**
20. Raise video screen into locked position.
21. Install speaker grille (item 7 pg. 2). Align clips in grille with holes in console and press firmly. See Figure 9.
22. If speaker upgrade kit was not installed, install cover plate (item 8 pg. 2) at front of console and secure using (2) # 6 X 1/2" screws (item 4 pg. 2).
23. Install cover plate decal (item 9 pg 2).