



Manitowoc

K00194 ADAPTER KIT TWO QC0700/QF0800 MACHINES ON AN S-970 BIN Installation Instructions

- Note: Bin must be level before installation of ice machines.
 - Remove the foam tape from the front and sides of the bin where the support angle will be located. Use the front angle to reference the areas where the tape should be removed.
 - Place the support angle on the front edge of the bin and position as far forward as possible.
 - Locate the four pieces of the 2" long, 3/4" wide foam tape in the front corners, as shown.
 - Place the adapter panel onto the bin, as shown.
 - Note: It is recommended to RTV the tape intersections and along the inside of the foam tape to prevent water tracking.
- Refer to ice machine installation manual for ice machine installation procedures.

