

# **Backboard and Rim Owners Manual**

**Customer Service Center** • N53 W24700 South Corporate Circle • Sussex, WI 53089 • U.S.A.



Adult Assembly Required.

This manual, accompanied by sales receipt, should be saved and kept on hand as a convenient reference, as it contains important information about your model.

> READ AND UNDERSTAND **OPERATOR'S MANUAL** BEFORE USING THIS UNIT.

INSTRUCTIONS COULD **RESULT IN INJURY OR** DAMAGE TO PROPERTY.

1

#### Write Model Number From Box Here:

Toll-Free Customer Service Number for U.S: 1-800-558-5234, For Canada: 1-800-284-8339, For Europe: 00 800 555 85234 (Sweden: 009 555 85234), For Australia: 1800 632 792

Internet Address: www.huffysports.com www.spalding.com





### ASSEMBLE THE BACKBOARD AND RIM

This is what your system will look like when you've finished this section:





1.

### WARNING!

IF YOUR SYSTEM IS EQUIPPED WITH AN ACRYLIC BACKBOARD, EXAMINE BACKBOARD FOR ANY DAMAGE THAT MAY HAVE OCCURRED DURING SHIPMENT. CRACKS IN THE BACKBOARD COULD RESULT IN SUDDEN BREAKAGE. IF BACKBOARD IS DAMAGED IN ANY WAY PRIOR TO OR AFTER ASSEMBLY, CALL TOLL-FREE NUMBER:

U.S. 1-800-558-5234; CANADA: 1-800-284-8339; http://www.huffysports.com

# **TOOLS REQUIRED**









# **EXTENSION ARM MOUNT**

# NOTE:

We recommend mounting backboard to a solid material (steel) behind rim area.

1

15

17

18

0

€

7

6





# POLE, ROOF, OR WALL MOUNT

# Model 8406 Universal Mounting Bracket is available for purchase by calling this number: 1-800-558-5234







# **ELEVATOR MOUNTS**

#### **IMPORTANT!**

All Elevator mounts will require this initial step of attaching brackets (8) to the backboard.















### Install Slam Jam Rim to Backboard

- A Fit rim (12) securely into bracket (17) as shown. Allow T-bolt (18) to slip through center hole in rim (12).
- **B** Install reinforcement bracket (19) onto T-bolt (18) as shown.
- **C** Install spring (20) onto T-bolt (18) as shown.

2.

- **D** Install special nut (21) and washer (10) onto T-bolt (18).
- **E** Tighten nut (21) until flush with end of T-bolt (18).



