COMPATIBILITY STATUS BETWEEN SKYPE VERSION AND VOIP080 USB PHONE DRIVER



THE VOIP080 USB PHONE DRIVER MAY NOT WORK PROPERLY WITH SKYPE BETA RELEASE.



FOR WINDOWS VISTA DRIVER:

- If it's a new installation please download the complete installation CD Content: Please click on the following link: LINK *

Unzip the file, execute Setup.exe and follow instructions.

- If it's an update of the driver, please check next



The VOIP080 USB Phone Driver V3.5.4.0 which can be downloaded from Philips web site is compatible with Skype software version from V2.5.0.122 until V3.8.0.x

1°) Read my Skype version:



- Open Skype window, select "About" in "Help" menu, to display the following window:

2°) Read VOIP080 USB Phone Driver version:

- Open VOIP080 PC application, by right click on 🗾 in status bar, and select "About". The following window is displayed:

Coptions générales Réglages audios Réglages so	ns A propos	
PHILIPS	Version du logiciel: 3.1.1.0	VOIP080 USI phone driver version
© Philips Consu	HONE VOIP080 Imer Electronics. Is réservés	
Téléphone VOIP080	0 - Déconnecté	
	OK Annuler Appliquer	

3°) Upgrade my VOIP080 USB Phone Driver:

- If you have an older VOIP080 USB Phone Driver version, you may have compatibility problem with last Skype release.
- To upgrade your VOIP080 USB Phone Driver version, first download the last driver on Philips web site: LINK
- Uninstall the VOIP080. Go to program, Philips, VOIP080 and select "Uninstall VOIP080".
- Install the latest "Setup.exe" downloaded from the Philips web site.
- Start the VOIP080 software.
- The following Skype window can be displayed:

Skype™ - Another program wants to use Skype		×
S	Another program wants to use Skype	
T	Another program is trying to access Skype. This can be a potential security risk. What would you like to do?	
	PulLIPS Name: VOIP080.exe Publisher: Philips	
	Allow this program to use Skype	
	⊙ Allow this program to use Skype, but ask again in the future	
	🔘 Do not allow this program to use Skype	
	What does this mean?	
	ОК	

- Select Allow this program to use Skype.
- Validate by pressing OK.