

615019-X and 615020-X DRUM COVER DRAINS


MODEL DESCRIPTION

615019 and 615020 Standard Funnel
615019-1 and 615020-1 Extra Wide Funnel

OPERATION

To raise or lower the funnel: Grasp the upper portion of the drain tube, loosen the thumb screw and raise the funnel and drain tube to the desired height. Tighten the thumb screw and release grasp on tube.

Dip gauge: When the oil level in the drum reaches the "F" mark on the dip gauge, it is time to empty or drain the drum.



PN 97999-839

ARO

INGERSOLL-RAND COMPANY
ONE ARO CENTER • BRYAN, OHIO 43506-0151
(419) 636-4242 • FAX (419) 633-1674

©1999 • PRINTED IN U.S.A.

INGERSOLL-RAND
FLUID PRODUCTS