




# COOKTOP, BURNER AND GRATE PARTS

For Models: GLS3665RS0  
(Stainless Steel)

36" GAS COOKTOP



Illus. No.	Part No.	DESCRIPTION
1	9761893	Literature Parts Installation Instructions
	9761890	Use & Care Guide
	9762236	LP Conversion Instructions
2	8190902	Cooktop
3	8190909	Panel, Control
4		Cap, Burner
	8190894	RR - LF
	8190893	RF - LR
	8190895	Center
5	8190891	Grates (2)
6	8190980	Grate, Center

Illus. No.	Part No.	DESCRIPTION
7	8190908	Knob, Control (5)
8	8190903	Seal, Foam (6) 3/8 x 1/2 x 5.5"
9	8190905	Seal, Foam (2) 1/8 x 1/2 x 18"
10	8190981	Seal, Foam (2) 1/8 x 1/2 x 33"
11		Head, Burner
	8190897	RR-LF
	8190896	RF-LR
	8190898	Center
12		Base, Burner
	8190900	RR-LF
	8190899	RF-LR
	8190901	Center

Illus. No.	Part No.	DESCRIPTION
13	8190892	Ignitor, Surf (5)
14	8190904	Clip, Spring (5)
15		Holder, Orifice
	8190931	RR-LF
	8190930	RF-LR
	8190932	Center
16	8190906	Frame, Top

**Following Parts Not Illustrated**


- 8190927 Harness, Wire
- 8190933 Ignitor Wire Kit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BURNER BOX, GAS VALVES, AND SWITCHES

For Models: GLS3665RS0

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	8190918	Nut, Compression
2	8190910	Pipe, Manifold
3	8190913	Switch, Spark (5)
4	8190929	Spark Module (5)
5		Valve, Burner
	8190915	RR-LF 1200 (Green)
	8190914	RF-LR 9000(Orange)
	8190916	Cntr 1500 (Yellow)
6	8190925	Power Cord
7	8190917	Sleeve, Compressor

Illus. No.	Part No.	DESCRIPTION
10		Tubing, Burner
	8190919	RR
	8190920	RF
	8190921	Center
	8190922	LR
	8190923	LF
13	8190926	Regulator, Pressure
14	8190928	Box, Burner
15	8190912	Clip, Spring (4)
16	8190911	Washer (4) (Spark Switch)

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated and Optional Parts Not Included		
	8190963	Gas Conversion Kit (Natural Gas To LP Gas)
	8190924	Strain Relief
	8190978	Bracket (2) – Mntg
	8190979	Screw (2) – Mntg
	8190977	Gasket (Cooktop Mounting)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST