


# COOKTOP, BURNER AND GRATE PARTS

For Models: GLT3057RB01, GLT3057RQ01, GLT3057RT01  
(Black) (Designer White) (Biscuit)

30" SEALED GAS COOKTOP



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP, BURNER AND GRATE PARTS


For Models: GLT3057RB01, GLT3057RQ01, GLT3057RT01  
(Black) (Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		LITERATURE PARTS	4		Cap, Burner 6K (RR)	8		Grate, Center
	8286304	Installation Instructions		8286153CB	Coal Matte Black		8285893CB	Coal Matte Black
	8286615	Use & Care Guide		8286153CG	Cumberland Gray		8285893CG	Cumberland Gray
	3191638	Safe Cooking Tips		8286153EP	Espresso	10	3191932	Seal, Foam
	9759133	Safe Cooking Tips			9.5K (LR)	15		Holder, Orifice
	8286620	L.P. Conversion Instructions		8286154CB	Coal Matte Black		8286179	6K (RR)
2		Bowl, Burner 6K (RR)		8286154CG	Cumberland Gray		8286180	12K (LF,RF)
	3191307	Black		8286154EP	Espresso		8286178	9K (LR)
	3191308	White			12.5K (LF,RF)	16		Head, Burner
	3191819	Biscuit		8286155CB	Coal Matte Black		8286181	RF
		9K,12K (LR,RF,LF)		8286155CG	Cumberland Gray		8286182	LF, RF
	3191302	Black	5	8286155EP	Espresso		8286184	LR
	3191303	White			Grate	18	4449809	Screw
	3191818	Biscuit			Left Hand	20	3368921	Screw
3		Grommet, Glass		8285892CB	Coal Matte Black	Following Parts Not Illustrated		
	3180079	Black		8285892CG	Cumberland Gray			Harness, Wire
	3180081	White		8285892EP	Espresso			Ignitor
	3191817	Biscuit			Right Hand		4456626	15"
				8285894CB	Coal Matte Black		4456627	28"
				8285894CG	Cumberland Gray		4449809	Screw (4)
				8285894EP	Espresso		3400806	Screw (2)
			6		Cooktop, Glass			
				8286102	Black			
				8286103	White			
				8286104	Biscuit			
			7		Knob, Control (4)			
				8286058BL	Black			
				8286058WH	White			
				8286058BT	Biscuit			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BURNER BOX, GAS VALVES, AND SWITCHES

For Models: GLT3057RB01, GLT3057RQ01, GLT3057RT01  
(Black) (Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BURNER BOX, GAS VALVES, AND SWITCHES

For Models: GLT3057RB01, GLT3057RQ01, GLT3057RT01  
(Black) (Designer White) (Biscuit)

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1	4455917	Bracket, (2) Cooktop mounting
2	8286069	Pipe, Manifold
	3196160	Screw (2)
3	4456905	Harness & Switches
4	8522423	Spark Module
5		Valve, Burner
	8286559	Auxi (White)
	8286560	Rapid (Purple)
	4456817	Large (2)
6	9763116	Power Cord
7	4173634	Bushing, Cord
8	3177991	Screw, Ground
9	8523704	Bolt, Gas Valve
10		Tubing, Burner
	3191326	LF
	3191325	RR
	3191324	RF
	8286100	LR
11	3192491	Bracket, Manifold
12	3400093	Screw
13	4455837	Bracket, Spark Module
14	8286098	Box, Burner
15	3191462	Shield, Heat
16	9759145	Bracket, Support Rail
17		Burner
	8286099	Center
	8285791	Center
18	3191387	Seal, (4) Switch Cover
19	8285788	Shield, Heat
20	3400843	Screw
21	3177991	Screw
22	4449809	Screw

---

Following Parts Not Illustrated  
and Optional Parts Not Included

---

8286320 Spud Kit  
4455918 Hardware Kit  
(Mounting)