





COOKTOP, BURNER AND GRATE PARTS

For Models: GLT3057RB00, GLT3057RQ00, GLT3057RT00
(Black) (Designer White) (Biscuit)

30" SEALED GAS COOKTOP



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP, BURNER AND GRATE PARTS

For Models: GLT3057RB00, GLT3057RQ00, GLT3057RT00

(Black) (Designer White) (Biscuit)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		LITERATURE PARTS	4		Cap, Burner 6K (RR)	7		Knob, Control (4)
	8286304	Installation Instructions		8286153BL	Black		8286058BL	Black
	8286313	Use & Care Guide		8286153CG	Cumberland Gray		8286058WH	White
	3191638	Safe Cooking Tips		8286153EP	Espresso		8286058BT	Biscuit
	8286314	L.P. Conversion Instructions		8286154BL	Black	8		Grate, Center
2		Bowl, Burner 6K (RR)		8286154CG	Cumberland Gray		8285893BL	Black
	3191307	Black		8286154EP	Espresso		8285893CG	Cumberland Gray
	3191308	White			12.5K (LF,RF)	10	3191932	Seal, Foam
	3191819	Biscuit		8286155BL	Black	15		Holder, Orifice
		9K,12K (LF,RF,LR)		8286155CG	Cumberland Gray		8286179	6K (RR)
	3191302	Black	5	8286155EP	Espresso		8286180	12K (RF,LF)
	3191303	White			Grate		8286178	9K (LR)
	3191818	Biscuit			Left Hand	16		Head, Burner
3		Grommet, Glass		8285892BL	Black		8286181	RR
	3180079	Black		8285892CG	Cumberland Gray		8286182	LF, RF
	3180081	White		8285892EP	Espresso		8286184	LR
	3191817	Biscuit			Right Hand	18	4449809	Screw
				8285894BL	Black	20	3368921	Screw
				8285894CG	Cumberland Gray	Following Parts Not Illustrated		
				8285894EP	Espresso			Harness, Wire Ignitor
			6		Cooktop, Glass		4456626	15"
				8286102	Black		4456627	28"
				8286103	White		4449809	Screw (4)
				8286104	Biscuit		3400806	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER BOX, GAS VALVES, AND SWITCHES

For Models: GLT3057RB00, GLT3057RQ00, GLT3057RT00

(Black) (Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER BOX, GAS VALVES, AND SWITCHES

For Models: GLT3057RB00, GLT3057RQ00, GLT3057RT00

(Black) (Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	4455917	Bracket, (2) Cooktop mounting
	3400093	Screw
2	8286069	Pipe, Manifold
	3196160	Screw (2)
3	4456905	Harness & Switches
4	8522423	Spark Module
	3400843	Screw
5		Valve, Burner
	8286559	Auxi (White)
	8286560	Rapid (Purple)
	4456817	Large (2)
6	3192231	Power Cord
7	4173634	Bushing, Cord
8	3177991	Screw, Ground
9	8523704	Bolt, Gas Valve
10		Tubing, Burner
	3191326	LF
	3191325	RR
	3191324	RF
	8286100	LR
11	3192491	Bracket, Manifold
13	4455837	Bracket, Spark Module
14	8286098	Box, Burner
	4449809	Screw
15	3191462	Shield, Heat
	3177991	Screw
16	9759145	Bracket, Support
	3400843	Screw
17		Rail
	8286099	Burner
	8285791	Center
	4449809	Screw
18	3191387	Seal, (4) Switch Cover
19	8285788	Shield, Heat

Following Parts Not Illustrated
and Optional Parts Not Included

8286320 Spud Kit
4455918 Hardware Kit
(Mounting)