

COOKTOP PARTS

For Models: GW395LEPB05, GW395LEPQ05, GW395LEPT05, GW395LEPS05


(Black)

(White)

(Biscuit)

(Stainless)

30" Slide-In
GAS OVEN
NON-CONV



Literature Parts

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|--|
| 1 | 9761413 | Literature Parts Installation Instructions |
| | W10086240 | Use & Care Guide |
| | 9761386 | Tech Sheet |
| | 9757680 | Anti-Tip Instructions |
| | 3191638 | Safe Cooking Tips English |
| | 9759133 | Safe Cooking Tips French |
| 2 | 9759523 | Burner Box |
| 3 | 4454023 | Bracket, Mounting |
| 4 | W10005980 | Cooktop Black |
| | W10005970 | Cooktop White |
| | W10005960 | Cooktop Biscuit |
| 5 | 3400843 | Screw |
| 6 | 9759530BL | Trim, Cooktop Right Black |
| | 9759530WH | Trim, Cooktop Right White |
| | 9759530BT | Trim, Cooktop Right Biscuit |
| | 9759530SS | Trim, Cooktop Right Stainless |
| | 9759531BL | Trim, Cooktop Left Black |
| | 9759531WH | Trim, Cooktop Left White |
| | 9759531BT | Trim, Cooktop Left Biscuit |
| | 9759531SS | Trim, Cooktop Left Stainless |


| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|-----------------------------|
| 7 | 3196537 | Screw |
| 8 | 9757807 | Thermostat |
| 9 | 3192811 | Bracket, Burner |
| 10 | 9756821 | Support, Wiring |
| 11 | 9760225BL | Dome Cap, Vent Black |
| | 9760225WH | Dome Cap, Vent White |
| | 9760225BT | Dome Cap, Vent Biscuit |
| 12 | 9759756BL | Grate, Burner Right Black |
| | 9759756MG | Grate, Burner Right White |
| | 9759756EP | Grate, Burner Right Biscuit |
| | 9759755BL | Grate, Burner Left Black |
| | 9759755MG | Grate, Burner Left White |
| | 9759755EP | Grate, Burner Left Biscuit |
| 13 | 4449809 | Screw |
| 14 | 3196160 | Screw |
| 15 | 8286181 | Head, Burner LR, RF |
| | 8286182 | Head, Burner RR |
| | 9762553 | Head, Burner LF |
| 16 | 9759944 | Thermostat |

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|------------------------------------|
| 17 | 9760224BL | Vent, Center Black |
| | 9760224WH | Vent, Center White |
| | 9760224BT | Vent, Center Biscuit |
| 18 | 9760520BL | Cap, Burner 12.5K (LF) Black |
| | 9760520WH | Cap, Burner 12.5K (LF) White |
| | 9760520BT | Cap, Burner 12.5K (LF) Biscuit |
| | 9760520SS | Cap, Burner 12.5K (LF) Stainless |
| 19 | 9761563GB | Cap, Burner 14K (RR) Black |
| | 9761563GS | Cap, Burner 14K (RR) Mouse Grey |
| | 9761563EP | Cap, Burner 14K (RR) Espresso |
| | 9761564GB | Cap, Burner 6K (RF, LR) Black |
| | 9761564GS | Cap, Burner 6K (RF, LR) Mouse Grey |
| | 9761564EP | Cap, Burner 6K (RF, LR) Espresso |
| | 3191898 | Cap, Burner 6K (RF, LR) Black |
| | 3191899 | Cap, Burner 6K (RF, LR) Mouse Grey |
| | 8273343 | Cap, Burner 6K (RF, LR) Espresso |
| 20 | 3368921 | Screw |
| 21 | 9759629 | Cover, Cooktop Rear |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GW395LEPB05, GW395LEPQ05, GW395LEPT05, GW395LEPS05
 (Black) (White) (Biscuit) (Stainless)



| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|-----------------------|
| 1 | | Control Panel |
| | W10035970 | Black |
| | W10035960 | White |
| | W10035950 | Biscuit |
| | W10035940 | Stainless |
| 2 | 4449745 | Screw |
| 3 | 9760013 | Control, Migration |
| 4 | 9757119 | Bracket, Console |
| 5 | 3196172 | Screw |
| 6 | W10036100 | Bracket, Oven Control |

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|--------------------|
| 7 | 9757409 | Support, Gas Valve |
| 8 | | Endcap |
| | 9756611BL | Black |
| | 9756611WH | White |
| | 9756611BT | Biscuit |
| | 9756614BL | Black |
| | 9756614WH | White |
| | 9756614BT | Biscuit |

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|---------------------------|
| 9 | | Knob |
| | 9759941BL | Black |
| | 9759941WH | White |
| | 9759941BT | Biscuit |
| 10 | 3196537 | Screw |
| 11 | 9780271 | Screw |
| 12 | W10078570 | Membrane, Switch Assembly |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: GW395LEPB05, GW395LEPQ05, GW395LEPT05, GW395LEPS05

(Black)

(White)

(Biscuit)

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: GW395LEPB05, GW395LEPQ05, GW395LEPT05, GW395LEPS05

(Black)

(White)

(Biscuit)


(Stainless)

| Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|--------------------------|------------|-----------|-------------------------------|--|-----------|---------------------------|
| 1 | | Trim, Side Right | 18 | 9757685 | Guide, Side Panel | 37 | | Trim, Bottom Vent |
| | 9757735BL | Black | 19 | 9756454 | Bracket, Appliance Manager | | 9756485BL | Black |
| | 9757735WH | White | | | Body, Side | | 9756485WH | White |
| | 9757735BT | Biscuit | 20 | | Black | | 9756485BT | Biscuit |
| | 9757735SS | Stainless | | 9760723PB | Black | | 9756485SS | Stainless |
| | | Left | | 9760723PW | White | 38 | 4449743 | Screw |
| | 9757734BL | Black | | 9760723PC | Biscuit | 39 | 4450118 | Nut |
| | 9757734WH | White | 21 | 9757461 | Bracket, Side Panel | 40 | 4448717 | Rack, Oven |
| | 9757734BT | Biscuit | 22 | 9760888 | Latch, Motorized | 41 | 9757732 | Shield, Heat |
| | 9757734SS | Stainless | 23 | 8300802 | Thermostat | 42 | 9757070 | Plate, Relectance |
| 2 | 3400832 | Screw (2) | 24 | 9757811 | Brace, Side Panel | 43 | 9760481 | Washer |
| 3 | | Hinge Receiver | 25 | 4455641 | Side, Chassis | 44 | 4448444 | Grommet, Mounting Rail |
| | 4455606 | Right | 26 | 9759762 | Back, Chassis | | | |
| | 4455605 | Left | 27 | | Liner, Oven (Not Serviceable) | 45 | 9759722 | Insulation Body Side Trim |
| 4 | W10105790 | Bumper, Door (2) | 28 | 9759890 | Clip, Side Panel | 47 | 9758080 | Spark Module |
| 5 | 3196537 | Screw | 29 | 4455636 | Sensor | 48 | 9760223 | Slide, DSI Module |
| 6 | 3196160 | Screw | 30 | 9757717 | Insulation | FOLLOWING PARTS NOT ILLUSTRATED | | |
| 7 | 8303099 | Top Chassis | 31 | 3196176 | Screw | INSULATION | | |
| 8 | 4449809 | Screw | 32 | 8053971 | Brace, Main Back | | 9756817 | Insulation, Wrap |
| 9 | 9761062 | Tube, Vent | 33 | W10045340 | Base, Chassis | | 9756470 | Insulation, Back |
| 10 | W10067870 | Lens, Light (2) | 34 | 4448933 | Retainer, Gasket | | | |
| 11 | W10009930 | Oven Light, Assembly (2) | 35 | 9758583 | Cover, Back | | | |
| 12 | 4452166 | Bulb, Light (2) | 36 | | Vent, Bottom Upper | | | |
| 13 | 4449154 | Screw | | 9756481BL | Black | | | |
| 14 | W10130368 | Frame, Front | | 9756481WH | White | | | |
| 15 | W10074200 | Gasket, Door | | 9756481BT | Biscuit | | | |
| 17 | 4452152 | Bracket, Mounting | | 9756481SS | Stainless | | | |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: GW395LEPB05, GW395LEPQ05, GW395LEPT05, GW395LEPS05
(Black) (White) (Biscuit) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS


For Models: GW395LEPB05, GW395LEPQ05, GW395LEPT05, GW395LEPS05

(Black) (White) (Biscuit) (Stainless)

| Illus. No. | Part No. | DESCRIPTION |
|-------------------|-----------------|-------------------------|
| 1 | 9759413 | Panel, Door |
| 2 | 9757706 | Glass, Inner |
| 3 | 4451722 | Insulation, Door |
| 4 | 4457132 | Retainer, Glass |
| 5 | | Hinge, Oven Door |
| | 9760571 | Right |
| | 9760572 | Left |
| 6 | 9759225 | Glass, Inner |
| 7 | 4457114 | Shield, Heat Bottom |
| 8 | 9759229 | Bracket, Glass Side |
| 9 | 4457103 | Shield, Heat Top |
| 10 | 4451040 | Screw |
| 11 | 9759230 | Bracket, Central |
| 12 | | Bracket, Handle |
| | 9763497 | R. Hand |
| | 9763496 | L. Hand |
| | 4451040 | Screw |
| 13 | | Pad, Handle |
| | 9759638 | Right |
| | 9759637 | Left |
| 14 | | Assembly, Door Kit |
| | 9759641 | Black |
| | 9759639 | White |
| | 9759640 | Biscuit |
| | 9759349 | Stainless |
| 15 | | Handle, Door |
| | 4448854 | Black |
| | 4448855 | White |
| | 4452860 | Biscuit |
| 17 | 4450863 | Retainer, Glass Clip |
| 18 | 9759635 | Spacer, Door Glass |

DRAWER PARTS

For Models: GW395LEPB05, GW395LEPQ05, GW395LEPT05, GW395LEPS05
 (Black) (White) (Biscuit) (Stainless)



| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|-----------------------|
| 1 | 9763501BL | Support, Front & Rear |
| 3 | 4453720 | Brace, Drawer Right |
| | 4453721 | Left |
| 4 | 9759965 | Bracket, Base |
| 5 | | Side, Base |
| | 9759953 | Right |
| | 9759954 | Left |
| 6 | W10058460 | Foot |
| 7 | 9759943 | Brace, Front |


| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-----------------|
| 8 | 3196037 | Foot Assembly |
| 9 | | Rail, Storage |
| | 9756837 | Right |
| | 9756839 | Left |
| 10 | 9757806 | Drawer |
| 11 | | Guide, Roller |
| | | Includes Roller |
| | 9756841 | Right |
| | 9756842 | Left |
| 12 | 9760592 | Panel, Drawer |

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|----------------|
| 13 | | Front, Drawer |
| | 4453921BL | Black |
| | 4453921WH | White |
| | 4453921BT | Biscuit |
| | 4453921SS | Stainless |
| 14 | | Handle, Drawer |
| | 9756674BL | Black |
| | 9756674WH | White |
| | 9756674BT | Biscuit |
| 15 | 3196537 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: GW395LEPB05, GW395LEPQ05, GW395LEPT05, GW395LEPS05
 (Black) (White) (Biscuit) (Stainless)



| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|---------------------|
| 1 | W10105780 | Front, Air Duct |
| 2 | W10068590 | Top, Air Duct |
| | W10068600 | Right |
| | | Left |
| 3 | 9759320 | Blower |
| 4 | 4451758 | Block, Foam |
| 6 | 9757117BL | Vent, Control Panel |
| 7 | 4450038 | Screw |
| 8 | 4449809 | Screw |
| 9 | 4449040 | Screw |
| 10 | 4455352 | Bracket, Blower |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS


For Models: GW395LEPB05, GW395LEPQ05, GW395LEPT05, GW395LEPS05

(Black)

(White)

(Biscuit)

(Stainless)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-----------------------|
| 1 | 9752980 | Flame Shield, Broiler |
| 2 | 3196176 | Screw |
| 3 | 3196385 | Screw |
| 4 | 4453920 | Pan, Oven Bottom |
| 5 | 9757779 | Fitting, Broiler |
| 6 | 3196176 | Screw |


| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|------------------------|
| 7 | 4454009 | Cover, Ignitor |
| 8 | 4453957 | Pan Support, Bake |
| 9 | 9760229 | Electrode, Bake Burner |
| 10 | 9760228 | Burner, Bake |
| 11 | 9752737 | Shield, Oven |
| 12 | 4453984 | Shield, Bake Flame |

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|-------------------------|
| 13 | 9763716 | Valve, Assembly |
| 14 | 9756831 | Tube, Broil |
| 15 | W10111219 | Burner, Broil |
| 16 | 8054129 | Electrode, Broil Burner |
| 17 | 3400080 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP BURNER PARTS

For Models: GW395LEPB05, GW395LEPQ05, GW395LEPT05, GW395LEPS05
 (Black) (White) (Biscuit) (Stainless)



| Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|-----------------------|------------|-----------|---------------------------------|------------|----------|------------------------|
| 1 | | Burner Base w/Orifice | 7 | 4456816 | Valve, Burner LR, RF | 14 | 8523704 | Bolt, Valve (4) |
| | W10110375 | LR, RF | 8 | 4456817 | Valve, Burner RR | 15 | | Spud, Orifice |
| | W10110376 | RR | 9 | 9756822 | Spark Switch & Harness Assembly | | 9762938 | RR |
| | W10110377 | LF | 10 | 4453755 | Tube, Manifold | | 9762937 | LR, RF |
| 2 | 9756827 | Tubing, Burner(RF) | 11 | 9756803 | Manifold | | 9762939 | LF |
| 3 | 9756828 | Tubing, Burner(RR) | 12 | 3196537 | Screw | 16 | 4453754 | Tubing GDS to Manifold |
| 4 | 9759759 | Tubing, Burner(LF) | 13 | W10110378 | Electrode, Orifice Holder | 17 | 8273062 | Screw |
| 5 | 9756829 | Tubing, Burner(LR) | | | | | | |
| 6 | 4456818 | Valve, Burner LF | | | | | | |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: GW395LEPB05, GW395LEPQ05, GW395LEPT05, GW395LEPS05

(Black)

(White)

(Biscuit)

(Stainless)

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

591014 Adhesive
Loctite (1/3 oz.)
482338 Sealer, Silastic
(3 oz.)

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

SPLICING WIRES--25FT.

LENGTH

242828 Wire (12 Ga.
150 c Black)
242820 Wire (14 Ga.
150 c Black)
242821 Wire (14 Ga.
150 c Blue)
242822 Wire (14 Ga.
150 c Brown)
242830 Wire (14 Ga.
200 c Brown)
242823 Wire (14 Ga.
150 c Green)
242824 Wire (14 Ga.
150 c Orange)
242829 Wire (12 Ga.
150 c Red)
242825 Wire (14 Ga.
150 c Red)
242831 Wire (14 Ga.
200 c Red)
242826 Wire (14 Ga.
150 c White)
242827 Wire (14 Ga.
150 c Yellow)
242832 Wire (14 Ga.
200 c Yellow)

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

WIRING HARNESS PARTS

9760533 Harness, Wire
(Main)
9756892 Harness, Wire
(Cooktop Power)
9756920 Harness, Wire
Bake/Broil Ignitor
313660 Clip, Ground Wire
9757778 Bushing, Split 1"
4449809 Screw
4450800 Screw, Ground
4452222 Spacer, Harness

Miscellaneous

9758677 Power Cord
9782676 Anti-Tip,
Assembly
9757427 Kit, Orifice (LP)
Filler,Counter Top
9757785BL Black
9757785WH White
9757785BT Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST