




COOKTOP PARTS

For Models: RF272LXTD1
(Universal Silver)

30" ELECTRIC FREESTANDING
SELF CLEAN RANGE



Illus. No.	Part No.	DESCRIPTION
1	9762996	Literature Instructions Installations Template, Anti-Tip
	9757142	English/Spanish
	9757143	English/French
	9763001	Owners Manual
	W10116309	Tech Sheet
	9762761	Safer Cooking Tips


Illus. No.	Part No.	DESCRIPTION
2	9763326	Cooktop
3	8273992	Element, Surface 2500 W - LF/RF
	8273994	1200 W - LR/RR

Illus. No.	Part No.	DESCRIPTION
4	3196169	Screw
5	8272791	Bracket, Element
6	W10035930	Spring, Locator
7	3196170	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RF272LXTD1
(Universal Silver)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	W10009080	Black Left Hand
	W10009090	Black Right Hand
2	9757609	Nameplate
3	W10127721	Panel, Control
4		Switch, Infinite
	3148954	LF/RF (Orange)
	3148951	LR/RR (Silver)


Illus. No.	Part No.	DESCRIPTION
5		Light, Indicator
	8523265	Surface Unit (2)
6	3196068	Lens, Light (3)
7		Knob, Infinite (4)
	9761964	Black
8	8523280	Shield, Heat
9		Screw
	3196168	Black

Illus. No.	Part No.	DESCRIPTION
10	8272473	Cover, Upper
11	8273564	Clip
12	W10108230	Control, Range
13	3196178	Screw
14	9762078	Brkt-Mntg., EOC
15	9762095	Brkt-Mntg, Console
16	3400882	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: RF272LXTD1
(Universal Silver)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER & BROILER PARTS

For Models: RF272LXTD1

(Universal Silver)




Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	9761031	Drawer, Storage
3	9758200	Bracket, Drawer(2)
4		Rivet, Push (2)
	3196813	Black
5	9761694	Panel, Drawer Frnt
6	8053334	Glide, Drawer (2)
7	3196168	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: RF272LXTD1

(Universal Silver)



Illus. No.	Part No.	DESCRIPTION
1	9762394	Trim, Top
2	3196164	Screw
3		Handle, Door
4	9761983	Black
4	9761344	Liner, Door
5	9758162	Glass, Inner (2)
6	3186289	Frame, Glass
7	W10031790	Screw

Illus. No.	Part No.	DESCRIPTION
8	8272618	Insulation, Door
9	9761357	Retainer, Insul.
10	9761496	Hinge, Door
11	9761699	Glass, Outer Door
12		Trim, Door Side
	8523171	Black L.H.
	8523165	Black R.H.
13	3196160	Screw

Illus. No.	Part No.	DESCRIPTION
14	8523180	Trim, Lower Door
16	W10031780	Screw
17	8522414	Seal, Window
18	3196025	Clip, Glass (6)
19	3196794	Bracket, Window(2)
20	3196165	Screw
21	W10113759	Strap, Door

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: RF272LXTD1

(Universal Silver)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black	12 Ga. 150° c
242821	Wire, Blue	14 Ga. 150°c
242822	Wire, Brown	14 Ga. 150°c
242830	Wire, Brown	14 Ga. 200°c
242823	Wire, Green	14 Ga. 150°c
242824	Wire, Orange	14 Ga. 150°c
242825	Wire, Red	14 Ga. 150°c
242831	Wire, Red	14 Ga. 200°c
242827	Wire, Yellow	14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350956	Almond
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3191048	Cleaner, Glass
4396923	Pan, Broiler

ANTI-TIP KIT

W10017440	Anti-Tip Kit
-----------	--------------

WIRING HARNESS PARTS

W10114915	Harness, Wire (Cooktop Left)
W10114894	Harness, Wire (Cooktop Right)
W10084660	Harness, Wire (Sensor/Dr Switch)
8523279	Wire, Ground
3196154	Screw
W10095540	Harness, Wire (Main)
313660	Clip, Wire Ground
3196173	Screw
8524132	Shield, Wiring
3196174	Screw (Grnd Wire / Back)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST