


COOKTOP PARTS

For Models: RF265LXTQ3, RF265LXTB3, RF265LXTT3, RF265LXTS3, RF265LXTY3
 (White) (Black) (Biscuit) (S.Steel) (Univ.Silver)



30" ELECTRIC CERAN
 FREESTANDING RANGE
 SELF CLEAN CONVECTION OVEN



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10162204	Owner's Manual
	W10134252	Tech Sheet
	W10141166	Installation Instructions
		Template, Anti-Tip
	9757143	English/French
	9757142	English/Spanish
	9762761	Brochure, Tips Safe Cooking


Illus. No.	Part No.	DESCRIPTION
2		Cooktop
	W10134940	White
	W10134939	Black
	W10134941	Biscuit
3		Element, Surface
	8523047	2400/1000 W - LF
	8273994	1200 W - LR & RR
	8273992	2500 W - RF

Illus. No.	Part No.	DESCRIPTION
4		Bracket, Element
	8272791	(2)
5	3196169	Screw
6	W10035930	Spring, Locator
7	3196170	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RF265LXTQ3, RF265LXTB3, RF265LXTT3, RF265LXTS3, RF265LXTY3
 (White) (Black) (Biscuit) (S.Steel) (Univ.Silver)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	W10009040	White Left Hand
	W10009050	White Right Hand
	W10009080	Black Left Hand
	W10009090	Black Right Hand
	W10009060	Biscuit, LH
	W10009070	Biscuit, RH
2	9762095	Bracket, Console
3		Panel, Control
	9762023	White
	9762026	Stainless Steel
	9762025	Black
	9762024	Biscuit


Illus. No.	Part No.	DESCRIPTION
4		Switch, Infinite
	9758060	Left Front (Dual)
	3148951	Left Rear
	3148951	Right Rear
	9758060	Right Front (Dual)
5	8523265	Light, Indicator
6	3196068	Lens, Light
7		Knob, Infinite (4)
	9761962	White
	9761964	Black
	9761963	Biscuit
8	W10134247	Shield, Heat
9	9762078	Brkt, Mntg EOC

Illus. No.	Part No.	DESCRIPTION
10	8272473	Cover, Rear
11		Control, Range
	W10108090	White
	W10108100	Black
	W10108110	Biscuit
12	3196178	Screw
13	9757609	Nameplate
14	3400882	Screw
15	8273564	Clip, Cover
16		Screw
	3196166	White
	3196168	Black
	8281194	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: RF265LXTQ3, RF265LXTB3, RF265LXTT3, RF265LXTS3, RF265LXTY3
 (White) (Black) (Biscuit) (S.Steel) (Univ.Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS


For Models: RF265LXTQ3, RF265LXTB3, RF265LXTT3, RF265LXTS3, RF265LXTY3
 (White) (Black) (Biscuit) (S.Steel) (Univ.Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9761299	Vent Tube Asmbly	16	W10058460	Foot, Rear (2)	35	3196174	Screw
2	8273905	Support, Corner LR	17	3195987	Guard, Wire	36	9758238	Retainer, Side (2)
3		Panel, Side (2)	18	9757239	Rod – Dr Switch	37	9760407	Brkt – Mounting
	8053830	White	19	3186116	Support, Oven (2)	38	9761013	Latch, Door
	8053832	Black	20	3186034	Bracket, Service	39	W10078380	Rod, Latch
	8272519	Biscuit	21	9761958	Block, Terminal	40	W10107820	Latch Asy, Rear
4	9761517	Clip,Door Mntg.(2)	22	8274034	Back, Main	41	9758701	Spacer, Door
5	8522416	Seal, Oven Door	23	9757262	Switch, Door	42	3196169	Screw
6	9757340	Element, Broil	24	3196701	Light Socket Assy	43	9758283	Cover, Box
7	9758541	Element, Bake (Hidden)	25	311255	Bulb, Oven Light	44	9761301	Screen – Catalyst
8	3195736	Support, Front (2)	27	8273902	Sensor, Oven	45	3196560	Screw (2)
9	3196548	Fuse, Thermal	28	3196179	Screw	46	112432	Nut (3)
10	W10114344	Glide, Drwr Top	29	3196178	Screw	47	9761490	Insulation
11	3196037	Foot, Front (2)	30	3400016	Screw	48	9761512	Clip, Mounting
12	W10067840	Screw	31	3196172	Screw	<u>INSULATION</u>		
13	8054068	Tray, Insulation	32	W10031780	Screw		8272616	Insulation, Wrap
14	3196576	Clip, Panel (6)	33	3196566	Screw		8272612	Insulation, Back
15	9760314	Rail, Base (2)	34	3196168	Screw		8272613	Insulation, Vent

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER PARTS

For Models: RF265LXTQ3, RF265LXTB3, RF265LXTT3, RF265LXTS3, RF265LXTY3
 (White) (Black) (Biscuit) (S.Steel) (Univ.Silver)



Illus. No.	Part No.	DESCRIPTION
1	W10138079	Rack, Oven (2)
2	9761031	Drawer, Storage
3	9758200	Brkt-Mntg, Drawer
4		Rivet, Push (2)
	3196814	White
	3196813	Black
	3196815	Almond


Illus. No.	Part No.	DESCRIPTION
5		Panel, Drawer Frnt
	8053339	White
	8053341	Black
	8272501	Biscuit
6	3196168	Screw
7	8053334	Glide, Drawer (2)

Illus. No.	Part No.	DESCRIPTION
8	W10031790	Screw(Stls. Model)
9	9781235	Clip(Stls. Model)
10	W10133363	Panel(Stls. Model)
11		Handle
	9757219	(Stainless Model)
	9762251	(Univ.Silver Mod.)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: RF265LXTQ3, RF265LXTB3, RF265LXTT3, RF265LXTS3, RF265LXTY3
 (White) (Black) (Biscuit) (S.Steel) (Univ.Silver)



Illus. No.	Part No.	DESCRIPTION
1	9761975	Trim, Top
	9762394	White
	9762391	Stainless Model
	9762391	Black
	9761976	Biscuit
	W10067560	Universal Silver
2	3196164	Screw
3		Handle, Door
	9761982	White
	9761983	Black
	9761984	Biscuit
	9761985	Universal Silver
4	9761344	Liner, Door
5	8522414	Seal, Window
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass
8	8272618	Insulation, Door

Illus. No.	Part No.	DESCRIPTION
9	9761357	Retainer, Insul.
10		Hinge, Door (2)
	9761493	White,Black,Bisc.
	9761496	Stainless Model
11		Glass, Outer
	W10075980	White
	W10075990	Black
	W10076000	Biscuit
	W10154806	Stainless Steel
12		Trim, Side
	8523172	White Left Hand
	8523166	White Right Hand
	8523171	Black Left Hand
	8523165	Black Right Hand
	8523173	Biscuit Left Hand
	8523167	Biscuit Right Hand
	W10113926	Gray Left Hand
	W10113925	Gray Right Hand

Illus. No.	Part No.	DESCRIPTION
13	3196160	Screw
14		Trim, Lower
	8523175	White
	8523177	Black
	8523178	Biscuit
	8523180	Stainless Model
	W10067550	Universal Silver
15	W10031790	Screw
16	W10031780	Screw
17	3196165	Screw
18	3196794	Bracket, Window(2)
19	W10113759	Strap, Door

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: RF265LXTQ3, RF265LXTB3, RF265LXTT3, RF265LXTS3, RF265LXTY3
 (White) (Black) (Biscuit) (S.Steel) (Univ.Silver)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

SPLICING WIRES--25FT.

LENGTH

- 242828 Wire, Black
12 Ga. 150° c
- 242821 Wire, Blue
14 Ga. 150°c
- 242822 Wire, Brown
14 Ga. 150°c
- 242830 Wire, Brown
14 Ga. 200°c
- 242823 Wire, Green
14 Ga. 150°c
- 242824 Wire, Orange
14 Ga. 150°c
- 242825 Wire, Red
14 Ga. 150°c
- 242831 Wire, Red
14 Ga. 200°c
- 242827 Wire, Yellow
14 Ga. 150°c

REFINISHING MATERIAL

- 799832 Kit, Porcelain
Repair (White)
- 242756 Touch-Up
Self-Clean(1/2 Pt)
- 261582 Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

INSULATION

- 240132 Insulation,
Fiberglass (2-1/2"
x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

- 72017 White
- 4392899 Biscuit
- 511873 White Porcelain
(2 Oz.)

**PAINT, PRESSURIZED SPRAY
(12 oz.)**

- 350930 White
- 4392901 Biscuit
- 285006 Superior Black
- 206922 Primer (White)

PAINT, BULK (1 qt.)

- 799344 White (Uncut)
- 4392900 Biscuit (Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ACCESSORY PARTS

- 241430 Foil, Aluminum
Oven (18" x 25')
- 3184478 Cleaner, Glass

ANTI-TIP KIT

- W10017440 Anti-Tip Kit

WIRING HARNESS PARTS

Following Parts Not Illustrated

- W10111767 Harness, Wire
(Cooktp Lft Dual)
- W10111766 Harness, Wire
(Cooktop Right)
- W10111768 Harness, Wire
(Main)
- W10084660 Harness, Wire
(Sensor/Dr Switch)
- W10144763 Tie, Wire
(Ceran Cktp)
- 8523279 Wire, Ground
- 313660 Clip, Ground Wire
- 3196154 Screw
- 3196173 Screw, Grnd Wire

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST