




COOKTOP PARTS

For Models: RS675PXGB0, RS675PXGQ0, RS675PXGZ0
(Black) (White) (Almond)

30" DROP-IN
ELECTRIC OVEN
SELF CLEAN



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	3192459	Burner Box
3	3192330	Bracket, Mounting
	3400843	Screw, 8-18 x 3/8
4		Cooktop
	3191169	Almond
	3191168	White
	3191167	Black
5	3195210	Clip, Mtg. (4)
6		Panel, Control
	3191230	Almond
	3191229	White
	3191228	Black
7		Switch, Infinite
	3191471	Use W/6" Surface (Blue Shaft)
	3191473	Use W/8" Surface (Red Shaft)
	3400855	Screw, 8-32 x 1/4
8	3191491	Light, Indicator
11		Pan, Surface
	3195208	6" Pan
	3195209	8" Pan
12		Element, Surface
	8053266	6" Burner
	8053268	8" Burner
14		Knob, Control
	3196232	White
	3196233	Almond
	3196231	Black
15	3183956	Seal, Switch Shaft (4)
18		Trim, Extension
	3192103	White
	3192104	Almond
	3192102	Black
19	3195917	Clip, Element

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: RS675PXGB0, RS675PXGQ0, RS675PXGZ0
(Black) (White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: RS675PXGB0, RS675PXGQ0, RS675PXGZ0
(Black) (White) (Almond)

Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1		Trim, Side (Right Hand)
	4450845	White
	4450846	Almond
	4450844	Black
	4449747	Screw
		(Left Hand)
	4450848	White
	4450849	Almond
	4450847	Black
	4449747	Screw
4	4448520	Bumper, Door
7	4452237	Top Chassis
	4449809	Screw
9	4452158	Tube, Vent
	4449154	Screw
10	4452165	Lens, Light
11	4452368	Oven Light Assy
12	4452166	Bulb, Light
14	4451740	Frame, Front
	4449040	Screw
	4450118	Nut

Illus. No.	Part No.	DESCRIPTION
15	4449372	Gasket, Door
19	4451478	Support, Insulation
	4449809	Screw
21		Rail, Side
	4450579	Right Side
	4450580	Left Side
	4448444	Grommet
	4449154	Screw
22	4451424	Latch Assembly
23	4451663	Solenoid
24	4451422	Micro Switch N.C.
	4449154	Screw
25	4454691	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4452234	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
28	4451426	Micro Switch
29	4451665	Sensor
	4449154	Screw
30	4451537	Spring, Latch

Illus. No.	Part No.	DESCRIPTION
37	4451442	Thermostat (TOD) (Temp.) SPST
43	4451398	Base, Chassis
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
53	4449845	Support, Bracket
	4449809	Screw
	4449809	Screw
55		Trim, Bottom
	4448478	White
	4448862	Almond
	4448477	Black


**FOLLOWING PARTS
NOT ILLUSTRATED**

INSULATION

4449316	Insulation, Wrap
4450365	Insulation, Back

CONTROL PANEL PARTS

For Models:RS675PXGB0, RS675PXGQ0, RS675PXGZ0
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	4451232	Control Panel Assy. White
	4451233	Almond
	4451231	Black
		W/Membrane Switch
	4449745	Screw
2	4451034	Gasket, Control Panel
3	4452240	Microcomputer
	4449745	Screw


LITERATURE PARTS

LIT3191799	Installation Instructions
LIT3191537	Use & Care Guide
LIT3192238	Tech Sheet
LIT3191638	Safer Cooking Tips

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: RS675PXGB0, RS675PXGQ0, RS675PXGZ0
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451719	Door Liner
2	4454947	Hinge, Door
	4449743	Screw
3	4449259	Glass, Inner
4	4451722	Insulation, Door

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

7	4449263	Glass, Inner (2)
9	4451668	Retainer, Glass
	4449809	Screw
13		Door Handle
	4448855	White
	4448856	Almond
	4448854	Black
14	4450813	Bracket, Handle
	4451040	Screw
15		Door Assembly, Glass
	4452066	White
	4452067	Almond
	4452065	Black


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

19	4450362	Shield, Heat
	4449809	Screw
20	4451671	Retainer, Glass
	4449809	Screw
21	4451674	Seal, Door Top
23		Retainer, Clip
	4450864	White
	4450865	Almond
	4449743	Black

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: RS675PXGB0, RS675PXGQ0, RS675PXGZ0
 (Black) (White) (Almond)




Illus. No.	Part No.	DESCRIPTION
2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448717	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models:RS675PXGB0, RS675PXGQ0, RS675PXGZ0
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
	4449040	Screw, 8-18 x 3/8
2	4451438	Elbow, Vent Top
3	6610168	Blower,Upper/Lower
4	4451758	Block, Foam
5	4451752	Elbow, Vent Bottom
11	4449868	Block, Terminal
	3196181	Screw
13	4448549	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Compt.
	3191832	Right
	3191833	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
20	3191842	Cover, Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:RS675PXGB0, RS675PXGQ0, RS675PXGZ0
(Black) (White) (Almond)

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	261869	Cord Brown
	72032	Black
<u>PAINT, SPRAY</u>		
	350930	White
	261900	Citrine White
	830864	Black
<u>ADHESIVE</u>		
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
<u>SPLICING WIRES--25FT.</u>		
<u>LENGTH</u>		
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
<u>WIRING HARNESS PARTS</u>		
	3191220	Harness, Wire (Main)
	4454918	Harness, Wire (Surface)
	4451163	Conduit
	4448664	Clamp
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground
	3192236	Harness, Wire (Infinite Switch)
	3192245	Harness, Wire (Light)
	4454384	Ground, Wire
<u>Miscellaneous</u>		
	814381	Hinge Pin Kit
	4448950	Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST