


# COOKTOP, BURNER AND GRATE PARTS

For Models: SCS3617RB01, SCS3617RQ01, SCS3617RS01, SCS3617RT01  
(Black) (Designer White) (Stainless) (Biscuit)



36" GAS COOKTOP



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	3192098	Wiring Diagram
	8286304	Installation Instructions
	8286615	Use & Care Guide
	3191638	Safe Cooking Tips
	9759133	Safe Cooking Tips
	8286620	LP Conversion Instructions
2		Panel, Control
	8286502	Black
	8286503	White
	8286504	Biscuit
3		Cooktop
	3191252	Black
	3191253	White
	3191289LM	Stainless
	8284706	Biscuit

Illus. No.	Part No.	DESCRIPTION
4		Cap, Burner
		6K (1)
	8286153CB	Coal Matte Black
	8286153CG	Cumberland Gray
	8286153EP	Espresso
		9.5K (2)
	8286154CB	Coal Matte Black
	8286154CG	Cumberland Gray
	8286154EP	Espresso
		12.5K (1)
5		Grate
		R.Hand
	8285885CB	Coal Matte Black
	8285885CG	Cumberland Gray
	8285885EP	Espresso
		L.Hand
	8285887CB	Coal Matte Black
	8285887CG	Cumberland Gray
	8285887EP	Espresso

Illus. No.	Part No.	DESCRIPTION
7		Knob, Control (4)
	8286057BL	Black
	8286057WH	White
	8286057BT	Biscuit
10	9760279	Seal, Foam
15		Holder, Orifice
	8286513	Auxi
	8286178	Semi Rapid
	8286180	Rapid
16		Head, Burner
	8286182	12K Rapid
	8286181	6K Auxi
	8286184	9K Semi-Rapid
18	4449809	Screw


**Following Parts Not Illustrated**

		Harness, Wire Ignitor
	4456626	15"
	4456627	28"

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BURNER BOX, GAS VALVES, AND SWITCHES

For Models: SCS3617RB01, SCS3617RQ01, SCS3617RS01, SCS3617RT01  
(Black) (Designer White) (Stainless) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BURNER BOX, GAS VALVES, AND SWITCHES

For Models: SCS3617RB01, SCS3617RQ01, SCS3617RS01, SCS3617RT01  
(Black) (Designer White) (Stainless) (Biscuit)

<u>Illus.</u> <u>No.</u>	<u>Part</u> <u>No.</u>	<u>DESCRIPTION</u>
1	4455917	Bracket, (2) Cocktop mounting
2	9759354	Pipe, Manifold
3	4456905	Harness & Switches
4	8522423	Spark Module
5		Valve, Burner
	4456817	Large (Black)
	8286559	Auxi (White)
	8286560	Rapid (Purple)
6	9763116	Power Cord
7	4173634	Bushing, Cord
8	3177991	Screw, Ground
9	3186217	Bolt, Gas Valve
10	3191318	Tubing, Burner RR & RF
11	3192491	Bracket, Manifold
12	3191322	Tubing, Burner LR & LF
13	3400093	Screw
14	4456781	Box, Burner
15	3400843	Screw
16	4449809	Screw
17	8286099	Rail, Burner (2)
18	3191387	Seal, (4) Switch Cover

---

## Following Parts Not Illustrated and Optional Parts Not Included

---

8286320	Gas Conversion Kit (Natural Gas To LP Gas)
4455918	Hardware Kit (Mounting)