




COOKTOP PARTS

For Model: RF315PCYW2, RF315PCYN2
(White) (Almond)

30" ELECTRIC
FREESTANDING
CONVENTIONAL
RANGE



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	3148790	Clip, Mtg. (4)
	487887	Screw
	814102	Nut
3	312606	Clip, Retainer (4)
	313808	Screw 6-32x9/32
7	3169186	Box, Burner
	309112	Screw, 10A x 3/8 (4)
8	307973	Shield, Wiring
	343641	Screw, 10-16 x 1/2 (4)
9	3148659	Rod, Cooktop (2)
11	307965	Bracket, Cooktop (2)
	343641	Screw 10-16 x 1/2 (4)
12	307966	Pin, Cooktop (2)
	343641	Screw, 10-16 x 1/2 (4)
13		Cooktop
	3170981	White
	3170982	Almond
	690989	Screw, 10-32 x 1/2
15	308605	Strain Relief
	343641	Screw, 10-16 x 1/2
18		Pan, Reflector
	3169204	6" (2)
	3169205	8" (2)
19		Unit, Surface
	660529	6" Element (2)
	660533	8" Element (2)
		(Includes Illus. 20)
20	309195	Medallion (4)

**FOLLOWING PARTS
NOT ILLUSTRATED**

LITERATURE PARTS


LIT3187321	Installation Instructions
LIT3182487	Wiring Diagram
LIT3187470	Use & Care Guide
LIT3150400	Installation Instr (Templet)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: RF315PCYW2, RF315PCYN2

(White) (Almond)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			7	3183184	ERC Timer Control	13		Indicator Light
				246132	Screw (2)		314031	Oven Unit On
			9	3182987	Panel, Control		3150662	Surface Unit On
				312604	Screw,	14	3183118	Knob, Control (4)
					8-18 x 5/8 (4)			(Infinite Switch)
			10		Switch, Infinite	15	3183106	Knob, Control
1	313191	End Trim R.H.		3148951	6" Unit (2)			(Thermostat)
	313190	End Trim L.H.		3148954	8" Unit (2)	16	313570	Tube Clip
	309112	Screw,		308119	Screw,	17	3187332	Rear Cover
		10A x 3/8 (2)			8-32 x 3/16 (8)			Control Panel
	343641	Screw,	11	3149886	Switch, Selector		343641	Screw,
		10-16 x 1/2 (4)			(4 Position)			10-16 x 1/2 (8)
2	313230	End Cap R.H.		3150344	Screw (2)	18	313101	Lens, Amber (2)
	313231	End Cap L.H.	12	661150	Thermostat, Oven	19	313608	Shield, Glass (2)
	254225	Screw,			310864 (Alt.)		246132	Screw,
		8BT x 1/4 (4)			311498 (Alt.)			8A x 3/8 (2)
5	3182717	Switch, Rocker		311932	Screw,	20	3183112	Knob, Control
					6-32 x 1/4 (2)			(Selector)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Model: RF315PCYW2, RF315PCYN2
(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Model: RF315PCYW2, RF315PCYN2
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	307981	Bracket, Mounting (2)
2	3169076	Pan, Broil
3	3147563	Grid, Broiler
4	661170	Unit, Bake (240V)
	3150532	Screw, 10-32 x 7/16 (2)
5	660579	Unit, Broil 311714 (Alt.) 311713 (Alt.)
	3150532	Screw, 10-32 x 7/16 (2)
6	258076	Terminal Block
	98884	Screw, 10-16 x 1 (2)
	112432	Nut (6)
7	308498	Ground Strap
	313660	Clip
	690989	Screw, 10-32 x 1/2
8	3150190	Bracket, Service
	343641	Screw, 10-16 x 1/2 (2)
10	3148975	Cover, Rear
	343641	Screw, 10-16 x 1/2 (7)
11	307972	Cover, Service
	343641	Screw, 10-16 x 1/2 (2)
12		Rail, Drawer
	3149256	L.H.
	3149255	R.H.
13	3149257	Glide, Drawer (2)
14	308173	Rack, Oven (Straight)
15	308172	Rack, Offset
17	313438	Clip, Harness
18	3149258	Block, Balance
	340184	Screw, 10-16 x 1-1/2


Following Parts Not Illustrated

309961	Insulation, Oven Wrap
814091	Anti-Tip Kit (Floor Mount)

DOOR AND DRAWER PARTS

For Model: RF315PCYW2, RF315PCYN2

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Model: RF315PCYW2, RF315PCYN2
(White) (Almond)


<u>Illus.</u>	<u>Part</u>	
<u>No.</u>	<u>No.</u>	<u>DESCRIPTION</u>

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	3172220	Liner, Door
	3148443	Screw, #8-18 x 5/16 (6)
2	3148183	Seal, Glass
3	3169202	Glass, Inner
4	3148287	Retainer
	3148443	Screw (6)
5		Glass Panel, Outer
	3149049	White
	3149050	Almond
6	3148282	Clip (2)
7	3148228	Handle, Door
	355515	Screw, 8A x 7/8 (4)
8	3148235	Frame, Door
	307748	Screw (3)
9	3148223	Top, Door Frame
	355515	Screw (2)
10	307980	Glide, Rear
	3393008	Screw, (2) 8-18 x 1/2
11	327887	Drawer, Utility
12		Panel, Drawer
	307935	White
	307939	Almond
	313349	Screw, (3) 8-18 x 1/2
13	3169105	Handle, Drawer
	313349	Screw, (2) 8-18 x 1/2
14	309329	Protector, Drawer (2)

OVEN PARTS

For Model: RF315PCYW2, RF315PCYN2
(White) (Almond)



Illus. Part No. No. DESCRIPTION

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	330086	White
	330090	Almond
	690989	Screw, 10-32 x 1/2
2	238614	Bumper, Cooktop (2)
3	312701	Leg Leveling (4)
4	3176714	Frame, Front
	343641	Screw, 10-16 x 1/2 (13)
5	307985	Pin, Hinge

Illus. Part No. No. DESCRIPTION

6	311255	Bulb, Light
7	308306	Pushnut
8	3176710	Hinge, R.H.
	3176711	Hinge, L.H.
	343641	Screw, 10-16 x 1/2 (4)
9	3176611	Oven (30" Conv)
	311056	Screw (2)
	3150537	Screw
10	3150505	Socket, Oven Light
15	311220	Bracket, Oven Mounting
	343641	Screw, 10-16 x 1/2 (4)
16	3169143	Vent, Oven
	307748	Screw, 10A x 1/2 (2)
19	3176708	Channel, Arm (2)

Illus. Part No. No. DESCRIPTION


20	307986	Hinge Pin (2)
21	307594	Ring, Retainer (2)
22	308127	Spring, Oven Door (2)
23	308125	Anchor, Spring (2)
24	313196	Support, Channel L.H.
	313197	R.H.
	343641	Screw, 10-16 x 1/2 (4)
25	310345	Switch, Door
27	313382	Clip, Therm Bulb (2)
29	309111	Snubber, Door (2)
30	308207	Spring, Door Stop
31	3169283	Seal, Rubber
32	3169107	Plug, Button (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS



For Model: RF315PCYW2, RF315PCYN2

(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- | | | |
|---|---------|-------------------------------|
| 1 | 3149881 | Wiring Harness (Surface Unit) |
| 2 | 3169155 | Wiring Harness (Oven) |
| 4 | 313154 | Wiring Harness (Oven Light) |
| 5 | 330031 | Receptacle |



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS NOT INCLUDED

For Model: RF315PCYW2, RF315PCYN2

(White) (Almond)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<div style="display: flex; justify-content: space-between;"> <div style="width: 33%;"> <p><u>SPLICING WIRES--25FT. LENGTH</u></p> <p>242828 Wire, Black 12 Ga. 150°c</p> <p>242820 Wire, Black 14 Ga. 150°c</p> <p>242821 Wire, Blue 14 Ga. 150°c</p> <p>242822 Wire, Brown 14 Ga. 150°c</p> <p>242830 Wire, Brown 14 Ga. 200°c</p> <p>242823 Wire, Green 14 Ga. 150°c</p> <p>242824 Wire, Orange 14 Ga. 150°c</p> <p>242829 Wire, Red 12 Ga. 150°c</p> <p>242825 Wire, Red 14 Ga. 150°c</p> <p>242831 Wire, Red 14 Ga. 200°c</p> <p>242826 Wire, White 14 Ga. 150°c</p> <p>242827 Wire, Yellow 14 Ga. 150°c</p> <p>242832 Wire, Yellow 14 Ga. 200°c</p> </div> <div style="width: 33%;"> <p><u>PAINT, TOUCH-UP (1/2oz.)</u></p> <p>Paint, Touch-Up 1/2 oz.</p> <p>72017 White</p> <p>72107 Almond</p> <p>72109 New Avocado</p> <p>72108 Coffee</p> <p>72110 Harvest Gold</p> <p>72112 Toast</p> <p>72113 Platinum</p> <p>*511873 White Porcelain (2 Oz.) Paint, Spray 13 Oz.</p> <p><u>PAINT, PRESSURIZED SPRAY (13 oz.)</u></p> <p>350930 White</p> <p>350956 Almond</p> <p>261888 New Avocado</p> <p>261886 Coffee</p> <p>261890 Harvest Gold</p> <p>285365 Toast</p> <p>285366 Platinum</p> <p>285006 Superior Black</p> <p>206922 Primer (White)</p> <p>206925 Leveler (Thinner) (2 oz.) Paint, Bulk 1 Qt.</p> <p><u>PAINT, BULK (1 qt.)</u></p> <p>799344 White (Uncut)</p> <p>978883 Almond (Uncut)</p> <p>261891 Harvest Gold (Uncut)</p> <p>285367 Toast (Uncut)</p> <p>285368 Platinum (Uncut)</p> </div> <div style="width: 33%;"> <p><u>REFINISHING MATERIAL</u></p> <p>799832 Kit, Porcelain Repair (White)</p> <p>242756 Touch-Up Self-Clean (1/2 Pt.)</p> <p>261582 Grease</p> <p><u>INSULATION</u></p> <p>261514 Insulation, Fiberglass (1-1/2" x 24" x 120"</p> <p>240132 Insulation, Fiberglass (2-1/2" x 22" x 120"</p> <p>241430 Foil, Aluminum Oven (18" x 25')</p> <p><u>ANTI-TIP KIT</u></p> <p>814234 Wall Mount</p> <p><u>Following May Be Purchased</u></p> <p><u>DO-IT-YOURSELF REPAIR MANUALS</u></p> <p>LIT677973 Manual, Range</p> </div> </div>		

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST