




COOKTOP PARTS

For Models: GS563LXSQ0, GS563LXST0, GS563LXSB0, GS563LXSS0
(Designer White)(Designer Biscuit)(Black)(Black Stainless)

30" GAS FREESTANDING
SELF CLEAN RANGE
SEALED BURNER



Illus. No.	Part No.	DESCRIPTION
1	9763002	Literature Parts Guide, Use & Care Tech Sheet
	9762983	English
	W10041630	French
	9762997	Instructions, Installation
	9757142	Spanish
	9757143	French
		Safer Cooking Tips
	9762761	(English)
	9759133	(French)
2		Cap, Burner LR
	3192487	Black
	9763244	Grey
	9763248	Espresso LF - RF
	3192488	Black
	9763243	Grey
	9763247	Espresso RR
	3192486	Black
	9763242	Grey
	9763246	Espresso


Illus. No.	Part No.	DESCRIPTION
4		Burner
	4455981	LF-RF
	4455980	LR
	4455979	RR
5		Cooktop
	8272251	White
	8272253	Black
	8272743	Biscuit
6		Panel, Manifold
	8523855	Black
	8523854	White
	8523856	Biscuit
7		Knob, Control (2)
	8273279	Black
	8522623	White
	8522626	Biscuit

Illus. No.	Part No.	DESCRIPTION
8		Knob, Accusimmer
	8273280	Black
	8522625	White
	8522628	Biscuit
9		Knob, Powerburner
	8273281	Black
	8522624	White
	8522627	Biscuit
12		Grate
	9762228	Gray
	9762229	Espresso
	9763283	Black
14	3400701	Screw
15	3196557	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER & BROILER PARTS

For Models: GS563LXSQ0, GS563LXST0, GS563LXSB0, GS563LXSS0
(Designer White)(Designer Biscuit)(Black)(Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1	8274021	Rack, Partial
2	3195996	Grill, Broiler
3	3196076	Pan, Broiler
4	9761031	Drawer, Storage
5	3196817	Bracket, Drawer(2)
6	3196814	Rivet, Push (2) White
	3196815	Almond
	3196813	Black


Illus. No.	Part No.	DESCRIPTION
7	8053336	Panel, Drawer Frnt White
	8053338	Black
	8272502	Biscuit
8	8053334	Spacer, Glide White,Blk,Biscuit
	9758701	Stainless Steel

Illus. No.	Part No.	DESCRIPTION
9	9761033	Drawer, Liner
10	3196168	Screw
11	8274022	Rack, Insert
12	3195710	Rack, Oven
13		Stnlss Mdl Only
14	9755797	Panel,Stnlss Stl
15	9762251	Handle, Drawer
16	9781235	Speed Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Models: GS563LXSQ0, GS563LXST0, GS563LXSB0, GS563LXSS0
(Designer White)(Designer Biscuit)(Black)(Black Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Models: GS563LXSQ0, GS563LXST0, GS563LXSB0, GS563LXSS0
(Designer White)(Designer Biscuit)(Black)(Black Stainless)


Illus. No.	Part No.	DESCRIPTION
1	8273096	Screw, Valve
2		Burner Base
	8273700	Large (3)
	8273701	Small (1)
3		Tubing, Burner W/Orifice
	8273692	Left Front
	8273694	Left Rear
	8273696	Right Front
	8273697	Right Rear
4	8523433	Tubing (Manifold to Regulator)
5	8523406	Harness, Igniter (W/Switches)
6	8523793	Electrode (4)
7	8523407	Pipe, Manifold
8		Valve
	9757218	LF – RF – LR
	8273004	Right Rear
9	8273060	Nut (4)
10	8273062	Screw (4)
11	3400228	Bolt
12	8054078	Burner, Broiler
13	8053970	Spreader, Flame (Oven)
14	9758078	Burner, Bake
15	9761959	Valve/Regulator
16		Igniter
	8054129	Broil
	9758079	Bake
17	8272222	Tubing (Broiler Fitting To Valve)
18	3186489	Fitting, Broiler
19	8272403	Cover, Igniter
20		Orifice, Burner
	8273065	Left Front
	8273064	Right Front
	8273065	Left Rear
	8273067	Right Rear
21	8053262	Spreader, Flame (Broiler)
22	9758382	Valv-Soln/Shtoff
23	3196265	Screw
24	3196176	Screw
25	3196385	Screw
26	3400016	Screw
27	8272470	Tube(GPR-Shutoff)

Following Parts Not Illustrated

8523422 Spuds, LP Gas
(Kit of 4)

CHASSIS PARTS


For Models: GS563LXSQ0, GS563LXST0, GS563LXSB0, GS563LXSS0
(Designer White)(Designer Biscuit)(Black)(Black Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GS563LXSQ0, GS563LXST0, GS563LXSB0, GS563LXSS0
(Designer White)(Designer Biscuit)(Black)(Black Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS


For Models: GS563LXSQ0, GS563LXST0, GS563LXSB0, GS563LXSS0
 (Designer White)(Designer Biscuit)(Black)(Black Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Endcap, Left Hand
	W10009080	Black
	W10009040	White
	W10009060	Biscuit
		Endcap, Right Hand
	W10009090	Black
	W10009050	White
	W10009070	Biscuit
	3	
9762586		Black
9762585		White
9762587		Biscuit
9762588		Unvsl Slvr fr SS
4		Glss, Swtch Memb
	9763256	White
	9763262	Black
	9763252	Biscuit
5	9758080	Module, Spark
6	8053505	Shield, Lower Heat
7	8523412	Bracket, Support
8	W10036170	Cover, Upper
9	8053910	Shield, Heat
10	8273132	Cover, Lower
11	3196170	Screw
12	9762969	Control, Range
13	3196178	Screw
14	9760080	Cnnctr Cbl, Flex
15	9757613	Nameplate
16	9757490	Support, Glass
17	9762589	Module, Light
18	9762855	Brkt-Mntg, Console
20	9762253	Bracket, DSI

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: GS563LXSQ0, GS563LXST0, GS563LXSB0, GS563LXSS0
(Designer White)(Designer Biscuit)(Black)(Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9762391	Trim, Top Black
	9761975	White
	9761976	Biscuit
	9761977	Stainless Steel
2	3196164	Screw
3	9761979	Handle, Door Black
	9761978	White
	9761980	Biscuit
	9761981	Stainless Steel
4	9761344	Liner, Door
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass

Illus. No.	Part No.	DESCRIPTION
9	8272618	Insulation, Door
10	9761496	Hinge, Door
11	9761357	Retainer, Insul.
12	8523171	Trim, Door Side Left Hand Black
	8523172	White
	8523173	Biscuit
	9762249	Universal Silver Right Hand
	8523165	Black
	8523166	White
	8523167	Biscuit
	9762250	Universal Silver

Illus. No.	Part No.	DESCRIPTION
13	W10010680	Glass, Outer Door Black
	W10010660	White
	W10010670	Biscuit
14	3196160	Screw
15	3196025	Clip, Door Glass
16	W10031780	Screw
18	W10031790	Screw
19	8523177	Trim, Bottom Black
	8523175	White
	8523178	Biscuit
21	3196794	Bracket, Window
22	3196165	Screw
23	9761517	Clip, Door Mntg(2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: GS563LXSQ0, GS563LXST0, GS563LXSB0, GS563LXSS0
(Designer White)(Designer Biscuit)(Black)(Black Stainless)

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated		

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black 12 Ga. 150° c
242821	Wire, Blue 14 Ga. 150°c
242822	Wire, Brown 14 Ga. 150°c
242830	Wire, Brown 14 Ga. 200°c
242823	Wire, Green 14 Ga. 150°c
242824	Wire, Orange 14 Ga. 150°c
242825	Wire, Red 14 Ga. 150°c
242831	Wire, Red 14 Ga. 200°c
242827	Wire, Yellow 14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
<u>INSULATION</u>		
	261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
	240132	Insulation, Fiberglass (2-1/2" x 22" x 120")
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	72107	Almond
	4392899	Biscuit
	511873	White Porcelain (2 Oz.)
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>		
	350930	White
	350956	Almond
	4392901	Biscuit
	285006	Superior Black
	206922	Primer (White)
<u>PAINT, BULK (1 qt.)</u>		
	799344	White (Uncut)
	978883	Almond (Uncut)
	4392900	Biscuit (Uncut)

Illus. No.	Part No.	DESCRIPTION
<u>ACCESSORY PARTS</u>		
	241430	Foil, Aluminum Oven (18" x 25')
<u>ANTI-TIP KIT</u>		
	W10017440	Anti-Tip Kit
<u>WIRING HARNESS PARTS</u>		
	9762965	Harness, Main
	9761165	Harness,Grnd DSI
	8524207	Harness, Bake &
	8523599	Harness, Wire (Cooktop Spark)
	3196696	Clip, Harness
	3196520	Clip, Wire
	3196896	Clip, Wire
	313438	Clip, Harness
	3196174	Screw,Grnd Hrns
<u>Miscellaneous</u>		
	814381	Pin Kit-Dr Removal